


FURUNO

OPERATOR'S MANUAL

INSTRUMENT

Model **FI-504/FI-507**



FURUNO ELECTRIC CO., LTD.

www.furuno.com



ECF

(Elemental Chlorine Free)

The paper used in this manual
is elemental chlorine free.

FURUNO ELECTRIC CO., LTD.

9-52, Ashihara-cho,
Nishinomiya, 662-8580, JAPAN

•FURUNO Authorized Distributor/Dealer

All rights reserved.

Printed in Japan

A : OCT. 2007
F : OCT. 31, 2012

Pub. No. OME-72690-F
(REFU) FI-504/507



* 00016733415 *

IMPORTANT NOTICES

General

- This manual has been authored with simplified grammar, to meet the needs of international users.
- The operator of this equipment must read and follow the descriptions in this manual. Wrong operation or maintenance can cancel the warranty or cause injury.
- Do not copy any part of this manual without written permission from FURUNO.
- If this manual is lost or worn, contact your dealer about replacement.
- The contents of this manual and equipment specifications can change without notice.
- The example screens (or illustrations) shown in this manual can be different from the screens you see on your display. The screens you see depend on your system configuration and equipment settings.
- Save this manual for future reference.
- Any modification of the equipment (including software) by persons not authorized by FURUNO will cancel the warranty.
- All brand and product names are trademarks, registered trademarks or service marks of their respective holders.

How to discard this product


Discard this product according to local regulations for the disposal of industrial waste. For disposal in the USA, see the homepage of the Electronics Industries Alliance (<http://www.eiae.org/>) for the correct method of disposal.

How to discard a used battery

Some FURUNO products have a battery(ies). To see if your product has a battery, see the chapter on Maintenance. Follow the instructions below if a battery is used. Tape the + and - terminals of battery before disposal to prevent fire, heat generation caused by short circuit.


In the European Union

The crossed-out trash can symbol indicates that all types of batteries must not be discarded in standard trash, or at a trash site. Take the used batteries to a battery collection site according to your national legislation and the Batteries Directive 2006/66/EU.



In the USA

The Mobius loop symbol (three chasing arrows) indicates that Ni-Cd and lead-acid rechargeable batteries must be recycled. Take the used batteries to a battery collection site according to local laws.



In the other countries

There are no international standards for the battery recycle symbol. The number of symbols can increase when the other countries make their own recycle symbols in the future.



SAFETY INSTRUCTIONS

The operator of this equipment must read these safety instructions before attempting to operate the equipment.



WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



Warning, Caution



Prohibitive Action



Mandatory Action

Safety instructions for the operator



WARNING



Do not open the equipment.

Only qualified personnel should work inside the equipment.



Do not disassemble or modify the equipment.

Fire or electrical shock can result if the equipment is modified.



Do not operate the equipment with wet hands.

Electrical shock can result.



Make sure no rain or water splash leaks into the equipment.

Fire or electrical shock can result if water leaks into the equipment.



Immediately turn off the power at the switchboard if water leaks into the equipment.

Continued use of the equipment can cause fire or electrical shock.

Warning Label

A warning label is attached to the equipment. Do not remove the label. If the label is missing or damaged, contact a FURUNO agent or dealer about replacement.

Safety instructions for the installer



WARNING



Turn off the power at the switchboard before beginning the installation.

Turn off the power to prevent electrical shock.



Make sure the installation site is not subject to water spray.

Fire or electrical shock can result if water leaks into the equipment.



CAUTION



Observe the following compass safe distances to prevent interference to the instruments:

	Standard compass	Steering compass
FI-504	0.35 m	0.30 m
FI-507		0.25 m

WARNING
DO NOT OPEN,
DANGEROUS
VOLTAGES INSIDE

警告
高電圧部分が
内部にあるた
め、開けな
いこと。

FURUNO
INSTRUMENT

MODEL

SER.NO.

COMPASS SAFE DISTANCE

STD (0.35) m STEER 0 m

Made in Japan

FURUNO ELECTRIC CO., LTD.
<http://www.furuno.co.jp>

TABLE OF CONTENTS

FOREWORD	iv
SYSTEM CONFIGURATION	v
1.OPERATION	1
1.1 Operating Controls, Display Layout.....	1
1.2 Turning the Power On/Off	2
1.3 Adjusting Brilliance and Contrast	2
1.4 Selecting a Display	3
1.5 Selecting Apparent or True Wind Angle, Wind Speed.....	8
1.6 Resetting Counters and Indications	8
1.7 Alarms	9
1.8 Timers	11
2. MAINTENANCE, TROUBLESHOOTING	13
2.1 Preventive Maintenance.....	13
2.2 Troubleshooting.....	14
3. INSTALLATION	15
3.1 Equipment Lists.....	15
3.2 Mounting.....	16
3.3 Wiring	18
3.4 Setting Up.....	21
SPECIFICATIONS	SP-1
PACKING LIST	A-1
OUTLINE DRAWINGS.....	D-1
INTERCONNECTION DIAGRAM	S-1

FOREWORD

A Word to the Owner of the FI-504, FI-507

Congratulations on your choice of the FURUNO FI-504 Multi/FI-507 Multi XL displays, members of the FI-50 series of marine instruments. We are confident you will see why the FURUNO name has become synonymous with quality and reliability.

Since 1948, FURUNO Electric Company has enjoyed an enviable reputation for quality marine electronics equipment. This dedication to excellence is furthered by our extensive global network of agents and dealers.

This equipment is designed and constructed to meet the rigorous demands of the marine environment. However, no machine can perform its intended function unless operated and maintained properly. Please carefully read and follow the recommended procedures for operation and maintenance.

Thank you for considering and purchasing FURUNO equipment.

Features


The FI-504 Multi/FI-507 Multi XL displays provide heading, environment, autopilot, engine, depth, speed, and wind information, all on a high quality, backlit LCD. The sturdy weather-proof case is built to stand up to even the harshest of environments.

The main features are

- Eight varieties of displays: heading, environment, autopilot, engine, depth, speed, timer, and wind.
- Four levels of backlighting including off.
- Timers: Stopwatch and count-down
- Depth alarms: Shallow alarm, Deep alarm
- Anchor alarms: Shallow alarm, Deep alarm
- Voltage alarm monitors power source voltage
- Wind alarms: High apparent wind angle, Low apparent wind angle, Max. true wind speed, Low true wind speed
- Speed indications: Max. STW, Average STW, SOG, Max. SOG, Average SOG, Wind speed, Max. true wind speed
- Log indication from 0 to 99,999 nm
- Resettable trip counter, from 0 to 999 nm


SYSTEM CONFIGURATION

Standalone configuration



NOTICE: Turn on the terminal resistor in the instrument when connecting an NMEA 2000 sensor or CAN bus device. For the procedure, see the section on setting up, in the installation chapter.

CAN bus network




NOTICE: Turn on the terminal resistor in the terminator of the CAN bus network.

1. OPERATION

Provided applicable sensors are connected, the FI-504/FI-507 provides the following information, all on a backlit LCD:

- Depth
- Speed
- Heading
- Environment data
- Autopilot (rudder)
- Engine
- Wind
- Timers
- Navigation data

1.1 Operating Controls, Display Layout




Key name	Function
SELECT/CLEAR	<ul style="list-style-type: none">• Select menu option.• Silence alarm.• Clear data.• Reset counters and indications.• Increment value.
APP/TRUE	<ul style="list-style-type: none">• Select aparent or true (wind) alternately.• Decrement value.
MODE	Select a display.
DISP key	<ul style="list-style-type: none">• Turn on power.• Select a display category.

Note: The example screens shown in this manual are taken from the FI-504. The screens from the FI-507 may be different.

1.2 Turning the Power On/Off

To power the instrument, press the **DISP** key. All LCD segments go on and off and then the last-used display appears.


To power off the instrument, press the **DISP** and **MODE** keys together (about 7-10 seconds). The timer appears and counts down from three seconds to one second, and then the power goes off.




Power OFF sequence

1.3 Adjusting Brilliance and Contrast

1. Press the **DISP** and **MODE** keys together. The display for adjustment of brilliance appears, with current brilliance setting flashing.



2. Within seven seconds of completing step 1, press the **APP/TRUE** key to lower the brilliance, or the **SELECT/CLEAR** key to raise it.
3. Press the **DISP** and **MODE** keys together. The display for adjustment of contrast appears, with current contrast setting flashing.




4. Within seven seconds of completing step 3, press the **APP/TRUE** key to lower the contrast, or the **SELECT/CLEAR** key to raise it.
5. Press the **DISP** and **MODE** keys together to save the settings and restore normal operation.

The brilliance and contrast will be the same on all units which are synchronized. (For how to synchronize units, see page 26.)

1.4 Selecting a Display







Use the **DISP** key to select a display category. Select desired display with the **MODE** key.



1. OPERATION

1.4.1 Display description

Depth category

Display title	Indication	Function
Current depth	DPTH	Current depth, in meters, feet or fathoms.
Shallow alarm	 SHALLOW	Set shallow depth alarm. Audio and visual alarms are released when the depth is lower than the threshold value.
Deep alarm	 DEEP	Set deep depth alarm. Audio and visual alarms are released when the depth is higher than the threshold value.
Shallow anchor alarm	  SHALLOW	Set shallow anchor alarm. Audio and visual alarms are released when the depth is lower than the threshold value.
Deep anchor alarm	  DEEP	Set deep anchor alarm. Audio and visual alarms are released when the depth is higher than the threshold value.





Speed category

Display title	Indication	Function
Boat speed	SPD	Boat speed, in knots (kt), miles per hour (MPH) or kilometers per hour (KMH).
Maximum STW	MAX SPD	Maximum boat speed, in knots (kt), miles per hour (MPH) or kilometers per hour (KMH).
Average STW	AVG SPD	Average boat speed, in knots (kt), miles per hour (MPH) or kilometers per hour (KMH).
SOG	SOG	Speed over ground, in knots (kt), miles per hour (MPH) or kilometers per hour (KMH).
Maximum SOG	MAX SOG	Maximum speed over ground, in knots (kt), miles per hour (MPH) or kilometers per hour (KMH).
Average SOG	AVG SOG	Average speed over ground, in knots (kt), miles per hour (MPH) or kilometers per hour (KMH).
VMG to windward	VMG	Velocity made good to windward, in knots (kt), miles per hour (MPH) or kilometers per hour (KMH).
Log	LOG	Log distance (total distance run), in nautical miles, (NM) kilometers (KM) or statute miles (SM).
Trip	TRIP	Trip distance (distance run between two points), in nautical miles (NM), kilometers (KM) or statute miles (SM).

Timer category

Display title	Indication	Function
Count up timer	UP	Count-up timer.
Count down timer 1	DOWN 1	Count-down timer 1.
Count down timer	DOWN 2	Count-down timer 2.

Wind category

Display title	Indication	Function
Wind speed	APP (or TRUE)	Wind speed, in knots or meters/second.
Maximum true wind speed	MAX TRUE	Maximum true wind speed.
Maximum true wind speed alarm	 MAX TRUE	Set maximum true wind speed alarm. Audio and visual alarms are released when the wind speed goes higher than the threshold value.
Low true wind speed alarm	 TRUE LO	Set low true wind speed alarm. Audio and visual alarms are released when the wind speed goes lower than the threshold value.
Wind angle	APP (or TRUE)	Apparent (or true) wind angle, in degrees.
High apparent wind angle alarm	 APP HI	Set high apparent wind angle alarm. Audio and visual alarms are released when the wind angle at starboard goes higher than the threshold value.
Low apparent wind angle alarm	 APP LO	Set low apparent wind angle alarm. Audio and visual alarms are released when the wind angle at port goes lower than the threshold value.
Beaufort wind speed	BFT	Beaufort wind speed. Beaufort speeds up to 12 are shown. See the table below for Beaufort no. and wind speed.
Ground wind angle	GWIND	Angle of wind over ground, in degrees. Bearing reference in Magnetic (MAG) or True (TRUE).

Beaufort no. and wind speed

Beaufort no.	Wind speed		Beaufort no.	Wind speed	
	kt	m/s		kt	m/s
0	0	0-0.2	7	28-33	14.4-17.4
1	1-3	0.5-2.0	8	34-40	17.5-21.0
2	4-6	2.1-3.5	9	41-47	21.1-24.6
3	7-10	3.6-5.6	10	48-55	24.7-28.8
4	11-16	5.7-8.6	11	56-63	28.9-32.6
5	17-21	8.7-11.2	12	64	32.7-32.9
6	22-27	11.3-14.3			

1. OPERATION


Heading category

Display title	Indication	Function
Current heading	HDG	Heading, in degrees. Bearing reference in Magnetic (MAG) or True (TRUE).
Average heading	AVG HDG	Average heading, in degrees. Bearing reference in Magnetic (MAG) or True (TRUE).
Heading on next tack	TACK	Heading on next tack, in degrees true (fixed). Bearing reference in Magnetic (MAG) or True (TRUE).
Course over ground	COG	Course over ground, in degrees. Bearing reference in Magnetic (MAG) or True (TRUE).
Course made good	CMG	Course made good, in degrees. Bearing reference in Magnetic (MAG) or True (TRUE).
Distance made good	DMG	Distance made good, in kilometers (km), nautical miles (nm) or statute miles (sm).

Navigation category

Display title	Indication	Function
Bearing to waypoint	BTW	Bearing to waypoint, in degrees. Bearing reference of Magnetic (MAG) or True (TRUE)
Distance to waypoint	DTW	Distance to waypoint, in kilometers (KM), nautical miles (NM) or statute miles (SM).
Cross track error	XTE	Cross-track error, in kilometers (KM), nautical miles (NM) or statute miles (SM).
Waypoint number/name	WPT	Waypoint number and name are shown.
Latitude	LAT	Position in latitude.
Longitude	LON	Position in longitude.
Course over ground	COG	Course over ground, in degrees. Bearing reference in Magnetic (MAG) or True (TRUE).
Speed over ground	SOG	Speed over ground, in knots (KT), miles per hour (MPH) or kilometers per hour (KMH).
Satellites tracked	GPS SAT	GPS satellites tracked.
Roll	ROLL	Ship's roll, in degrees.
Pitch	PITCH	Ship's pitch, in degrees.

Environment category

Display title	Indication	Function
Battery voltage	VOLTS	Battery voltage.
Minimum battery voltage alarm	 VOLTS LO	Set low battery voltage alarm. Audio and visual alarms are released when the battery voltage goes lower than the threshold value.
Time	-	Current time, in 12-hour or 24-hour format.
Date	-	Current date.
Water temperature	WATER	Water temperature, in °C or °F.
Air temperature	AIR	Air temperature, in °C or °F.
Air pressure	PRE	Air pressure, in Hectopascal.
Humidity	HUMID	Relative humidity, in percentage.
Wind chill temperature	CHILL	Wind chill temperature, in °C or °F.
Dew point	DEW	Dew point, in °C or °F.

Autopilot category

Display title	Indication	Function
Rudder angle	RUDDER	Rudder angle, in degrees either P(ort) or S(tarboard).

Engine category

Display title	Indication	Function
Trip fuel used	TOTAL	Total fuel consumption, in liters or gallons.
Fuel rate	RTE (L/H)	Amount of fuel consumed in hour, in liters/hour (L/H) or gallons/hour (G/H).
Engine RPM	RPM	Engine speed per minute.

Note: In case of multiple engines, the data of desired engine number (max. eight, E0-E7) can be selected with the **SELECT/CLEAR** key.

Scrolling speed and scrolling direction

Display scrolling speed and direction can be changed by the length of key push.

Short push: Scroll in forward order.


Medium push: Go back one display. Several beeps sound and then the previous display appears.

Hold down: Rapid scrolling, in forward direction. Several beeps sound and then speed is changed.

1.5 Selecting Apparent or True Wind Angle, Wind Speed

You can show wind angle and wind speed in apparent or true wind. The **apparent wind** is the actual flow of air acting upon a sail, or the wind as it appears to the sailor. **True wind** is the wind seen by a stationary observer in velocity and direction.

With a wind angle or wind speed indication displayed, press the **APP/TRUE** key to change the wind angle or wind speed to apparent or true alternately. A beep sounds after the change is completed. (Wind angle and wind speed displays are mutually changed.) True wind requires boat speed input. If there is no speed input three dashes appear.



1.6 Resetting Counters and Indications

You can reset the following counters and indications:

- Trip
- Course made good
- Distance made good
- Average speed
- Average SOG
- Maximum speed
- Maximum SOG
- Average heading
- Maximum true wind speed

Select the applicable display and press and hold down the **SELECT/CLEAR** key. A short beep sounds, the counter or indication flashes twice and then a long beep sounds to indicate that resetting is completed.

1.7 Alarms

There are nine conditions which trigger audio and visual alarms: Shallow alarm, Deep alarm, Shallow anchor alarm, Deep anchor alarm, Max. true wind speed alarm, Low true wind speed alarm, High apparent wind angle alarm, low apparent wind angle alarm, and low battery voltage alarm.

1. Use the **DISP** and **MODE** keys to select desired alarm page, referring to the illustration below for alarm location.

Display category	Available alarms			
DEPTH	 Shallow alarm	 Deep alarm	 Shallow anchor alarm	 Deep anchor alarm
WIND	 Max. true wind speed alarm	 Low true wind speed alarm	 High apparent wind angle alarm	 Low apparent wind angle alarm
ENVIRON- MENT	 Low voltage alarm			

*S (Starboard) or P (Port)


Alarm description

Alarm	Alarms released when;	Setting range
Shallow alarm	depth is shallower than this threshold.	0.0-303 m
Deep alarm	depth is deeper than this threshold.	0.1-304 m
Shallow anchor alarm	anchor depth is shallower than this threshold.	depth is shallower than this threshold.
Deep anchor alarm	anchor depth is greater than this threshold.	depth is deeper than this threshold.
Max. true wind speed alarm	max. true wind speed is greater than this threshold.	0.1-999 kts
Low true wind speed alarm	true wind speed is lower than this threshold.	0-998 kts
High apparent wind angle alarm	apparent wind angle is higher than this threshold.	S0°-S179° (High) S180°-P1° (Low) (S=Starboard, P=Port)
Low apparent wind angle alarm	apparent wind angle is lower than this threshold.	

Alarm description

Alarm	Alarms released when;	Setting range
Low battery voltage alarm	battery voltage is lower than this threshold.	5.0 - 20.0 volts

2. If the selected alarm page shows "Off," press and hold down the **SELECT/CLEAR** key until an alarm setting appears.
 3. Press the **APP/TRUE** and **SELECT/CLEAR** keys together to enable adjustment. The alarm setting starts flashing.
 4. Press the **APP/TRUE** key to lower the setting; the **SELECT/CLEAR** key to raise it.
- Note:** A low alarm cannot be set higher than its affiliated high (max.) alarm.
5. Press the **APP/TRUE** and **SELECT/CLEAR** keys together to confirm setting and restore normal operation.

When an alarm is violated, the buzzer sounds and the alarm icon () flashes. You can silence the buzzer with the **SELECT/CLEAR** key. The icon continues flashing until the offending alarm is disabled.

While the icon is flashing you can switch between alarm display and current display alternately by pressing the **DISP** and **SELECT/CLEAR** keys together.

1.8 Timers

Three timers are provided:

- Count-up timer (stopwatch)
- Count-down timer (two provided)

Time is displayed in seconds or minutes, depending on counter values.

Once you have set a timer, you can leave that page and select any other display. The counter continues to run in the background.

Count-up timer

The count-up timer functions like a stop watch, counting time upward, to 99 hours, 99 minutes and 59 seconds.

Count-down timers

The two count-down timers count down from a time between 15 minutes and one minute. When these timers have counted down to zero, they then start counting up. The timers beep at preset intervals to alert you to specific points in time.

- Two beeps every minute
- Three beeps at the start of the last 30 seconds
- One beep/second for each of the last 10 seconds
- Two-second beep at zero

How to set the timers


1. Press the **MODE** key to show the desired timer display.



Count-up
timer



Count-down
timer 1



Count-down
timer 2

2. Do one of the following depending on timer type selected:

Count-up timer:

Press the **SELECT/CLEAR** key to start the timer. A long beep sounds and the timer starts counting upward.

Count-down timer:

To start the timer from the time shown, press the **SELECT/CLEAR** key. To set a different start time, press the **APP/TRUE** and **SELECT/CLEAR** keys together to enable adjustment. Use the **APP/TRUE** key to lower the value; **SELECT/CLEAR** key to raise it. Press the **APP/TRUE** and **SELECT/CLEAR** keys together to confirm setting. Press the **SELECT/CLEAR** key to start the timer.

1. OPERATION


To stop or restart the timer, press the **SELECT/CLEAR** key momentarily. A short beep sounds when the timer is stopped or restarted.


To stop and reset the timer to start value, press the **SELECT/CLEAR** key until you hear a long beep. The timer is stopped and reset to start value.

The timer settings are reflected on any timer-equipped instrument in the network which is set up for synchronization.

2. MAINTENANCE, TROUBLESHOOTING

This chapter provides the information necessary for keeping your equipment in good working order.

 **WARNING**

 **Do not open the equipment.**
Only qualified personnel should work inside the equipment.

2.1 Preventive Maintenance

Following the recommended procedures below will help maintain performance.

Check item	Check point	Remedy
Cabling	Check that all cabling is securely fastened and is free of rust and corrosion.	Reconnect if necessary. Replace if damaged.
Cabinet	Dust on cabinet	Remove dust with a soft, lint-free cloth. NOTICE Do not apply paint, anti-corrosive sealant or contact spray to coating or plastic parts of the equipment. Those items contain organic solvents that can damage coating and plastic parts, especially plastic connectors.

2.2 Troubleshooting

If you feel the equipment is not functioning properly, follow the procedures in the table below to try to restore normal operation. If normal operation cannot be restored, do not attempt to check inside the cabinet. There are no user-serviceable parts inside.

Troubleshooting

Problem	Possible cause	Remedy
Display is blank. Panel is not lit.	<ul style="list-style-type: none"> • Power supply • Cabling disconnected or damaged. 	<ul style="list-style-type: none"> • Check power supply. • Check cabling.
Power is on but no or some data.	Sensor is turned off. Cable from sensor is disconnected or damaged.	<ul style="list-style-type: none"> • Turn on sensor. • Check cabling.
Inaccurate data	<ul style="list-style-type: none"> • Electromagnetic field generating equipment is in operation. • Cabling from sensor is damaged. • Sensor is improperly aligned (where applicable). 	<ul style="list-style-type: none"> • Turn off all electromagnetic field generating equipment. Turn them on and off one by one. Check the display. Relocate offending equipment or this instrument as appropriate. • Check cabling. • Check installation. If installation is proper, an offset may be applied to certain data. For details, see section 1.7.

3. INSTALLATION

NOTICE

Do not apply paint, anti-corrosive sealant or contact spray to coating or plastic parts of the equipment.

Those items contain organic solvents that can damage coating and plastic parts, especially plastic connectors.

3.1 Equipment Lists

Standard supply

(FI-504)

Name	Type	Code No.	Qty	Remarks
Display Unit	FI-504	-	1	
Installation Materials	CP26-00600	000-011-744	1 set	See packing list at end of manual for details.

(FI-507)

Name	Type	Code No.	Qty	Remarks
Display Unit	FI-507	-	1	
Installation Materials	CP26-00800	000-015-730	1 set	See packing list at end of manual for details.

Optional supply


Name	Type	Code No.	Qty	Remarks
Cable Assy.	FI-50-DROP-6M	001-105-810-10	1	
	FI-50-CHAIN-0.3M	001-105-820-10	1	
	FI-50-CHAIN-5M	001-105-840-10	1	
	FI-50-CHAIN-1M	000-166-950-11	1	
	FI-50-CHAIN-10M	001-105-850-10	1	
	FI-50-CHAIN-20M	001-105-860-10	1	
Flush Mount Kit	FI-50-FLUSH-KIT	000-010-619	1 set	For FI-504
	FI-507-FLUSH-KIT	000-015-722		For FI-507
Junction Box	FI-5002	000-010-765	1 set	
Smart Sensor	DST-800	000-168-850-10	1	

3.2 Mounting

The display unit can be installed two ways: surface mount (fixed at front panel or fixed from rear panel) and flush mount (optional kit required). This section covers surface mounting. For flush mounting, see the flush mounting instructions, issued separately.

Surface mount 1: Fix instrument from front panel


1. Using the applicable template at the back of this manual, open a mounting hole in the installation site.
2. Detach the front panel together with the keypad assy. Attach sponge (supplied) to rear of display unit.
3. Set the display unit to the mounting hole, and fix it with four self-tapping screws (3×20, supplied).
4. Attach the front panel and keypad assy. to the display unit.




(ex. FI-504)

Surface mount 2: Fix instrument from rear panel

1. Using the applicable template at the back of this manual, open a mounting hole in the installation site.
2. Insert studs (M3×40, 2 pcs. (FI-504) or 4 pcs. (FI-507), supplied) in the holes shown below. (Use only the studs supplied.)




(FI-504)



(FI-507)

Display unit, rear view

3. Set the display unit to the mounting hole, inserting studs through respective holes. Fix the display unit with spring washers, flat washers and wing nuts (M3, supplied).




3.3 Wiring


For the service technician detailed information about CAN bus wiring is on the FURUNO Tech-net. See “Furuno CAN bus Network Design Guide” (TIE-00170-*).

3.3.1 Standalone configuration

For standalone configuration the junction box is not necessary; connect the instrument directly to the power supply.




3.3.2 Multi-instrument configuration




NOTE: The total length of drop cables and backbone cables must be within 80 m.

Junction box (option)


The junction box is required when connecting CAN bus network. This section covers wiring of the junction box. For how to mount the junction box, see its installation instructions, issued separately.



CH3 DROP - CH5 DROP and BACKBONE are socket-and-plug-type terminal blocks. Detach plug to connect wiring to it, by rocking it back and forth with your fingers. Remove approx. 6 mm of the sheath from the end of wires and twist wires. Loosen fixing screw in the plug, insert wire into hole and tighten fixing screw. Set plug to socket.



How to fabricate cable




How to insert wire

Terminal resistor

The illustration below show various system configurations and what units to activate the terminal resistor.


Smart sensor+FI-50x




Multiple FI-50 series instruments, FI-5002, drop cabling




Multiple FI-50 series instruments, FI-5002




Multiple FI-50 series instruments, multiple FI-5002




Multiple FI-50 series instruments, FI-5002, smart sensor



Multiple FI-50 series instruments, FI-5002, heading sensor, smart sensor




Multiple FI-50 series instruments, FI-5002, NMEA 2000, CAN bus sensors



• = Terminal resistor ON

Turn on the terminal resistor in the junction box when the FURUNO CAN bus and/or NMEA 2000 sensor(s) connected to it do not have a terminal resistor.



For how to turn on the terminal resistor in a FI-50 series instrument, see paragraph 3.4.2 “Setup2 menu”.

3.4 Setting Up


Your instrument is pre-programmed with factory default settings, which may or may not be suited to your vessel. Therefore, it is necessary to initialize the instrument for use with your vessel. This should be done immediately after completion of the installation.

Two sets of setup menus are provided: setup1 and setup2. The setup1 menu provides system parameters and the setup2 menu has user settings.

3.4.1 Setup1 menu

The setup1 menu contains system parameters which optimize the instrument for use on your vessel. Follow the procedure below to access and set parameters.

1. Press the **APP/TRUE** and **SELECT/CLEAR** keys momentarily to enable the setup1 menu. The Depth unit selection screen appears, with the depth unit flashing. (See the illustration on the next page.)
2. Use the **DISP** key to select a menu item. Each press of the key changes the menu item in the sequence shown in the illustration on the next page.



3. Use the **APP/TRUE** or **SELECT/CLEAR** key to set value or select option.

VMG key: Decrement value

SELECT/CLEAR key: Increment value or select option.

4. To continue, press the **DISP** key to select another menu item.

5. To save settings and restore normal operation, press the **APP/TRUE** and **SELECT/CLEAR** keys together.

Setup1 menu items

Display	Function	Setting range or options	Default setting
<div> DPTH M CAL </div>	Select depth unit.	M (Meter), FT (Feet)	M
<div> DPTH M CAL 0.0 </div>	Set depth offset.	-99 - +99	0.0
<div> SHWLOCK CAL OFF </div>	Lock/unlock shallow alarm setting.	ON, OFF	OFF
<div> DPT RES CAL 3 </div>	Set depth response. The lower the setting the faster the response to change in depth.	0 - 12	3
<div> SPD KT CAL </div>	Select speed unit.	KT (Knot), MPH (Miles/Hour), KMH (Kilometers/Hour)	KT
<div> SPD CAL 0.01 </div>	Select speed resolution. Select number of places to show after decimal point.	0.01, 0.1	0.01
<div> SPD --- CAL 1.00 </div>	Set speed adjustment. (STW only)	0.30 - 2.50	1.00
<div> LOG NM CAL </div>	Select log unit.	NM (Nautical Mile), SM (Statute Mile), KM (Kilometer)	NM

Setup1 menu items

Display	Function	Setting range or options	Default setting
<div>SPD RES</div> <div>CAL</div> <div>0</div>	Set speed response. The lower the setting the faster the response to change in speed.	0 - 12	0
<div>SOG RES</div> <div>CAL</div> <div>0</div>	Set SOG response. The lower the setting the faster the response to change in speed over ground.	0 - 12	0
<div>VMG RES</div> <div>CAL</div> <div>3</div>	Set VMG response. The lower the setting the faster the response to change in velocity made good.	0 - 12	3
<div>*TIMER</div> <div>CAL</div> <div>On</div>	Enable/disable the timer alarm's audio alarm.	ON, OFF	ON
<div>WIND</div> <div>CAL</div> <div>F</div>	Select source of wind data. Select "r" for second unit.	F: For FI-5001 (Furuno Sensor), r: repeater	F
<div>WIND KT</div> <div>CAL</div>	Select wind unit.	KT (Knot), M/S (Meters/Second)	KT
<div>WINDADJ</div> <div>CAL</div> <div>1.0</div>	Set wind speed adjustment.	0.3 - 2.5	1.0
<div>ANGLE S</div> <div>CAL</div> <div>0</div>	Set wind angle offset.	S 0° - 180° P 1° - 179°	0
<div>WSPDRES</div> <div>CAL</div> <div>3</div>	Set wind speed response. The higher the setting the faster the response to change in wind speed.	0 - 12	3


Setup1 menu items

Display	Function	Setting range or options	Default setting
<div> <div>HDG MAG</div> <div>CAL</div> <div></div> </div>	Select true or magnetic bearing.	MAG (Magnetic), TRU (True)	MAG
<div> <div>HDGLOCK</div> <div>CAL</div> <div>LOC</div> </div>	Select heading type to display when activating locked heading.	LOC (Locked), CUr (Current)	LOC
<div> <div>HDG RES</div> <div>CAL</div> <div>0</div> </div>	Set heading response. The lower the setting the faster the response to change in heading.	0 - 12	0
<div> <div>TIME HR</div> <div>CAL</div> <div>12</div> </div>	Select time format.	12, 24 (hour)	12
<div> <div>---:---:---</div> <div>CAL</div> <div>0</div> </div>	Use local time. Enter time difference between local time and GMT to use local time.	-12 - +12	0
<div> <div>TEMP °C</div> <div>CAL</div> <div></div> </div>	Select water temperature unit.	°C, °F	°C
<div> <div>W TEMP</div> <div>CAL</div> <div>0.0</div> </div>	Set water temperature offset.	-99 - +99	0
<div> <div>FUEL L</div> <div>CAL</div> <div></div> </div>	Select fuel unit.	L (Liter), G (Gallon)	L

3.4.2 Setup2 menu











The setup 2 menu contains user settings which once preset do not require frequent adjustment.

1. Press and hold down the **APP/TRUE** and **SELECT/CLEAR** keys together (about 5-6 seconds) to enable the user settings menu. The software version of CPU1 appears. (See the illustration below.)
2. Press the **DISP** key to choose menu item. Each press of the key changes the menu item in the sequence shown below.












3. Use the **SELECT/CLEAR** key to select setting.
4. To continue, press the **DISP** key to select another item.
5. To save settings and restore normal operation, press the **APP/TRUE** and **SELECT/CLEAR** keys together.

Setup2 menu items

Display	Function	Setting range or options	Default setting
	Software version of CPU1. X=program no. and xxxx=program version no.	-	-
	Software version of CPU2. X=program no. and xxxx=program version no.	-	-
	Turn key beep on/off.	ON, OFF	ON
	Auto brilliance on/off.	ON, OFF	ON
	Enable/disable alternating displays.	OFF 1: Depth/boat spd 2: Boat spd/water temp. 3: Depth/water temp. 4: Depth/boat spd/water temp. 5: Roll/pitch 6: Latitude/Longitude	OFF
	Enable/disable access to the setup1 menu.	ON, OFF	ON
	Turn the terminal resistor on/off.	ON, OFF	OFF
	Turn on/off synchronization of FI-50 series instruments.	ON: Synchronize FI-50 instruments having this setting. OFF: Turn off synchronization. A: Synchronize FI-50 instruments having this setting. b: Synchronize FI-50 instruments having this setting.	ON
	Turn depth displays on/off.	ON, OFF	ON
	Turn speed displays on/off.	ON, OFF	ON

Setup2 menu items

Display	Function	Setting range or options	Default setting
	Turn timer displays on/off.	ON, OFF	ON
	Turn wind displays on/off.	ON, OFF	ON
	Turn heading displays on/off.	ON, OFF	ON
	Turn navigation displays on/off.	ON, OFF	ON
	Turn environmental displays on/off.	ON, OFF	ON
	Turn autopilot displays on/off.	ON, OFF	ON
	Turn engine displays on/off.	ON, OFF	ON
	Demo mode. To enable, press the SELECT/CLEAR key. Depth is shown. To disable and return to this menu, press and hold down the SELECT/CLEAR key.	ON, OFF	OFF
	Restore factory defaults. To restore factory defaults, press and hold down the SELECT/CLEAR key to show ON. Press the key again. A beep sounds upon completion.	ON, OFF	OFF

SPECIFICATIONS OF FI-504 MULTI

1 GENERAL

1.1	Indication system	Segment LCD
1.2	Brilliance	4 steps
1.3	Contrast	3 steps
1.4	Display Contents	Depth, speed, wind speed, wind angle, timer, environmental information (water temperature, air temperature, air pressure, dewpoint, wind chill temperature), rudder angle
1.5	Number of Port	CAN bus, 2 ports
1.6	Mount Method	Surface or flush mount

2 JUNCTION BOX (OPTION)

2.1	Number of Port	CAN bus Drop: 6 ports, CAN bus Backbone: 2 ports
2.2	Circuit Protection	Reverse, short, over current

3 POWER SUPPLY AND POWER CONSUMPTION

3.1	Display Unit	12 VDC, less than 0.1 A
3.2	Junction Box	12 VDC, less than 1 A, max. 2A connectable

4 ENVIRONMENTAL CONDITIONS

4.1	Useable Temperature Range	-15°C - +55°C
4.2	Relative Humidity	Less than 95% (+40°C)
4.3	Waterproofing	
	Display Unit	IP56
	Junction Box	IPX0
4.4	Vibration	- 2 Hz-5 Hz and up to 13.2 Hz with an excursion of $\pm 1 \text{ mm} \pm 10\%$ (7 m/s^2 maximum acceleration at 13.2 Hz); - above 13.2 Hz and up to 100 Hz with a constant maximum acceleration of 7 m/s^2

5 COATING COLOR

5.1	Display Unit	N2.5
5.2	Junction Box	N2.5

SPECIFICATIONS OF FI-507 MULTI XL

1 GENERAL

- | | | |
|-----|-------------------|---|
| 1.1 | Indication system | Segment LCD |
| 1.2 | Brilliance | 4 steps |
| 1.3 | Contrast | 3 steps |
| 1.4 | Display contents | Depth, Ship's speed, Wind speed/angle, Date, Time, Bearing
Environmental information ^{*1} , Navigational information,
Rudder angle, Engine information ^{*2} |
| 1.5 | Number of port | CAN bus: 2 port |
| 1.6 | Mount method | Surface or flush mount |

*1) Battery voltage, date, time, water temperature, air temperature, air pressure, humidity, wind chill temperature and dew point

*2) Fuel consumption, fuel efficiency and engine speed

2 JUNCTION BOX

- | | | |
|-----|--------------------|--------------------------------------|
| 2.1 | Number of port | CAN bus drop: 6, CAN bus backbone: 2 |
| 2.2 | Circuit protection | Reverse, short, over current |

3 POWER SUPPLY

- | | | |
|-----|--------------|---------------|
| 3.1 | Main unit | 12 VDC: 0.1 A |
| 3.2 | Junction box | 12 VDC: 1 A |

4 ENVIRONMENTAL CONDITION

- | | | |
|-----|----------------------|---|
| 4.1 | Ambient temperature | -15°C to +55°C |
| 4.2 | Relative humidity | 95% at 40°C |
| 4.3 | Degree of protection | |
| | Main unit | IP56 |
| | Junction box | IPX0 |
| 4.4 | Vibration | - 2 Hz-5 Hz and up to 13.2 Hz with an excursion of
±1 mm ±10% (7 m/s ² maximum acceleration at 13.2
Hz);
- above 13.2 Hz and up to 100 Hz with a constant
maximum acceleration of 7 m/s ² |









5 COATING COLOR

- | | | |
|-----|--------------|------|
| 5.1 | Main unit | N2.5 |
| 5.2 | Junction box | N2.5 |

PACKING LIST FI-504

26AA-X-9860-4






1/1

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
ユニット			
表示部 MONITOR UNIT		FI-504 000-011-745-00	1
工事材料 INSTALLATION MATERIALS CP26-00600			
+ナベ ヲッピンネジ 1ｼﾂ SELF-TAPPING SCREW		3X20 SUS304 000-163-884-10	4
ケーブル組品 CABLE ASSEMBLY		FI-50-DROP-6M 001-105-810-10	1
ケーブル組品0.3M CABLE ASSEMBLY 0.3M		FI-50-CHAIN-0.3M 001-105-820-10	1
サーフェスマウントｽﾌｵﾝｼﾞ SPONGE		TZ7583002A0 000-167-832-10	1
ﾊﾟﾈﾘﾑ-ﾊﾞｰ PANEL REMOVER		19-028-3124-1 100-340-471-10	1
ﾊﾞﾈ座金 SPRING WASHER		M3 SUS304 000-167-404-10	2
ﾐｶｷ丸平座金 FLAT WASHER		M3 SUS304 000-167-453-10	2

コード番号末尾の[**]は、選用品の代表コードを表します。

CODE NUMBER ENDING WITH "**" INDICATES THE CODE NUMBER OF REPRESENTATIVE MATERIAL.

(略図の寸法は、参考値です。DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
寸切ボルト BOLT		M3X40 SUS304	2
		000-167-804-10	
蝶ナット WING NUT		M3 SUS304	2
		000-167-826-10	
図書 DOCUMENT			
取扱説明書 (英) OPERATOR'S MANUAL		OME-72690-*	1
		000-167-334-1*	
操作要領書 OPERATOR'S GUIDE		OS*-72690-*	1
		000-167-295-1* **	
内部終端/設定 INTERNAL RESISTOR SETTING		C72-00705-*	1
		000-168-501-1*	

型式/コード番号が2段の場合、下段より上段に代わる過渡期品であり、どちらが入っています。なお、品質は変わりません。









TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT. QUALITY IS THE SAME.






C7269-Z01-D

PACKING LIST FI-507

26AA-X-9863-2

1/1

NAME	UNIT	OUTLINE	DESCRIPTION/CODE No.	Q'TY
ユニット				
表示部	MONITOR UNIT		FI-507	1
工事材料				
INSTALLATION MATERIALS CP26-00800				
+self-tapping screw 1шт	SELF-TAPPING SCREW		3X20 SUS304	4
Surface mounting sponge XL	SURFACE MOUNTING SPONGE XL		TZ7583059A0	1
Cable assembly	CABLE ASSEMBLY		FI-50-DROP-6M	1
Cable assembly 0.3M	CABLE ASSEMBLY 0.3M		FI-50-CHAIN-0.3M	1
Panel remover	PANEL REMOVER		19-028-3124-1	1
Spring washer	SPRING WASHER		M3 SUS304	4
Flat washer	FLAT WASHER		M3 SUS304	4

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
寸切ボルト		M3X40 SUS304	4
蝶ナット		000-167-804-10	
WING NUT		M3 SUS304	4
図書 DOCUMENT			
取扱説明書 (英)		OME-72690-*	1
OPERATOR'S MANUAL		000-167-334-1*	
操作要領書 (英)		OSE-72770-*	1
OPERATOR'S GUIDE (EN)		000-170-641-1*	
内部終端/設定		C72-00705-*	1
INTERNAL RESISTOR SETTING		000-168-501-1*	

型式/コード番号が2段の場合、下段より上段に代わる過渡期品であり、どちらが入っています。なお、品質は変わりません。

TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT. QUALITY IS THE SAME.



(略図の寸法は、参考値です。DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

C7277-Z01-C

表1 TABLE 1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
L ≤ 50	±1.5
50 < L ≤ 100	±2.5
100 < L ≤ 500	±3

取付穴寸法図
CUTOUT DIMENSIONS





注 記

- 1) 指定外の寸法公差は表1による。
- 2) #印寸法は最小サービス空間とする。
- 3) 取付方法は次の2種類から選択する。
 - ④: ナベタッピンネジ呼び径3×20を使用のこと。
 - ⑥: M3×40寸切りボルト、M3平座金／バネ座金／蝶ナットを使用のこと。

NOTE





1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
2. #: MINIMUM SERVICE CLEARANCE.
3. SELECT FIXING METHOD FROM FOLLOWINGS;
 - ④: USE TAPPING SCREWS $\phi 3 \times 20$.
 - ⑥: USE M3 STUD BOLT, P.W. / S.W. / WING NUT, SCREW LENGTH: 40.



DRAWN	30/Sep/09 I.YAMASAKI	TITLE	FI-501/502/503/504/505/506
CHECKED	30/Sep/09 I.TAKENO	名称	インスツルメント (サーフェスマウント)
APPROVED	26/Oct/09 R. Esumi	外寸図	
SCALE	MASS 0.3 kg	NAME	INSTRUMENT (SERFACE MOUNT)
DWG.No.	C7266-G02-C	REF.No.	26-001-102G-2

表1 TABLE 1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
$L \leq 50$	± 1.5
$50 < L \leq 100$	± 2.5
$100 < L \leq 500$	± 3



注 記

- 指定外の寸法公差は表1による。
- 取付用ネジはナベタッピンネジ呼び径3×20を使用のこと。


NOTE

- TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
- USE TAPPING SCREWS $\phi 3 \times 20$ FOR FIXING THE UNIT.

DRAWN	30/Sep/09 I.YAMASAKI	TITLE	FI-501/502/503/504/505/506
CHECKED	30/Sep/09 I.TAKENO	名称	インスツルメント (フラッシュマウント)
APPROVED	26/Oct/09 R.Esumi	外寸図	
SCALE	MASS 0.3 $\pm 10\%$ kg	NAME	INSTRUMENT (FLUSH MOUNT)
DWG.No.	C7266-G01-B	REF.No.	26-001-101G-0
OUTLINE DRAWING			

表1 TABLE 1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
L ≤ 50	±1.5
50 < L ≤ 100	±2.5
100 < L ≤ 500	±3




注 記

- 1) # 印寸法は最小サービス空間寸法とする。
- 2) 指定外の寸法公差は表 1 による。
- 3) 取付用ネジはトラススタッピッドネジ呼び径4×20を使用のこと。

NOTE


1. # MINIMUM SERVICE CLEARANCE.
2. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
3. USE TAPPING SCREWS $\phi 4 \times 20$ FOR FIXING THE UNIT.

DRAWN	Jul. 19 '07	I. YAMASAKI	TITLE	FI-5002
CHECKED	Jul. 19 '07	I. TAKENO	名称	ジャンクションボックス
APPROVED	Jul. 24 '07	R. Esumi	外寸図	
SCALE	MASS 0.3 kg		NAME	JUNCTION BOX
DWG. No.	C7268-G01-A	REF. No.	26-001-103G-0	OUTLINE DRAWING



注記 1) 指定外の寸法公差は表 1 による。
 2) #印寸法は最小サービスク間寸法とする。
 3) 取付方法は 2 種類から選択のこと。
 ④の場合、ナベタツピンネジ呼び径 3×20 を使用のこと。
 ⑤の場合、M3×40 寸切ボルト、M3 平座金・バネ座金・蝶ナットを使用のこと。

NOTE 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
 2. # : MINIMUM SERVICE CLEARANCE.
 3. SELECT FOLLOWING METHOD FOR FIXING THE UNIT;
 ④: USE TAPPING SCREWS $\phi 3 \times 20$.
 ⑤: USE M3×40 STUD BOLTS, M3 P.W./S.W./WING NUTS.



DRAWN	2/Dec/08	I. YAMASAKI			TITLE	F1-507
CHECKED	3/Dec/08	I. TAKENO			名称	インスツルメント (サーフェスマウント)
APPROVED	9/Dec/08	R. Esumi			外寸図	
SCALE		MASS 0.46 kg	±10%		NAME	INSTRUMENT (SURFACE MOUNT)
DWG.No.	C7277-G02-A				REF.No.	26-001-201G-0
						OUTLINE DRAWING

171





表1 TABLE 1


寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
L ≤ 50	±1.5
50 < L ≤ 100	±2.5
100 < L ≤ 500	±3

4- 取付用下穴
PILOT HOLES



取付穴寸法図
CUTOUT DIMENSIONS


10 39 #50 R5




取付穴
4-φ3.5
FIXING HOLES

194

183




コネクタ
CONNECTOR



型式銘板
NAMEPLATE

- 注記 1) 指定外の寸法公差は表 1 による。
2) # 印寸法は最小サービスクリアランスとする。
3) 取付用ネジはナベタツピンネジ呼び径3×20を使用のこと。
- NOTE 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
2. #: MINIMUM SERVICE CLEARANCE.
3. USE TAPPING SCREWS φ3×20 FOR FIXING THE UNIT.

DRAWN	3/Dec/08	I. YAMASAKI	TITLE	FI-507
CHECKED	4/Dec/08	I. TAKENO	名称	インストルメント (フラッシュマウント)
APPROVED	9/Dec/08	R. Esumi	外寸図	
SCALE	1/MS	0.45	NAME	INSTRUMENT (FLUSH MOUNT)
DWG.No.	C7277-G01-A	REF.No.	26-001-200G-0	OUTLINE DRAWING



注記
 * 1) オプション。
 * 2) ケーブルを切断する場合は、ターミナルボックス（非防水）を使用のこと。
 * 3) 短絡しないように、端末を処理する。

INSTRUMENT	FI-501/502	FI-503/504	FI-505/506/507
名称	インスツルメント	インスツルメント	インスツルメント
相互結線図	相互結線図	相互結線図	相互結線図
NAME	INSTRUMENT	INSTRUMENT	INSTRUMENT
INTERCONNECTION DIAGRAM	INTERCONNECTION DIAGRAM	INTERCONNECTION DIAGRAM	INTERCONNECTION DIAGRAM

FURUNO Worldwide Warranty for Pleasure Boats (Except North America)

This warranty is valid for products manufactured by Furuno Electric Co. (hereafter FURUNO) and installed on a pleasure boat. Any web based purchases that are imported into other countries by anyone other than a FURUNO certified dealer may not comply with local standards. FURUNO strongly recommends against importing these products from international websites as the imported product may not work correctly and may interfere with other electronic devices. The imported product may also be in breach of the local laws and mandated technical requirements. Products imported into other countries as described previously shall not be eligible for local warranty service.

For products purchased outside of your country please contact the national distributor of Furuno products in the country where purchased.

This warranty is in addition to the customer's statutory legal rights.

1. Terms and Conditions of Warranty

FURUNO guarantees that each new FURUNO product is the result of quality materials and workmanship. The warranty is valid for a period of 2 years (24 months) from the date of the invoice, or the date of commissioning of the product by the installing certified dealer.

2. FURUNO Standard Warranty

The FURUNO standard warranty covers spare parts and labour costs associated with a warranty claim, provided that the product is returned to a FURUNO national distributor by prepaid carrier.

The FURUNO standard warranty includes:

- Repair at a FURUNO national distributor
- All spare parts for the repair
- Cost for economical shipment to customer

3. FURUNO Onboard Warranty

If the product was installed/commissioned and registered by a certified FURUNO dealer, the customer has the right to the onboard warranty.

The FURUNO onboard warranty includes

- Free shipping of the necessary parts
- Labour: Normal working hours only
- Travel time: Up to a maximum of two (2) hours
- Travel distance: Up to a maximum of one hundred and sixty (160) KM by car for the complete journey

4. Warranty Registration

For the Standard Warranty - presentation of product with serial number (8 digits serial number, 1234-5678) is sufficient. Otherwise, the invoice with serial number, name and stamp of the dealer and date of purchase is shown.

For the Onboard Warranty your FURUNO certified dealer will take care of all registrations.

5. Warranty Claims

For the Standard Warranty - simply send the defective product together with the invoice to a FURUNO national distributor. For the Onboard Warranty – contact a FURUNO national distributor or a certified dealer. Give the product's serial number and describe the problem as accurately as possible.

Warranty repairs carried out by companies/persons other than a FURUNO national distributor or a certified dealer is not covered by this warranty.

6. Warranty Limitations

When a claim is made, FURUNO has a right to choose whether to repair the product or replace it.

The FURUNO warranty is only valid if the product was correctly installed and used. Therefore, it is necessary for the customer to comply with the instructions in the handbook. Problems which result from not complying with the instruction manual are not covered by the warranty.

FURUNO is not liable for any damage caused to the vessel by using a FURUNO product.

The following are excluded from this warranty:

- a. Second-hand product
- b. Underwater unit such as transducer and hull unit
- c. Routine maintenance, alignment and calibration services.
- d. Replacement of consumable parts such as fuses, lamps, recording papers, drive belts, cables, protective covers and batteries.
- d. Magnetron and MIC with more than 1000 transmitting hours or older than 12 months, whichever comes first.
- e. Costs associated with the replacement of a transducer (e.g. Crane, docking or diver etc.).
- f. Sea trial, test and evaluation or other demonstrations.
- g. Products repaired or altered by anyone other than the FURUNO national distributor or an authorized dealer.
- h. Products on which the serial number is altered, defaced or removed.
- i. Problems resulting from an accident, negligence, misuse, improper installation, vandalism or water penetration.
- j. Damage resulting from a force majeure or other natural catastrophe or calamity.
- k. Damage from shipping or transit.
- l. Software updates, except when deemed necessary and warrantable by FURUNO.
- m. Overtime, extra labour outside of normal hours such as weekend/holiday, and travel costs above the 160 KM allowance
- n. Operator familiarization and orientation.

FURUNO Electric Company, March 1, 2011

FURUNO Warranty for North America

FURUNO U.S.A., Limited Warranty provides a twenty-four (24) months LABOR and twenty-four (24) months PARTS warranty on products from the date of installation or purchase by the original owner. Products or components that are represented as being waterproof are guaranteed to be waterproof only for, and within the limits, of the warranty period stated above. The warranty start date may not exceed eighteen (18) months from the original date of purchase by dealer from Furuno USA and applies to new equipment installed and operated in accordance with Furuno USA's published instructions.

Magnetrons and Microwave devices will be warranted for a period of 12 months from date of original equipment installation.

Furuno U.S.A., Inc. warrants each new product to be of sound material and workmanship and through its authorized dealer will exchange any parts proven to be defective in material or workmanship under normal use at no charge for a period of 24 months from the date of installation or purchase.

Furuno U.S.A., Inc., through an authorized Furuno dealer will provide labor at no cost to replace defective parts, exclusive of routine maintenance or normal adjustments, for a period of 24 months from installation date provided the work is done by Furuno U.S.A., Inc. or an AUTHORIZED Furuno dealer during normal shop hours and within a radius of 50 miles of the shop location.

A suitable proof of purchase showing date of purchase, or installation certification must be available to Furuno U.S.A., Inc., or its authorized dealer at the time of request for warranty service.

This warranty is valid for installation of products manufactured by Furuno Electric Co. (hereafter FURUNO). Any purchases from brick and mortar or web-based resellers that are imported into other countries by anyone other than a FURUNO certified dealer, agent or subsidiary may not comply with local standards. FURUNO strongly recommends against importing these products from international websites or other resellers, as the imported product may not work correctly and may interfere with other electronic devices. The imported product may also be in breach of the local laws and mandated technical requirements. Products imported into other countries, as described previously, shall not be eligible for local warranty service.


For products purchased outside of your country please contact the national distributor of Furuno products in the country where purchased.


WARRANTY REGISTRATION AND INFORMATION

To register your product for warranty, as well as see the complete warranty guidelines and limitations, please visit www.furunousa.com and click on "Support". In order to expedite repairs, warranty service on Furuno equipment is provided through its authorized dealer network. If this is not possible or practical, please contact Furuno U.S.A., Inc. to arrange warranty service.


FURUNO U.S.A., INC.
Attention: Service Coordinator
4400 N.W. Pacific Rim Boulevard
Camas, WA 98607-9408
Telephone: (360) 834-9300
FAX: (360) 834-9400

Furuno U.S.A., Inc. is proud to supply you with the highest quality in Marine Electronics. We know you had several choices when making your selection of equipment, and from everyone at Furuno we thank you. Furuno takes great pride in customer service.






FI-507サーフェスマウント用型紙
FI-507 Surface Mount Template



タッピンネジ用穴 (4カ所)
For tapping screws (4 pcs.)

寸切りボルト用穴 (4カ所)
For bolts (4 pcs.)



FI-507 フラッシュマウント用型紙
FI-507 Flush Mount Template