

**Installation Manual  
ECDIS****Model FMD-3005/FMD-3200/  
FMD-3300/FMD-3200-BB**

(ELECTRONIC CHART DISPLAY AND INFORMATION SYSTEM)

<b>SAFETY INSTRUCTIONS .....</b>	i
<b>SYSTEM CONFIGURATION .....</b>	ii
<b>EQUIPMENT LISTS.....</b>	v
<b>1. MOUNTING.....</b>	1-1
1.1 Monitor Unit.....	1-1
1.2 ECDIS Control Unit/Track Control Unit.....	1-1
1.3 Processor Unit .....	1-4
1.4 Sensor Adapters (option).....	1-6
1.5 Intelligent HUB (option).....	1-7
1.6 Switching HUB (option).....	1-8
1.7 Radar Connection Box (option). ....	1-8
<b>2. WIRING.....</b>	2-1
2.1 Processor Unit .....	2-3
2.2 Monitor Unit.....	2-13
2.3 Sensor Adapters (option).....	2-15
2.4 Intelligent HUB (option).....	2-32
2.5 How to Extend the Control Unit Cable (option) .....	2-33
2.6 Radar Connection Box (option).....	2-37
2.7 Raytheon Anschütz Autopilot NP-5400.....	2-41
<b>3. ECN-303/304 (OPTION) .....</b>	3-1
3.1 How to Install the Console .....	3-1
3.2 How to Dismount the Rack for the Processor Unit.....	3-2
3.3 How to Connect External Cables .....	3-4
3.4 How to Mount the Rack for the Processor Unit.....	3-6
<b>4. SETTING UP THE EQUIPMENT .....</b>	4-1
<b>APPX. 1 JIS CABLE GUIDE .....</b>	AP-1
<b>APPX. 2 ROD TERMINALS .....</b>	AP-2
<b>APPX. 3 RA/IF BOARD JUMPER VALUES .....</b>	AP-8
<b>APPX. 4 ALERT LIST .....</b>	AP-9
<b>PACKING LIST(S) .....</b>	A-1
<b>OUTLINE DRAWING(S) .....</b>	D-1
<b>INTERCONNECTION DIAGRAM(S) .....</b>	S-1

**FURUNO ELECTRIC CO., LTD.**[www.furuno.com](http://www.furuno.com)

All brand and product names are trademarks, registered trademarks or service marks of their respective holders.

## **FURUNO ELECTRIC CO., LTD.**

9-52 Ashihara-cho,  
Nishinomiya, 662-8580, JAPAN

• FURUNO Authorized Distributor/Dealer

[ All rights reserved. ] Printed in Japan

A : APR. 2012

S : JAN. 11, 2024

Pub. No. IME-44730-S

(YOSH ) FMD-3005/3200/3300



0 0 0 1 9 5 3 0 6 1 6



# SAFETY INSTRUCTIONS

The installer of the equipment must read the safety instructions before attempting to install the equipment.



## WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



## CAUTION

Indicates a potentially hazardous situation which, if not avoided, can result in minor or moderate injury.



Warning, Caution



Prohibitive Action



Mandatory Action



## WARNING



**Do not open the equipment unless totally familiar with electrical circuits and service manual.**

**ELECTRICAL SHOCK HAZARD**

Only qualified personnel should work inside the equipment.

**Turn off the power at the mains switch-board before beginning the installation.**

Fire, electrical shock or serious injury can result if the power is left on or is applied while the equipment is being installed.

**Be sure that the power supply is compatible with the voltage rating of the equipment.**

Connection of an incorrect power supply can cause fire or damage the equipment.

**Use only the specified power cable.**

Fire or damage to the equipment can result if a different cable is used.

**Do not install the monitor unit, processor unit or control unit where they may get wet from rain or water splash, or in a dusty environment.**

Water in the units can result in fire, electrical shock, or damage the equipment.



**Attach protective earth securely to the ship's body.**

The protective earth (grounding) is required for the AC power supply to prevent electrical shock.



## CAUTION


**Observe the following compass safe distances to prevent deviation of a magnetic compass:**

	Standard compass	Steering compass
Processor Unit (EC-3000*/EC-3005)	2.65 m	1.70 m
Monitor Unit (MU-190)	1.65 m	1.05 m
Monitor Unit (MU-231)	2.55 m	1.55 m
Monitor Unit (MU-270W)	0.90 m	0.55 m
ECDIS Control Unit (RCU-024)	0.30 m	0.30 m
Trackball Control Unit (RCU-026)	0.30 m	0.30 m
Intelligent HUB (HUB-3000)	1.20 m	0.75 m
Switching HUB (HUB-100)	1.00 m	0.60 m
Sensor Adapter (MC-3000S)	2.05 m	1.35 m
Sensor Adapter (MC-3010A)	0.75 m	0.50 m
Sensor Adapter (MC-3020D)	1.05 m	0.70 m
Sensor Adapter (MC-3030D)	0.90 m	0.60 m
Radar Connection Box (RCB-002)	1.45 m	0.95 m

\*: If the internal CPU board is ADP-556, the compass safe distances are 2.40 m for standard compass, and 1.55 m for steering compass. The CPU board type can be found in the [System 1] tab in the [About] window.

# SYSTEM CONFIGURATION

## System with one processor unit




<sup>1</sup>: For the monitors available for connection with the ECDIS, see page iv.

<sup>2</sup>: When the network complies with IEC 61162-450 Ed.1, the Switching Hub HUB-100 can also be used. (FMD-3200/3200-BB/3300 only)

**Note:** When using the EC-3000/3005 as an AMS device, connect an emergency power supply, in addition to the main power supply.

## System with two processor units



\*1: For the monitors available for connection with the ECDIS, see page iv.

\*2: When the network complies with IEC 61162-450 Ed.1, the Switching Hub HUB-100 can also be used. (FMD-3200/3200-BB/3300 only)

**Note:** When using the EC-3000/3005 as an AMS device, connect an emergency power supply, in addition to the main power supply.

**Monitors compatible with the ECDIS**

The following monitors are available for connection with the ECDIS:

Maker	Model	Viewing distance
FURUNO	MU-190* <sup>1</sup>	1.02 m
	MU-231* <sup>2</sup>	1.2 m
	MU-201CE	1.0759 m
	MU-231CE	1.0138 m
	MU-270W* <sup>3</sup>	1.02 m
Hatteland Technology	JH19T14 FUD	1.011 m
	JH20T17 FUD	0.878 m
	JH23T12 FUD* <sup>4</sup>	1.011 m
	JH23T14 FUD	1.011 m
	JH26T11 MMD* <sup>4</sup>	0.985 m
	HD19T21 MMD* <sup>4</sup>	1.010 m
	HD19T22 FUD	1.010 m
	HD24T21 MMD* <sup>4</sup>	0.951 m
	HD24T22 FUD	0.951 m
	HD26T21 MMD	0.985 m
	HD26T22 MMD* <sup>4</sup>	0.985 m
	HD26T22 FUD	0.985 m
	HD27T22 FUD	1.070 m
	HD32T22 FUD	1.268 m
	HD55T22 FUD	2.164 m
North Invent	WA270-01.MON.01	1.02 m
	WE270FU* <sup>5</sup>	1.07 m
	WA460-01.MON.01	1.82 m

\*<sup>1</sup>: Standard supply for FMD-3005/3200/3200-BB.

\*<sup>2</sup>: Standard supply for FMD-3300.

\*<sup>3</sup>: Standard supply for FMD-3005/3300.

\*<sup>4</sup>: Do not use for the monitor connected to the DVI1 port. These monitors are available for the port other than DVI1 port.

\*<sup>5</sup>: Only CCS certified (not MED certified). Neither CCS nor MED certification has been obtained for use with FMD-3005.

# EQUIPMENT LISTS

---

## Standard Supply

Name	Type	Code No.	Qty	Remarks
Monitor Unit	MU-190	-	1	For FMD-3005/3200, 19-inch
	MU-231	-		For FMD-3300, 23.1-inch
	MU-270W	-		For FMD-3005/3300, 27-inch
Processor Unit	EC-3000	-	1	
	EC-3005	-		
ECDIS Control Unit	RCU-024	-	1	
Trackball Control Unit	RCU-026	-	1	
Installation Materials	CP24-02100	000-020-557	1	CP24-02101 and cables
	CP24-02201	001-170-810	1	For RCU-024
	CP24-02301	001-170-910	1	For RCU-026
Accessories	FP24-00602	001-258-570	1	For EC-3000(FMD-V3)
	FP24-00607	001-623-580		For EC-3000(FMD-V5)
	FP24-01401	001-628-840		For EC-3005
	FP24-00701	001-170-820	1	For RCU-024
	FP24-00801	001-170-920	1	For RCU-026
Spare Parts	SP24-00601	001-170-660	1	For 100VAC
	SP24-00602	001-170-670	1	For 220VAC

## Console Type

Name	Type	Code No.	Qty	Remarks
Standard Console	ECN-303	-	1	Built-in type, monitor unit: MU-231
	ECN-304	-		Built-in type, monitor unit: MU-190
	ECN-319	-		Stand-alone type, monitor unit: MU-190
	ECN-323	-		Stand-alone type, monitor unit: MU-231
	ECN-327	-		Stand-alone type, monitor unit: MU-270W

## Optional Supply

Name	Type	Code No.	Remarks
Sensor Adapter	MC-3000S	-	Serial IN/OUT type
	MC-3010A	-	Analog IN
	MC-3020D	-	Digital IN
	MC-3030D	-	Digital OUT
Radar Connection Box	RCB-002	-	For connection of external radar
Intelligent HUB	HUB-3000	-	
Switching HUB	HUB-100	-	
AC/DC Power Supply Unit	PR-240	-	
	PR-241	-	
Ferrite Core	OP86-11	001-594-450	For PR-241

EQUIPMENT LISTS

Name	Type	Code No.	Remarks
Monitor Unit	MU-190	-	19-inch display
	MU-231	-	23.1-inch display
	MU-270W	-	27-inch display
	HD26T22-FUD-MA4-FAGA	-	26-inch display
ECDIS Control Unit	RCU-024	-	
Trackball Control Unit	RCU-026	-	
Bracket Assembly	OP26-5	000-016-270	For MU-190, w/knobs
	OP26-15	001-116-730	For MU-231
	OP26-30	001-439-060	For MU-270W
IPX2 Kit	OP24-23	001-171-780	For EC-3000/3005
Flush Mount	OP24-24	001-171-790	For RCU-024
	OP24-27	001-171-820	For RCU-026
Connection Stand (19)	OP24-25	001-171-800	For RCU-024, FMD-3005/3200
	OP26-20	001-139-300	For FMD-3005
Connection Stand (23)	OP24-26	001-171-810	For RCU-024, FMD-3300
Case Gasket	OP24-28	001-169-970	For MC-3000S
	OP24-29	001-169-960	For MC-3010A/3020D/3030D
Hood Assembly	OP26-6	001-080-930	For MU-190
	OP26-16	001-116-740-01	For MU-231
Flush Mount Kit	OP26-12	001-116-280	For MU-190
	OP26-13	001-116-290	For two MU-190s
	OP26-18	000-017-273	For two MU-231s
	OP26-14	001-116-300	For three MU-190s
	OP26-19	000-017-274	For three MU-231s
	OP26-17	001-116-750	For MU-231
Flush Mount Assembly (Rear)	OP26-31	001-439-070	For MU-270W
Mounting Bracket	OP26-21	001-139-310	For MU-190
Monitor Replacement Kit	OP26-22	001-139-320	For MU-190, flush mounting
	OP26-23	001-139-360	For MU-190, desktop mounting
	OP26-26	001-139-390	For MU-190, hood
	OP26-27	001-139-570	For MU-231, desktop mounting
Control Unit Replacement Kit	OP24-31	001-181-700	For RCU-024
Hood Assembly	OP26-24	001-139-370	For MU-190
	OP26-25	001-139-380-01	For MU-231
Hood Assembly (Front)	OP26-32	001-439-090	For MU-270W
Hood Assembly (Rear)	OP26-33	001-439-110	For MU-270W
Connection Stand (27)	OP26-34	001-462-860	For MU-270W
Terminal Opener	OP24-33	001-188-850	
EC-3000 Attachment Kit	OP24-36	001-258-180	For EC-3000/3005

Name	Type	Code No.	Remarks
Program Install Software	OP24-37	001-529-060	For EC-3000(FMD-V3)
	OP24-65	001-624-260	For EC-3000(FMD-V5)
	OP24-66	001-628-930	For EC-3005
Replacement Kit	OP24-50	000-027-446	
Unit Mounting Base	OP24-51	001-461-600	For ECN-319/323/327
FAN-LED Kit	OP24-052	001-462-730	For ECN-319/323/327
Dust Cover	26-007-1201	001-116-260-10	For MU-190
	26-007-2141	001-121-240-10	For MU-231
	26-009-1093	001-439-120	For MU-270W
	03-163-7271	001-121-230-10	For console type
Installation Materials	CP03-28900	000-082-658	LAN cable for sensor adapter, 10 m
	CP03-28910	000-082-659	LAN cable for sensor adapter, 20 m
	CP03-28920	000-082-660	LAN cable for sensor adapter, 30 m
	CP24-02900	001-208-050	LAN cable for HUB-3000, 10 m
	CP24-02910	001-208-060	LAN cable for HUB-3000, 20 m
	CP24-02920	001-208-070	LAN cable for HUB-3000, 30 m
Connector	CP03-28901	008-542-460	
Spare Parts	SP03-15001	001-042-330	For HUB-100
	SP24-00801	001-235-320	For HUB-3000
Hand Grip Assembly	FP03-09840	008-535-570	For MU-190/231/270W
Cable Assy.	DSUB9P-X2-L5M	001-188-260	For monitor unit, 5 m
	DSUB9P-X2-L5M-WP	001-207-890	For monitor unit, 5 m, waterproof type
	DSUB9P-X2-L10M	001-188-270	For monitor unit, 10 m
	DSUB9P-X2-L10M-WP	001-207-900	For monitor unit, 10 m, waterproof type
	DSUB9P-X2-A-L5M	001-252-580	Brightness control cable for monitor unit, 5 m
	DSUB9P-X2-A-L10M	001-252-590	Brightness control cable for monitor unit, 10 m
	MC1.5-W-L600	001-187-470-10	Between sensor adapters, 0.6 m
	MC1.5-W-L1000	001-187-480-10	Between sensor adapters, 1 m
	MC1.5-W-L2000	001-187-490-10	Between sensor adapters, 2 m
	MC1.5-W-L3000	001-187-500-10	Between sensor adapters, 3 m
	TET-16-045A-2(L5M)	000-194-754-10	For RCU-024, 5 m
	TET-16-045A-3(L10M)	000-194-755-10	For RCU-024, 10 m
	TET-16-045A-4(L20M)	000-194-756-10	For RCU-024, 20 m
	TET-16-045A-5(L30M)	000-194-757-10	For RCU-024, 30 m
	6TPSH-XH12X2-L5.0SP2	001-186-310-10	For RCU-026, 5 m
	6TPSH-XH12X2-L10SP2	001-186-320-10	For RCU-026, 10 m
	6TPSH-XH12X2-L20SP2	001-186-330-10	For RCU-026, 20 m
	6TPSH-XH12X2-L30SP2	001-186-340-10	For RCU-026, 30 m

EQUIPMENT LISTS

Name	Type	Code No.	Remarks
Cable Assy. (con't.)	DVI-D/D S-LINK 5M	001-132-960-10	For monitor unit, 5 m
	DVI-D/D S-LINK 10M	001-133-980-10	For MU-190, 10 m
	OP24-32	001-188-300	USB cable (between processor and control units), 5 m
	MJ-A10SPF0020A-050+	001-283-370	Cable between RCB-002 and external radar, 5 m
	MJ-A10SPF0020A-100+	001-283-380	Cable between RCB-002 and external radar, 10 m
	MJ-A10SPF0020A-200+	001-283-390	Cable between RCB-002 and external radar, 20 m
	MJ-A10SPF0020A-300+	001-283-400	Cable between RCB-002 and external radar, 30 m
	AI.14-8AI.34-6L430	001-460-190	For ECN-319/323/327, cable between MC-3010A/3020D/3030D
	IOK-V0024-2	001-460-210	For ECN-319/323/327, cable between HUB-3000 and processor unit
Operator's Manual	OME-44730-*	000-194-857-**	Hard copy English manual, for software version 05.**
	OME-44732-*	000-199-414-**	Hard copy English manual, for software version 03.**
	OMJ-44730-*	000-195-305-**	Hard copy Japanese manual, for software version 05.**
	OMJ-44732-*	000-199-415-**	Hard copy Japanese manual, for software version 03.**
LOP Instruction Manual	E42-01411-*	000-190-356-**	Hard copy English manual
Radar Instruction Manual	E42-01502-*	000-190-843-**	Hard copy English manual, for software version 05.**
	E42-02114-*	000-199-378-**	Hard copy English manual, for software version 03.**
Crimping Tool	CRIMPFOX10S	001-206-920	For ferrule
Conning Kit	CON-KIT-L5M	001-628-910	For FMD-3005, extension cable for conning screen, 5 m

# 1. MOUNTING

---

## NOTICE

**Do not apply paint, anti-corrosive sealant or contact spray to coating or plastic parts of the equipment.**

Those items contain organic solvents that can damage coating and plastic parts, especially plastic connectors.

## 1.1 Monitor Unit

To mount the monitor unit, see the operator's manual supplied with the monitor unit.

Make sure that the ground wire is connected between the earth terminal on the chassis and the ship's earth.

## 1.2 ECDIS Control Unit/Track Control Unit

The control units can be mounted on a desktop, with or without the KB fixing metal (supplied), which mounts the control units at an angle. The control unit also can be mounted in a console panel using the optional kit.

**Note:** The control unit RCU-024 can be used instead of the RCU-018 (for FEA-2xx7) mounted in the connection stand (OP03-184 or OP26-20) using the option OP24-31.

### Mounting considerations

When you select a mounting location, keep in mind the following points:


- Select a location where the control unit can be operated conventionally.
- Locate the unit away from heat sources because of heat that can build up inside the cabinet.
- Locate the equipment away from places subject to water splash and rain.
- Leave sufficient space for maintenance and service, referring to the outline drawings at the back of this manual.

**Note:** The outline drawing number for the ECDIS control unit (RCU-024) is different depending on the serial number, as shown below:

- “199999” or earlier: See “C4473-G02” to “C4473-G04”.
- “200001” or later: See “C4473-G18” to “C4473-G20”.
- Determine the mounting location considering the length of the signal cable between the control unit and the processor unit.
- A magnetic compass will be affected if the control unit is placed too close to the magnetic compass. Observe the compass safe distances on page i to prevent compass malfunction.

## 1. MOUNTING

- Make sure that the ground wire is connected between the earth terminal on the chassis and the ship's earth.
- Fasten the USB cable with the cable tie (supplied) to the cable routing peg.




*Ex. ECDIS control unit, bottom view*

### 1.2.1 Desktop Mounting


#### Fixing with KB fixing metal

1. Fix the KB fixing metal to the bottom of the control unit.
2. Fix the unit with self-tapping screws (5x20, local supply).



#### Fixing without KB fixing metal

1. Drill four mounting holes of 5 mm (RCU-024) or 4 mm (RCU-026) diameter referring to the outline drawing at the back of this manual.
2. Fix the control unit with four screws (RCU-024: M4, RCU-026: M3) from under side of the desktop. (The M4 screws with a sufficient length for the thickness of the desktop should be provided locally.)




## 1.2.2 Flush mounting

Use the optional flush mount kit to mount the control unit in a console panel.


### Flush mount kits for RCU-024/025

Control Unit	Type	Code No.
RCU-024	OP24-24	001-171-790
RCU-026	OP24-27	001-171-820

1. Prepare a cutout in the mounting location as shown on below.



2. Set the control unit to the cutout.
3. Attach the mounting plate to the control unit with four screws from the rear side.
4. Screw the wing screw to each mounting plate and then insert hex. bolt to each wing screw.
5. Fasten each wing screw and then fasten the wing nuts as shown in figure below.




*Side view of control units*

## 1.3 Processor Unit


### 1.3.1 Mounting considerations

When you select a mounting location, keep in mind the following points:

- Locate the processor unit away from heat sources because of heat that can build up inside the cabinet.
- The vibration at the mounting location should be minimum.
- Locate the equipment away from places subject to water splash and rain.
- Make the service clearance of 100 mm in front of the vent hole (left side).
- Leave sufficient space at the sides and rear of the unit to facilitate maintenance.
- Make sure that the ground wire is connected between the earth terminal on the chassis and the ship's earth.
- A magnetic compass will be affected if the processor unit is placed too close to the magnetic compass. Observe the compass safe distances on page i to prevent compass malfunction.
- Do not remove the dummy plate to prevent the wrong operation of the power switch. The items behind the plate are for use by the serviceman.



- Mount the processor unit on the floor, or on a bulkhead with the following direction (horizontal), because of the DVD drive unit.




### 1.3.2 How to mount the processor unit


Use six bolts (M6, local supply) to mount the processor unit.

1. Use 10 binding head screws (M4x8, supplied) to attach the chassis bases 1 and 2 to the processor unit.

**Note:** For bulkhead mounting, attach the chassis base 2 so that the notches on it are facing the deck.



2. Use six bolts (M6, local supply) to fix the processor unit.



## 1.4 Sensor Adapters (option)

### Mounting considerations

When you select a mounting location, keep in mind the following points:

- Locate the adapter away from heat sources because of heat that can build up inside the cabinet.
- The vibration should be minimal.
- Locate the equipment away from places subject to water splash and rain.
- Make sure that the ground wire is connected between the earth terminal on chassis and the ship's earth.
- Leave sufficient space at the sides and rear of the unit to facilitate maintenance.
- A magnetic compass will be affected if the adapter is placed too close to the magnetic compass. Observe the compass safe distances at the front of this manual to prevent interference to a magnetic compass.
- Select the mounting location considering the numbers of the sensor adapters connected.


Maximum eight MC-3000S can be connected to a sensor network (for the redundant connection:16).

Maximum 10 sensor adapters (MC-3010A/3020D/3030D) can be connected to a MC-3000S. However, note that five MC-3010A can be connected.


- Select the mounting location so that the length of cables among the sensor adapters (MC-3000S, 3010A, 3020D and 3030D) is less than 6 m. If the length is more than 6 m, the equipment may not work properly.

### How to mount the sensor adapter

1. Unfasten four binding screws to remove the cover from the sensor adapter.
2. Fasten four self-tapping screws (4x20, supplied) to fix the sensor adapter.
3. Reattach the cover.



MC-3000S



MC-3010A/3020D/3030D

## 1.5 Intelligent HUB (option)

Use the optional Intelligent HUB (HUB-3000) to connect gateway network or sensor network. Do not use the HUB to connect a network other than shipboard LAN gateway network or sensor network. Note that a commercial PC cannot be connected in this network, other than for the maintenance.


### Mounting considerations

When you select a mounting location, keep in mind the following points:

- Locate the adapter away from heat sources because of heat that can build up inside the cabinet.
- The vibration should be minimal.
- Locate the equipment away from places subject to water splash and rain.
- Make sure that the ground wire is connected between the earth terminal on chassis and the ship's earth.
- Leave sufficient space at the sides and rear of the unit to facilitate maintenance.
- A magnetic compass will be affected if the adapter is placed too close to the magnetic compass. Observe the compass safe distances at the front of this manual to prevent interference to a magnetic compass.

### How to mount the HUB-3000


1. Use two binding screws (M3x6, supplied) to attach the cable clamp (supplied) to the bottom of the HUB-3000.



HUB-3000, bottom view

## 1. MOUNTING

2. Fasten four self-tapping screws (4x20, supplied) to fix the unit.



## 1.6 Switching HUB (option)

Use this Switching HUB to connect the sensor network that complies with IEC 61162-450 Ed.1. Do not use the HUB to connect a network other than shipboard LAN sensor network. Note that a commercial PC cannot be connected in this network, other than for the maintenance. The total length of all cables connected to the hub is 6 m.

For the mounting procedures, see the operator's manual for HUB-100 (Pub. No.OMC-35191).

### Mounting considerations

When you select a mounting location, keep in mind the following points:

- Locate the adapter away from heat sources because of heat that can build up inside the cabinet.
- The vibration should be minimal.
- Locate the equipment away from places subject to water splash and rain.
- Make sure that the ground wire is connected between the earth terminal on chassis and the ship's earth.
- Leave sufficient space at the sides and rear of the unit to facilitate maintenance.
- A magnetic compass will be affected if the adapter is placed too close to the magnetic compass. Observe the compass safe distances at the front of this manual to prevent compass malfunctions.

## 1.7 Radar Connection Box (option)


You can display signals from up to two external radars on the chart display by using the RCB-002. The RCB-002 must be connected via the Gateway Network.

### Mounting considerations

Keep the following points in mind when selection a mounting location:

- Locate the unit away from heat sources. Heat can build up inside the cabinet, causing undue wear to electrical components.
- Take into account the length of the cables to connected to the unit when selecting an installation location.
- Fix the unit firmly so that rough seas and vibrations do not cause the unit to move in any manner.
- Locate the unit away from areas which may be subject to splash or rain.
- Leave sufficient space at the sides and rear of the unit to facilitate maintenance.
- A magnetic compass will be affected if the equipment is placed too close to the magnetic compass. Observe the compass safe distances at the front of this manual to prevent interference to a magnetic compass.
- Vibration at the mounting location should be minimum.

1. Referring to the outline drawing at the back of this manual, drill four holes ( $\phi 5 \times 20$ ) in the mounting location.
2. Fix the unit firmly in place using  $\phi 5 \times 20$  self-tapping screws.




## 1. MOUNTING

This page is intentionally left blank.

## 2. WIRING

The illustration on this page shows the general connection between FMD-3005/3200/3300 and external equipment. For detailed information, see the interconnection diagram. Many of the cables mentioned are JIS (Japan Industry Standard) cables. If not available locally, use the equivalent. See the cable guide in the Appendix for how to select equivalent cables. For other monitor unit wiring, see the applicable operator's manual.



**\*:** Use Switching Hub HUB-100 for IEC61162-450 Ed.1 compliant network. (FMD-3200/3200-BB/3300 only)

**Note:** If the MU-201, MU-231CE or a Hatteland Technology monitor is connected, the DSUB9P-X2-A-L5M/L10M cable (available as an optional extra) for brilliance control is required to connect.

### **Notice for the network construction**

Pay attention to the following points when installing the network.

- Use HUB-3000 for IEC 61162-450 Ed.2 compliant network. HUB-100 can also be used to connect IEC 61162-450 Ed.1 compliant network. (FMD-3200/3200-BB/3300 only)
- Do not connect the shipboard LAN network to the HUB-100 or HUB-3000. Also, commercial PCs cannot be connected to the gateway network, other than for maintenance.
- Connect to other ECDIS units and radars (FEA-2xx7, FAR-2xx7 series radars, etc) using the gateway network.
- When constructing a network with two or more FMD-3xxx, a FAR-2xx7 series radar, and HUB-3000, the HUB-3000 querier must be configured. For how to set the HUB-3000 querier, see the instruction manual (E42-01204).
- The FMD-3xxx does not support IGMP snooping or CGMP enabled switch.
- The FMD-3xxx does not have a router or repeater hub function.
- The Switching Hub (HUB-100) does not support IGMP snooping or CGMP enabled switch.
- To use IEC 61162-450 compatible sensors, set [Transmission Group] on the [Common Installation Settings] menu. For how to set [Transmission Group], see the instruction manual (E42-01204).
- Modbus is only available for AMS database communication.
- To ensure the security of the FURUNO network, be sure to connect with non-FURUNO networks via the service gateway (tBOX810-83A-FL).
- At least one AMS device must be installed in the navigation system. This ECDIS can operate as an AMS device as an optional function. When connecting to INS, do not use this ECDIS as an AMS device.


### **Notice on wiring**

- To use the USB port on the control unit, connect the control unit to the processor unit, using the USB cable supplied with the control unit or optional USB cable.
- The length of the USB cable should be within 5 m to prevent equipment trouble.
- The length of LAN cables should be within 50 m.
- Use the CAT5E or CAT6 LAN cables for the network if available locally.
- If LAN cables are not available locally, use the optional LAN cables (FR-FTPC-CY for sensor network, DTI-C5E350 VCV for gateway network).
- If extension or division of the DVI or ERGB cables is necessary, use the dividers shown below.
  - DVI cable divider: DVI-12A (maker: IMAGENICS)
  - RGB divider: CIF-12H, DD-106 or WBD-14F (maker: IMAGENICS)
- Make sure that the ground wires are connected between the ground terminals on each equipment and the ship's earth.
- If a UPS (user supply) is connected to this equipment, be sure that the grounding lamp does not light.

## 2.1 Processor Unit


### 2.1.1 How to connect cables to terminals on the processor unit

Use screws (M3×6, supplied) to attach the wiring plate 1 and wiring plate 2 to the processor unit. Connect the cables to the connectors at the front of the processor unit, referring to the following figure. After the connection, bind cables to the appropriate fixing metal with the cable ties (supplied).



For the cables from the monitor unit (type: DVI-D/D SLINK5M/10M (MU-190 only), DSUB9P-X2-L5/10M) and ground wire, connect them to the processor unit directly (without fixing to a wiring plate). Tighten the fixing screws on these connectors to prevent disconnection from the processor unit.

**Note:** Connect the cables so that they do not interfere with the opening or closing of the DVD tray.



\*: Use HUB-100 for IEC 61162-450 Ed.1 compliant network. (FMD-3200/3200-BB/3300 only)

#### Cables connected at the wiring plate 1

- USB cables from the control units
- Printer cable
- LAN cable (type: DTI-C5E350 VCV) from the HUB-3000
- LAN cable (type: FR-FTPC-CY) from the HUB-100/MC-3000S

#### Cables connected at the wiring plate 2



- Power cable (Type: IEC60320-C13-L5M)
- LAN cable to the LAN3 port

### Fabricating LAN cable


Fabricate the LAN cable (FR-FTPC-CY, DTI-C5E350 VCV), as shown below. (Wrap both edges of the armor with vinyl tape.) Confirm that the shield of the cable touches to the shell of the modular plug.

**Note 1:** Be sure to use the shielded modular plug that is supplied with the LAN cable.


**Note 2:** This equipment can use either straight or crossover cables.



[Cross cable]



[Straight cable]




**IPX2 kit**

The optional IPX2 kit (Type: OP24-23, Code No.: 001-171-780) protects the connectors shown below to waterproofing standard IPX2.


**Contents of IPX2 kit**

Name	Type	Code No.	Qty	Remarks
Binding Screw	#4-40UNCX3/16	000-176-619-10	10	
Connector Gasket 1	24-014-0107	100-367-730-10	2	For D-sub connectors
Connector Gasket 2	24-014-0108	100-367-741-10	3	For DVI connectors
Rainproof Cover	24-014-0109	100-372-202-10	1	
Gasket Clamping Plate	24-014-0114	100-372-210-10	2	For D-sub connectors
	24-014-0115	100-372-220-10	3	For DVI connectors

1. Set the connector gasket to the unused connector not used.
2. Fasten two binding screws to fix the connector gasket.



3. Peel the paper from the double-sided tape on the rainproof cover, then attach the cover to the position shown below by using four screws preattached to the processor unit.




## 2.1.2 How to connect cables inside the processor unit

### Fabrication

Fabricate JIS cables as shown below to connect them to the WAGO connectors on the I/O Board 24P0124 inside the processor unit.




For locations of cables and cores, see the sticker on the reverse side of the top cover. (All dimensions in millimeters)

#### Fabrication of TTYCS series




Cable type (JIS)	Length of "L"
TTYCS-4, TTYCSLA-4, TTYCS-1Q, TTYCSLA-1Q	400
TTYCS-10, TTYCSLA-10	380

#### Fabrication of TTYCSLA series



## Connection

1. Unfasten four screws (M4x8) to remove the top cover from the processor unit.
2. Unfasten three bolts shown below to remove the upper plate of the cable clamp.



*Processor unit, top view*


3. Pass the cables through the clamp holes, then fasten the bolts removed at step 2 to fix the cables.




4. Connect the WAGO connectors appropriately to the I/O Board, referring to the interconnection diagram.

## 2. WIRING

5. Bind the cables to the fixing metal in the processor unit with the cable ties (supplied).



6. For TTYCSLA series cables, pass the drain wire into the shrink tube (local supply), then fasten crimp-on lugs at the end of drain wires to screws shown above.




*Example of wiring (inside the processor unit)*

## 2.1.3 How to set jumper blocks on I/O Board

### How to set the termination resistors

Use the jumper blocks JP1 to JP4 on the I/O Board (24P0124) to set the termination resistors for J3 to J6 ON or OFF. The default setting is ON.

- When setting the starting/ending terminal for the multipoint connection, or multipoint is not connected (CH1 to CH4): termination resistor ON
- When not setting the starting/ending terminal for the multipoint connection (CH1 to CH4): termination resistor OFF



Processor unit, I/O Board (24P0124)

Jumper block JP1	Connector J3
1-2	SHORT
2-3	OPEN
1-2	OPEN
2-3	SHORT
Jumper block JP2	Connector J4
1-2	SHORT
2-3	OPEN
1-2	OPEN
2-3	SHORT
Jumper block JP3	Connector J5
1-2	SHORT
2-3	OPEN
1-2	OPEN
2-3	SHORT
Jumper block JP4	Connector J6
1-2	SHORT
2-3	OPEN
1-2	OPEN
2-3	SHORT

## 2. WIRING

### How to select the serial input/output format

Use the connectors J3 to J6 to set the input/output format for serial CH1 to CH4, from IEC 61162-1 or IEC 61162-2. For connectors J7 to J10, use TTYCS-1Q or TTYCSLA-1Q cable for a connector.

#### Connector J3

Pin #	Signal	In/Out	Description	IEC 61162-2	IEC 61162-1
1	TD1-A	Out	Serial CH1, output IEC 61162-1/2	TTYCS(LA)-4	TTYCS(LA)-4
2	TD1-B	Out	Serial CH1, output IEC 61162-1/2		No connection
3	RD1-A	In	Serial CH1, input IEC 61162-2		
4	RD1-B	In	Serial CH1, input IEC 61162-2		
5	ISOGND1	-	Isolation GND (CH1)		
6	RD1-H	In	Serial CH1, input IEC 61162-1	No connection	TTYCS(LA)-4
7	RD1-C	In	Serial CH1, input IEC 61162-1		

#### Connector J4

Pin #	Signal	In/Out	Description	IEC 61162-2	IEC 61162-1
1	TD2-A	Out	Serial CH2, output IEC 61162-1/2	TTYCS(LA)-4	TTYCS(LA)-4
2	TD2-B	Out	Serial CH2, output IEC 61162-1/2		No connection
3	RD2-A	In	Serial CH2, input IEC 61162-2		
4	RD2-B	In	Serial CH2, input IEC 61162-2		
5	ISOGND2	-	Isolation GND (CH2)		
6	RD2-H	In	Serial CH2, input IEC 61162-1	No connection	TTYCS(LA)-4
7	RD2-C	In	Serial CH2, input IEC 61162-1		

#### Connector J5

Pin #	Signal	In/Out	Description	IEC 61162-2	IEC 61162-1
1	TD3-A	Out	Serial CH3, output IEC 61162-1/2	TTYCS(LA)-4	TTYCS(LA)-4
2	TD3-B	Out	Serial CH3, output IEC 61162-1/2		No connection
3	RD3-A	In	Serial CH3, input IEC 61162-2		
4	RD3-B	In	Serial CH3, input IEC 61162-2		
5	ISOGND3	-	Isolation GND (CH3)		
6	RD3-H	In	Serial CH3, input IEC 61162-1	No connection	TTYCS(LA)-4
7	RD3-C	In	Serial CH3, input IEC 61162-1		

#### Connector J6

Pin #	Signal	In/Out	Description	IEC 61162-2	IEC 61162-1
1	TD4-A	Out	Serial CH4, output IEC 61162-1/2	TTYCS(LA)-4	TTYCS(LA)-4
2	TD4-B	Out	Serial CH4, output IEC 61162-1/2		No connection
3	RD4-A	In	Serial CH4, input IEC 61162-2		
4	RD4-B	In	Serial CH4, input IEC 61162-2		
5	ISOGND4	-	Isolation GND (CH4)		
6	RD4-H	In	Serial CH4, input IEC 61162-1	No connection	TTYCS(LA)-4
7	RD4-C	In	Serial CH4, input IEC 61162-1		

Connector J7

<b>Pin#</b>	<b>Signal</b>	<b>In/Out</b>	<b>Description</b>	<b>Remarks</b>
1	TD5-A	Out	Serial CH5, output IEC 61162-1	Use TTYCS(LA)-1Q, IEC 61162-1 only
2	TD5-B	Out	Serial CH5, output IEC 61162-1	
3	RD5-H	In	Serial CH5, input IEC 61162-1	
4	RD5-C	In	Serial CH5, input IEC 61162-1	
5	GND	-	GND	

Connector J8

<b>Pin#</b>	<b>Signal</b>	<b>In/Out</b>	<b>Description</b>	<b>Remarks</b>
1	TD6-A	Out	Serial CH6, output IEC 61162-1	Use TTYCS(LA)-1Q, IEC 61162-1 only
2	TD6-B	Out	Serial CH6, output IEC 61162-1	
3	RD6-H	In	Serial CH6, input IEC 61162-1	
4	RD6-C	In	Serial CH6, input IEC 61162-1	
5	GND	-	GND	

Connector J9

<b>Pin#</b>	<b>Signal</b>	<b>In/Out</b>	<b>Description</b>	<b>Remarks</b>
1	TD7-A	Out	Serial CH7, output IEC 61162-1	Use TTYCS(LA)-1Q, IEC 61162-1 only
2	TD7-B	Out	Serial CH7, output IEC 61162-1	
3	RD7-H	In	Serial CH7, input IEC 61162-1	
4	RD7-C	In	Serial CH7, input IEC 61162-1	
5	GND	-	GND	

Connector J10

<b>Pin#</b>	<b>Signal</b>	<b>In/Out</b>	<b>Description</b>	<b>Remarks</b>
1	TD8-A	Out	Serial CH8, output IEC 61162-1	Use TTYCS(LA)-1Q, IEC 61162-1 only
2	TD8-B	Out	Serial CH8, output IEC 61162-1	
3	RD8-H	In	Serial CH8, input IEC 61162-1	
4	RD8-C	In	Serial CH8, input IEC 61162-1	
5	GND	-	GND	

## 2. WIRING

### How to set contact input/output


The connector J11 can be used for the connection of contact input or voltage input. Refer to the figures shown below to make the wiring which complies with the input specification.

**Note:** The input must not exceed the range of the input voltage, to prevent malfunction.


-Setting for voltage input: 21.6V to 31.2V

-Setting for contact input: Voltage cannot be input (contact signal only).

- (Setting for contact input)



- (Setting for voltage input)



Connector J11

Pin #	Signal name	In/Out	Description	Contact input	Voltage input		
1	SYS_FAIL-A	Out	System fail output (NC)	TTYCS(LA)-10	TTYCS(LA)-10		
2	SYS_FAIL-B	Out	System fail output (NC)				
3	PWR_FAIL-A	Out	Power fail output (NC)				
4	PWR_FAIL-B	Out	Power fail output (NC)				
5	NC1-A	Out	Alarm output (NC1)				
6	NC1-B	Out	Alarm output (NC1)				
7	NC2-A	Out	Alarm output (NC2)				
8	NC2-B	Out	Alarm output (NC2)				
9	NO1-A	Out	Alarm output (NO1)				
10	NO1-B	Out	Alarm output (NO1)				
11	NO2-A	Out	Alarm output (NO2)				
12	NO2-B	Out	Alarm output (NO2)				
13	DC12V_OUT	Out	ACK input	#13-#14: short	No connection		
14	DIGI_IN1	In	ACK input		TTYCS(LA)-10		
15	DIGI_RTN1	Out	ACK input	TTYCS(LA)-10			
16	GND (DC12V)	In	ACK input		No connection		
17	GND	-	GND		NO connection		

**Note:** NC1/2 and NO1/2 are output with a fixed value.

## 2.1.4 Alert interface types and maximum number of alert interfaces

The EC-3000/3005 has the following alert interface types and quantities:

- IEC 61162-1/2 (4 ports)
- IEC 61162-1 (4 ports)
- IEC 61162-450 (1 port)

## 2.2 Monitor Unit

For the wiring of the monitor unit, see the operator's manual supplied with the monitor unit.

### Mounting consideration

#### <Standard type>

- Connect the ECDIS main monitor to the DVI1 and COM1 ports.
- For the sub ECDIS monitor, connect it to the DVI2 and COM2 port.

#### <Conning type>

- ECDIS main monitor: DVI1 and COM1 ports, conning monitor: DVI3 port and COM2 ports
- When an ECDIS sub monitor is added to the above connection, connect it to the DVI2 port (the brilliance adjustment is not available).


#### <Monitor Color Calibration>

For the following monitor, it is required to calibrate monitor color ([Monitor Color Calibration]) on the [Common Installation Settings] menu. For how to calibrate monitor color, see the instruction manual (E42-01204).

- |               |               |               |
|---------------|---------------|---------------|
| • HD19T21 MMD | • HD24T21 MMD | • HD24T22 FUD |
| • HD26T21 MMD | • HD26T22 MMD | • HD26T22 FUD |
| • HD27T22 FUD | • HD32T22 FUD | • HD55T22 FUD |

#### <Notice for HD24T22 FUD-MA1-FxGx>

For the monitor unit HD24T22 FUD-MA1-FxGx, do not use the monitor cascade function (connect to the VGA Output port in the connection) as shown in the following figure. This installation is not available for the ECDIS.



#### <Notice for HD55T22 FUD-MA1-FxGx>

For the monitor unit HD55T22 FUD-MA1-FxGx, attach the ferrite core (type: Wurth 742 711 31) to the optional cable DSUB9P-X2-A-L5M/10M for brilliance control.

**<VDR connection>**

- Do the settings in the [Common Installation Settings] menu. See the Instruction Manual (E42-01204) for the procedure.
- To connect a IEC61162-450 compliant VDR (VR-7000/S), connect the VDR to the LAN2 port.
- To connect a VDR that does not comply with IEC61162-450 (VR-3000/S), connect the VDR to the DVI3 or DVI2 port.

Connections at the EC-3000/3005

Prepare the following cables and installation materials.

- When connecting a VDR to the DVI3 port:  
Use a DVI-BNCX converter cable (type: DVI-BNCX5-L2000).
- When connecting a VDR to the DVI2 port:  
Use a DVI/RGB converter (maker: IMAGENICS, type: DVI-12A, local supply).

Connections at the VDR (VR-3010)

See the VDR Installation Manual.

**Setting for MU-190/MU-231/MU-270W**

The [INSTALLATION SETTING] menu appears only when the power is turned on for the first time after installation of the monitor unit.



Adjust the settings referring to the following table.


EXT BRILL CTRL	SERIAL BAUDRATE	COLOR CALIBRATION	KEY LOCK	DVI PWR SYNC*
RS-485	4800bps	ON	ON	ON

\*: [DVI PWR SYNC] is the slide switch at the bottom rear of the monitor unit. Confirm that this switch is set to [ON] (default setting). See "Slide switch" below for details.

**Slide switch**

Set the slide switch to "ON" (default setting). This setting automatically powers the monitor unit on or off according to the DVI signal input. The power switch of the monitor unit is inoperative.

**Note:** The OFF position provides control of the monitor unit power with the power switch of the monitor unit.



### How to open the [INSTALLATION SETTING] menu

Turn off the monitor unit. While you hold the **DISP** key, press the **⊕ /BRILL** key to turn on the monitor unit. Keep the **DISP** key pressed until the [INSTALLATION SETTING] menu appears.

**Note:** When the [DVI PWR SYNC] slide switch is ON, turn on the connected external equipment while you press the **DISP** key to turn on the monitor unit.

## 2.3 Sensor Adapters (option)

Maximum eight MC-3000S can be connected to a sensor network (for the redundant connection: 16). The MC-3000S (serial input/output, IEC 61162-2/1, 4ch) can connect max. 10 sensor adapters using the MC1.5-W cables. The maximum number of MC-3010A units is five.

When fabricating the MC1.5-W cables, use the lot terminal (ferrule type, supplied) to maintain performance. This fabrication requires the optional crimping tool (type: CRIMPFOX 10S). For the relations between the connectors and rod terminals, see page AP-2. Also, the stickers attached on the reverse side of the covers show the detailed connections.

Attach the cables to the applicable pins.


Pin No.	Cable color	Signal
1	Red	24V_OUT or 24V_IN
2	Black	24V_GND
3	White	MODBUS-A
4	Blue	MODBUS-B
5	Gray	GND

Use the ferrule-type terminals (supplied) to connect the cables to the terminals in the sensor adapters. This connection requires a crimping tool (CRIMPFOX10S, option).

**Note 1:** Use the MC1.5-W cable between the sensor adapters.

**Note 2:** The total length of the MC1.5-W cables should be less than 6 m to prevent malfunction.

### How to attach ferrule-type lug



Rod terminal (ferrule type):  
The core must protrude 0.5 to 1 mm past the rod terminal.

Rod terminal (ferrule type):  
After attaching the rod terminal, use the optional crimping tool CRIMPFOX 10S to crimp.


## 2. WIRING

### 2.3.1 MC-3000S


Use the LAN cable FR-FTPC-CY cable to connect the MC-3000S and the processor unit. With HUB-100 or HUB-3000, a maximum of eight MC-3000S can be connected.

#### Fabrications


##### LAN cable (FR-FTPC-CY)




##### TTYCS-1Q cable








##### MC1.5-W-L600/1000/2000/3000 cable



##### TTYCSLA-1Q cable




TTYCS-1 cableTTYCSLA-1 cableTTYCS-4 cableTTYCSLA-4 cableDPYC-1.5 cable

## 2. WIRING

### Connections

Unfasten four screws to remove the cover, pass the cables through the clamps and attach the cables to respective connectors. The shield part of the cable (or drain wire) must be fastened by (connected to) the clamp.



**Note:** Fasten the cable shield with the cable clamp.

### How to set NC/NO output (J2)

The POWER FAIL signal on the connector J2 can be set to NC (normal close) output or NO (normal open) output as shown in the table below.

Connector J2

Pin #	Signal name	In/Out	Description	NO	NC
1	24V_IN	-	24 VDC	DPYC-1.5	
2	24V_GND	-	GND (24 VDC)		
3	PWR_FAIL_A	Out	Power fail output	TTYCS(LA)-1	No connection
4	PWR_FAIL_COM	Out	Power fail output		TTYCS(LA)-1
5	PWR_FAIL_B	Out	Power fail output	No connection	

### How to set input/output specification (J4 to J9)

For connectors J4 to J7, the connections are different depending on the input specifications as shown below.

#### Connector J4

Pin #	Signal name	In/Out	Description	IEC 61162-2	IEC 61162-1	Modbus*
1	TD1-A	Out	Serial CH1, output IEC 61162-1/2/modbus	TTYCS(LA)-4	TTYCS(LA)-4	TTYCS(LA)-4
2	TD1-B	Out	Serial CH1, output IEC 61162-1/2/modbus		No connection	No connection
3	RD1-A	In	Serial CH1, input IEC 61162-2/modbus			
4	RD1-B	In	Serial CH1, input IEC 61162-2/modbus			
5	ISOGND1	-	Isolation, GND (CH1)			
6	RD1-H	In	Serial CH1, input IEC 61162-1		TTYCS(LA)-4	
7	RD1-C	In	Serial CH1, input IEC 61162-1			

\*: Set the jumpers J20/J21 to Modbus.

#### Connector J5

Pin #	Signal name	In/Out	Description	IEC 61162-2	IEC 61162-1	Modbus*
1	TD2-A	Out	Serial CH2, output IEC 61162-1/2/modbus	TTYCS(LA)-4	TTYCS(LA)-4	TTYCS(LA)-4
2	TD2-B	Out	Serial CH2, output IEC 61162-1/2/modbus		No connection	No connection
3	RD2-A	In	Serial CH2, input IEC 61162-2/modbus			
4	RD2-B	In	Serial CH2, input IEC 61162-2/modbus			
5	ISOGND2	-	Isolation, GND (CH2)			
6	RD2-H	In	Serial CH2, input IEC 61162-1		TTYCS(LA)-4	
7	RD2-C	In	Serial CH2, input IEC 61162-1			

\*: Set the jumpers J20/J21 to Modbus.

#### Connector J6

Pin #	Signal name	In/Out	Description	IEC 61162-2	IEC 61162-1
1	TD3-A	Out	Serial CH3, output IEC 61162-1/2	TTYCS(LA)-4	TTYCS(LA)-4
2	TD3-B	Out	Serial CH3, output IEC 61162-1/2		No connection
3	RD3-A	In	Serial CH3, input IEC 61162-2		
4	RD3-B	In	Serial CH3, input IEC 61162-2		
5	ISOGND3	-	Isolation, GND (CH3)		

## 2. WIRING

Pin #	Signal name	In/Out	Description	IEC 61162-2	IEC 61162-1
6	RD3-H	In	Serial CH3, input IEC 61162-1	No connection	TTYCS(LA)-4
7	RD3-C	In	Serial CH3, input IEC 61162-1		

Connector J7

Pin #	Signal name	In/Out	Description	IEC 61162-2	IEC 61162-1
1	TD4-A	Out	Serial CH4, output IEC 61162-1/2	TTYCS(LA)-4	TTYCS(LA)-4
2	TD4-B	Out	Serial CH4, output IEC 61162-1/2		No connection
3	RD4-A	In	Serial CH4, input IEC 61162-2		
4	RD4-B	In	Serial CH4, input IEC 61162-2		
5	ISOGND4	-	Isolation, GND (CH4)		
6	RD4-H	In	Serial CH4, input IEC 61162-1	No connection	TTYCS(LA)-4
7	RD4-C	In	Serial CH4, input IEC 61162-1		

Connector J8

Pin#	Signal name	In/Out	Description	Used cable
1	TD5-A	Out	Serial CH5, output IEC 61162-1	TTYCS-1Q or TTYCSLA-1Q
2	TD5-B	Out	Serial CH5, output IEC 61162-1	
3	RD5-H	In	Serial CH5, input IEC 61162-1	
4	RD5-C	In	Serial CH5, input IEC 61162-1	
5	TD6-A	Out	Serial CH6, output IEC 61162-1	
6	TD6-B	Out	Serial CH6, output IEC 61162-1	
7	RD6-H	In	Serial CH6, input IEC 61162-1	
8	RD6-C	In	Serial CH6, input IEC 61162-1	

Connector J9

Pin#	Signal name	In/Out	Description	Used cable
1	TD7-A	Out	Serial CH7, output IEC 61162-1	TTYCS-1Q or TTYCSLA-1Q
2	TD7-B	Out	Serial CH7, output IEC 61162-1	
3	RD7-H	In	Serial CH7, input IEC 61162-1	
4	RD7-C	In	Serial CH7, input IEC 61162-1	
5	TD8-A	Out	Serial CH8, output IEC 61162-1	
6	TD8-B	Out	Serial CH8, output IEC 61162-1	
7	RD8-H	In	Serial CH8, input IEC 61162-1	
8	RD8-C	In	Serial CH8, input IEC 61162-1	


### Case packing OP24-28

The optional kit OP24-28 protects the connectors on the MC-3000S to waterproofing standard IPX2.



Case packing (type: OP24-28, code no.: 001-169-970)

Name	Type	Code No.	Qty	Remarks
Case packing (serial)	24-014-2051	100-367-880-10	2	For MC-3000S

1. Unfasten four binding screws to remove the cover from the adapter.



2. Peel the paper from the case packing, then attach the case packing to the reverse side of the cover and the body unit as shown below.




3. Attach the cover to the MC-3000S body unit.

### 2.3.2 MC-3010A/3020D/3030D


- MC-3010A: Inputs analog signal. To set MC-3010A to the current input, connect short pins to each terminals.
- MC-3020D: Inputs digital signal (8ch contact input). Contact or voltage input is selectable (contact input requires short pins).
- MC-3030D: Outputs digital signal (8ch, normal open/close).

#### Fabrications


MC1.5-W-L600/1000/2000/3000 cable  
(Input)




TTYCSLA-1 (MC-3010A)




MC1.5-W-L600/1000/2000/3000 cable  
(Output)




TTYCS-1 (MC-3010A)




MPYC-12 cable (MC-3030D)




MPYC-12 cable (MC-3020D)



### Connection



MC-3010A



MC-3020D/3030D

**Note:** Fasten the cable shield with the cable clamp.

#### Input method (MC-3010A only)

Select the method of the analog data input, power voltage or power current.

**Note 1:** The input must not exceed the range of the input voltage, to prevent malfunction.


-Setting for voltage input: -10V to +10V or 0 to 10V (depending on the setting)

-Setting for contact input: Voltage 4mA to 20mA.


**Note 2:** When changing the input method, turn off the MC-3010A and on again to put change in effect.

## 2. WIRING

- Power voltage: Input the amount of power voltage change to the operational amplifier.



- Power current: Pass the power current to the shunt resistor,  $1k\Omega$ /parallel (combined resistance:  $500\Omega$ ) to input the amount of voltage change at the both ends of the resistor to the operational amplifier.



Connector J3

Pin #	Signal name	In/Out	Description	Power voltage	Power current
1	AN1_IN	In	Analog 1 input	TTYCS(LA)-1	
2	AN1_GND	-	Analog 1 GND		
3	CURR1_JP1	-	Analog 1 input, power current/voltage setting jumper 1	Pin #3-#4: open	Pin #3-#4: short
4	CURR1_JP2	-	Analog 2 input, power current/voltage setting jumper 1		

Connector J4

Pin #	Signal name	In/Out	Description	Power voltage	Power current
1	AN2_IN	In	Analog 2 input	TTYCS(LA)-1	
2	AN2_GND	-	Analog 2 GND		
3	CURR2_JP1	-	Analog 2 input, power current/voltage setting jumper 1	Pin #3-#4: open	Pin #3-#4: short
4	CURR2_JP2	-	Analog 2 input, power current/voltage setting jumper 1		


Connector J5

Pin #	Signal name	In/Out	Description	Power voltage	Power current
1	AN3_IN	In	Analog 3 input	TTYCS(LA)-1	
2	AN3_GND	-	Analog 3 GND		
3	CURR3_JP1	-	Analog 3 input, power current/voltage setting jumper 1	Pin #3-#4: open	Pin #3-#4: short
4	CURR3_JP2	-	Analog 3 input, power current/voltage setting jumper 1		


How to set ACK input (MC-3020D)

Use the connectors J3 to J6 on the MC-DIN Board (24P0116) to set the ACK input for ACK1 to ACK8 as shown below.

- Input circuit for voltage input



- Input circuit for contact input



**Note 1:** The input must not exceed the range of the input voltage, to prevent malfunction.

-Setting for voltage input: 21.6 V to 31.2 V

-Setting for contact input: Voltage cannot be input (contact signal only).

**Note 2:** For analog input, see page 2-23

2. WIRING

Connector J3

Pin #	Signal name	In/Out	Remarks	ACK1 contact	ACK1 voltage	ACK2 contact	ACK2 voltage
1	DC12V_OUT	Out	ACK1 In	Pin#1-#2: short MPYC-12	No connection	-	
2	DIGI_IN1	In			MPYC-12		
3	DIGI_RTN1	Out			No connection		
4	GND (DC12V)	In					
5	DC12V_OUT	Out	ACK2 In	-		Pin #5-#6: short	No connection
6	DIGI_IN2	In					MPYC-12
7	DIGI_RTN2	Out				MPYC-12	
8	GND (DC12V)	In				NO connection	

Connector J4

Pin #	Signal name	In/Out	Remarks	ACK3 contact	ACK3 voltage	ACK4 contact	ACK4 voltage
1	DC12V_OUT	Out	ACK3 In	Pin #1-#2: short MPYC-12	No connection	-	
2	DIGI_IN3	In			MPYC-12		
3	DIGI_RTN3	Out			No connection		
4	GND (DC12V)	In					
5	DC12V_OUT	Out	ACK4 In	-		Pin #5-#6: short	No connection
6	DIGI_IN4	In					MPYC-12
7	DIGI_RTN4	Out				MPYC-12	
8	GND (DC12V)	In				No connection	

Connector J5

Pin #	Signal name	In/Out	Remarks	ACK5 contact	ACK5 voltage	ACK6 contact	ACK6 voltage
1	DC12V_OUT	Out	ACK5 In	Pin#1-#2: short MPYC-12	No connection	-	
2	DIGI_IN5	In			MPYC-12		
3	DIGI_RTN5	Out			No connection		
4	GND (DC12V)	In					
5	DC12V_OUT	Out	ACK6 In	-		Pin #5-#6: short	No connection
6	DIGI_IN6	In					MPYC-12
7	DIGI_RTN6	Out				MPYC-12	
8	GND (DC12V)	In				No connection	

Connector J6

Pin #	Signal name	In/Out	Remarks	ACK7 contact	ACK7 voltage	ACK8 contact	ACK8 voltage
1	DC12V_OUT	Out	ACK7 In	Pin#1-#2: short MPYC-12	No connection	-	
2	DIGI_IN7	In			MPYC-12		
3	DIGI_RTN7	Out			No connection		
4	GND (DC12V)	In					
5	DC12V_OUT	Out	ACK8 In	-		Pin #5-#6: short	No connection
6	DIGI_IN8	In					MPYC-12
7	DIGI_RTN8	Out				MPYC-12	
8	GND (DC12V)	In				No connection	

**How to set alarm output (MC-3030D)**

Use the connector J3 to J6 on the MC\_OUT Board (24P0117) to select NC (normal close) or NO (normal open) for alarm output 1 to 8.

Connector J3

Pin #	Signal name	In/Out	Remarks	Alarm1 NO Out	Alarm1 NC Out	Alarm2 NO Out	Alarm2 NC Out	
1	A1	Out	Alarm1 Out	MPYC-12	No connection	-		
2	COM1				MPYC-12			
3	B1		No connection					
4	A2		Alarm2 Out	-			MPYC-12	No connection
5	COM2					MPYC-12		
6	B2					No connection		

Connector J4S

Pin #	Signal name	In/Out	Remarks	Alarm3 NO Out	Alarm3 NC Out	Alarm4 NO Out	Alarm4 NC Out	
1	A3	Out	Alarm3 Out	MPYC-12	No connection	-		
2	COM3				MPYC-12			
3	B3			No connection				
4	A4		Alarm4 Out	-			MPYC-12	No connection
5	COM4					MPYC-12		
6	B4			No connection				

Connector J5

Pin #	Signal name	In/Out	Remarks	Alarm5 NO Out	Alarm5 NC Out	Alarm6 NO Out	Alarm6 NC Out	
1	A5	Out	Alarm5 Out	MPYC-12	No connection	-		
2	COM5				MPYC-12			
3	B5			No connection				
4	A6		Alarm5 Out	-			MPYC-12	No connection
5	COM6					MPYC-12		
6	B6			No connection				

Connector J6

Pin #	Signal name	In/Out	Remarks	Alarm7 NO Out	Alarm7 NC Out	Alarm8 NO Out	Alarm8 NC Out	
1	A7	Out	Alarm7 Out	MPYC-12	No connection	-		
2	COM7				MPYC-12			
3	B7			No connection				
4	A8		Alarm8 Out	-			MPYC-12	No connection
5	COM8					MPYC-12		
6	B8			No connection				

## 2. WIRING


### Case packing OP24-29

The optional kit OP24-29 protects the connectors on the MC-3010A/3020D/3030D to waterproofing standard IPX2.



Case packing (type: OP24-29, code no.: 001-169-960)

Name	Type	Code No.	Qty	Remarks
Case packing (analog)	24-014-2052-1	100-367-961-10	2	MC-3010A/3020D/3030D

1. Unfasten four binding screws to remove the cover from the adapter.



2. Peel the paper from the case packing, then attach the case packing to the reverse side of the cover and the body unit as shown below.




3. Attach the cover to the MC-3010A/3020D/3030D chassis.

### 2.3.3 How to set jumper blocks in the sensor adapters

#### MC-3000S

Set the jumper blocks in the MC-CS Board (24P0114) referring to the tables that follow.



MC-CS Board (24P0114)

**Rotary switch:** Use the rotary switch (S2) to set the Modbus address when setting connectors J4/J5 to Modbus. The Modbus address set at J4/J5 in the network is not used. When setting J4/J5 to IEC 61162-1/2, use the default setting ("0").

#### **Jumper block:**

Use the jumper block J19 to set the termination resistor on/off for the MODBUS communication on the connector J1. For the first and last sensor adapter in a series, their termination resistors should be set to ON. Use the MC-CS Board with the default setting because it becomes the "first" adapter in a series.

Jumper block J19		Connector J1
1-2	SHORT	Termination resistor: ON (default setting)
2-3	OPEN	
1-2	OPEN	Termination resistor: OFF
2-3	SHORT	

Set the jumper blocks J14 through J17 to turn the termination resistors on connectors J4 through J7 respectively.

(Termination resistor ON)

- When setting the starting/ending terminal for the multipoint, or the multipoint is not connected (CH1 to 4).
- When setting the starting/ending terminal for Modbus (CH1, CH2)

## 2. WIRING

(Terminal resistor OFF)

- When setting the terminal other than starting/ending for the multipoint (CH1 to 4).
- When setting the terminal other than starting/ending for Modbus (CH1/CH2)

Jumper block J14		Connector J4 (CH1)
1-2	SHORT	Termination resistor: ON (default setting)
2-3	OPEN	
1-2	OPEN	Termination resistor: OFF
2-3	SHORT	Termination resistor: ON (default setting)
Jumper block J15		Termination resistor: OFF
1-2	SHORT	
2-3	OPEN	Termination resistor: ON (default setting)
1-2	OPEN	
2-3	SHORT	
Jumper block J16		Connector J6 (CH3)
1-2	SHORT	Termination resistor: ON (default setting)
2-3	OPEN	
1-2	OPEN	Termination resistor: OFF
2-3	SHORT	
Jumper block J17		Connector J7 (CH4)
1-2	SHORT	Termination resistor: ON (default setting)
2-3	OPEN	
1-2	OPEN	Termination resistor: OFF
2-3	SHORT	

Set the jumper blocks J20 and J21 to choose the communication type (IEC-61162-1/2 or MODBUS) of the connector J4 (CH1).

The setting of the jumper block JP20 and JP21 must be identical.


Jumper block J20/J21		Communication type of J4 (between RD1 and TD1)
1-2	OPEN	IEC-61162-1/2 (default setting)
2-3	SHORT	
1-2	SHORT	MODBUS (The setting of J14 is different depending on the unit position (starting/ending terminal).)
2-3	OPEN	

The jumper blocks J22 and J23 are used to set the communication type of the connector J5 (CH2).


Jumper block J22/J23		Communication type of J5 (between RD2 and TD2)	
1-2	OPEN	IEC-61162-1/2 (default setting)	
2-3	SHORT		
1-2	SHORT	MODBUS (The setting of J15 is different depending on the unit position (starting/ending terminal).)	
2-3	OPEN		

**MC-3010A/3020D/3030D**

This paragraph shows how to set the MC-ANLG Board (24P0115, for MC-3010A), MC-DIN Board (24P0116, for MC-3020D) and MC-DOUT Board (24P0117, for MC-3030D).



MC-ANLG Board (24P0115)



MC-DIN Board (24P0116)

MC-DOUT Board (24P0117)

**Rotary switch:** Use the rotary switch (U18) to set the MODBUS address with a digit of number from "0". When multiple sensor adapters are connected to the MC-3000S, the same number cannot be used among them. (It is allowed to use the same number between the MC-3000S and a sensor adapter.)


**Jumper block**

Use the jumper block J25 to set the termination resistor on/off for the MODBUS communication on the connector J1. For the first and last sensor adapter in a series, their termination resistors should be set to ON. If not, communication between sensor adapters is not possible.


Jumper block J25		Connector J1
1-2	OPEN	Termination resistor: OFF (default setting)
2-3	SHORT	
1-2	SHORT	Termination resistor: ON
2-3	OPEN	

## 2.4 Intelligent HUB (option)

Fix the LAN cable connected to the cable clamp using the cable ties (supplied).



Attach the LAN cap (supplied) to the unused connector holes to provide waterproofing standard IPX2.



## 2.5 How to Extend the Control Unit Cable (option)

To extend the length of the cable between the control unit and the processor unit, use the appropriate cable assembly for the control unit, as listed below.

- RCU-024: TET-16-045A (5/10/20/30 m)
- RCU-026: 6TPSH-XH12X2-LxxSP2 (5/10/20/30 m)


**Note:** When the control unit cable is 10 m or longer, the USB cable (TS-20-071-1, 5 m) that is supplied with the control unit cannot be used. Even if the USB cable is not used, you can operate the control unit properly, but the USB port on the control unit is deactivated.

### 2.5.1 ECDIS control unit (RCU-024)


#### Wiring for the control unit

1. Unfasten 12 binding screws (M3x8) from the bottom of the control unit to remove the cover.

**Note:** Do not add stress to the cables connected to the control unit board when removing the cover. When the serial number of the control unit is “200001” or later, disconnect the cable from the J3 (see the figure on step 3) before removing the cover.




2. Unfasten two screws to remove the cable clamp.
3. Release the control unit cable from the wiring clamp, then disconnect the cable from the J1.



## 2. WIRING


4. Pull out the control unit cable from the cover.
  5. Pass the optional cable assy (TET-16-045A) through the grommet and cable entrance on the control unit.
  6. Fasten the shield of the cable with the cable clamp (removed at step 2).
- Note:** When the serial number is “200001” or later, fasten the shield as shown in the figure to the right.




7. Connect the cable to the J1, then secure the cable with the wiring clamp.
8. Reattach the control unit cover.

### Wiring for the processor unit

1. Unfasten four screws (M4x8) to remove the processor unit cover.
2. Unfasten three bolts to remove the cable clamp (upper) as shown below.



- Unfasten these three bolts to remove the upper plate.
3. Disconnect the control unit cable from the processor unit, then connect the cable assy (TET-16-045A).
  4. Set the shield part of cables under the cable clamp then tighten the cable clamp.




5. Attach the processor unit cover.

## 2.5.2 Trackball control unit (RCU-026)


### Wiring for the trackball control unit

- Unfasten four binding screws (M3x8) from the bottom of the control unit, and a pan head screw (M3x8) and flat washer from the back of the control unit to remove the cover.


**Note:** Be careful not to add stress to the cables connected to the control unit board when removing the cover.



- Remove the cable clamp from the control unit, then disconnect the control unit cable from the J1 connector.




- Pull out the control unit cable from the cover.
- Pass the optional cable assy (6TPSH-XH12X2-LxxSP2) through the cable hole on the cover.



## 2. WIRING

- Fasten the shield part of the cable assy with the cable clamp (removed at step 2), then connect the connector at the end of the cable assy to the J1 on the control unit board.


**Note:** When clamping, the shield part of the cable must not touch the circuit board.




- Reattach the control unit cover.

### Wiring for the processor unit

- Unfasten four screws (M4x8) to remove the processor unit cover.
- Unfasten three bolts to remove the cable clamp (upper) as shown below.




- Unfasten these three bolts to remove the upper plate.
- Disconnect the control unit cable from the processor unit, then connect the cable assy (6TPSH-XH12X2-LxxSP2).
  - Set the shield part of cables under the cable clamp then tighten the cable clamp.



- Attach the processor unit cover.

## 2.6 Radar Connection Box (option)


The Radar Connection Box (RCB-002) can connect a maximum of two radar systems to the processor unit. Referring to the figure below, connect the respective equipment to the RCB-002.




### Connecting LAN cables

When connecting LAN cables (MOD-WPAS0001-030+) to the RCB-002, use the following procedure.

1. Unfasten and remove the sealing nut from the NETWORK port on the RCB-002, then remove the seal assembly. See the right figure for reference.




2. Dismantle the seal assembly as shown below.




## 2. WIRING

3. Referring to the figure below, pass the LAN cable through the seal nut, then the claw and finally the seal.



4. Connect the LAN cable to the connector.
5. Join the claw and seal to form the seal assembly, then firmly join the seal assembly to the LAN connector.
6. Fasten the seal nut and secure the cable. Continue to fasten the nut until the space between the two nuts is approximately 3 mm. See the figure below for reference.




## 2.6.1 Jumper settings for RCB-002

The RCB-002 is compatible with the following radars.

<b>Maker</b>	<b>Model</b>	<b>Maker</b>	<b>Model</b>
FURUNO*	• FAR-14×7 series	Japan Radio Company (JRC)	JMA-9100 series
	• FAR-2××7 series	Tokyo Keiki Inc.	BR-3440 series
	• FAR-2××5 series • Model 1835	*: FURUNO radars are only compatible with the CH2 (RADAR SIGNAL IN NO.2 port).	

Change the jumper settings on the RA/IF board (24P0140) according to the radar to be connected, referring the tables on the next page. For details of the values for each jumper block on the RA/IF board (24P0140), see "RA/IF BOARD JUMPER VALUES" on page AP-8.

Jumper locations on the RA/IF board (24P0140)



**CH1 settings (RADAR SIGNAL IN NO.1)**

Using the table below for reference, change the jumper settings to suit the appropriate radar connection. Use the figure on the previous page for jumper locations.

Jumper	Radar to be connected	
	JMA-9100 series	BR-3440 series
J1	#2-3: short	
J2	#3-6: short	
J3	#2-6: short	#1-5: short
J4	#1-2: short	
J5	#2-3: short	
J6	#3-6: short	
J10	#3-7: short	#2-6: short
J13	#1-2: short	#2-3: short

**CH2 settings (RADAR SIGNAL IN NO.2)**


Using the table below for reference, change the jumper settings to suit the appropriate radar connection. Use the figure on the previous page for jumper locations.

Jumper	Radar to be connected		
	FURUNO radars	JMA-9100 series	BR-3440 series
J7	#2-3: short	#1-2: short	
J8	#1-2: short	#2-3: short	
J9	#1-4: short	#3-6: short	
J11	#2-3: short	#1-2: short	
J12	#1-2: short	#1-2: short	
J14	#2-3: short	#1-2: short	
J15	#2-3: short	#1-2: short	
J16	#2-6: short	#2-6: short	#1-5: short
J17	#2-3: short	#1-2: short	
J18	#1-2: short	#2-3: short	
J19	#1-4: short	#3-6: short	
J20	#2-3: short	#1-2: short	
J21	#2-3: short	#1-2: short	
J22	#3-7: short	#3-7: short	#2-6: short
J23	#2-3: short	#1-2: short	
J24	#1-2: short	#1-2: short	#2-3: short

## 2.7 Raytheon Anschütz Autopilot NP-5400

### 2.7.1 General interconnection diagram

The NP-5400 connects to the FMD as shown in the figure below. For details, see the Raytheon Anschütz installation manual.



#### Notes on the connection

- **Speed data**

Speed data is output from the MC-3000S to the NP-5400. Make sure the MC-3000S is connected and set up to output speed data.

- **Position and time data**

Position and time data are output from the MC-3000S to the NP-5400. Make sure the MC-3000S is connected and set up to output position and time data.

- **BNWAS connection**

When AMS is also installed, the Backup Navigator Alarm is output to the BNWAS via the AMS. Connect both AMS and BNWAS. Note that it is not necessary to connect either the ECDIS or the NP-5400 to the BNWAS.

- **Position and speed data input to the FMD**

Do not input position and speed data directly to the FMD. Input the data to the FMD via the MC-3000S. This allows that data to be input to the NP-5400 when the ECDIS EC-3000/3005 is powered off. Note that heading data can be input directly to the ECDIS EC-3000/3005.

## 2.7.2 When the Raytheon Anschütz Steering Gear System will not be used

When the Raytheon Anschütz Steering Gear System will not be used, take the following measures to detect and announce autopilot interface failure.

- The preferred method is to use the 4-20mA output of the track control system when the steering gear control system provides the failure detection and response as described below. This method requires only the rudder order information and does not require any additional status transfer between the autopilot and the steering gear control system.
- The second best method is to use  $\pm 10V$  when the steering gear control system provides the failure detection and response as described below. Compared to the 4-20mA interfaced an additional failure input is required in the steering gear control system.
- The use of an additional analog memory device requires a failure input in order to activate the memory function and a switch over of the rudder order from the track control system (in their case the Autopilot Interface AS) to the analog memory device. This method should only be used if the steering gear control system does not provide the functions as described above.


### **Failure of the Autopilot Interface AS and interface system type**

What occurs when the Autopilot Interface AS fails depends on the type of interface system used.

- 4-20mA interface
  - System failure alert generated.
  - Rudder order from the Autopilot Interface AS to the steering gear control system goes to 0mA
  - The steering gear control system detects a failure as 0mA is an invalid value.
  - Steering gear control system maintains the rudder angle.
- $\pm 10V$  interface
  - System failure alert generated.
  - Rudder order from the Autopilot Interface AS to the steering gear control system goes to 0V.
  - Input of the system failure alert to the steering gear control system.
  - Steering gear control system maintains the rudder angle.


### 3. ECN-303/304 (OPTION)

This section provides the information necessary for installing the display unit console ECN-303/304.



#### 3.1 How to Install the Console

1. Install a channel base (height: 100 mm), consulting with the shipyard.
2. Pass a lifting belt through the four eye bolts at the top of the console. Hoist the console with a crane and place it on top of the channel base.
3. Remove the front cover of the console by unfastening two screws.



4. Fix the console to the channel base with six hexagon head bolts (M12, local supply).
5. Remove the four eye bolts. Cover the four holes for the eye bolts with the caps supplied.


## 3.2 How to Dismount the Rack for the Processor Unit

If it is difficult to access the inside bottom of the console (for wiring), follow the procedure in this section to remove the rack for the processor unit. Otherwise, go to section 3.3 How to Connect the External Cables.

**Note 1:** Leave sufficient space at the sides and rear of the unit to facilitate maintenance.


**Note 2:** Confirm that the power switch of the ECDIS is turned off before starting the installation.

1. Unfasten the cable clamp at the top-left hand side in the console to release the power cable.




2. Unfasten two hex. bolts (M6) to pull the rack for the processor unit toward you until you hear a click.

The rack comes to a stop against the stoppers on the right and left rails.




3. Release all cables other than the power cable from their cable clamps.  
There are six cable clamps on the rack as shown below.



4. Press the stoppers with your fingers to unlock them to release the rack, then pull out the rack slowly.


**Note 1:** When dismounting the processor unit from the console, be careful not to apply tension on the cables.

**Note 2:** The processor unit weighs 20 kg. Hold the rack securely so that it will not drop to the deck.




### 3.3 How to Connect External Cables


Pass the cables from external equipment through the bottom of the console. Connect the cables to the terminal board as shown in the interconnection diagrams in this manual and the label attached to the bottom of the console. Lay shields of cables under clamps then tighten clamps.







**Note 1:** The illustration below shows where to locate cables on the cable clamp. The location for the TTYCS-4/TYYCSLA-4 cables can alternately accommodate TTYCS-1Q/TYYCSLA-1Q cables. In this case, unfasten two hex. bolts to remove the clamp plate and fasten it behind the clamp base.



**Note 2:** For TTYCSLA cables, attach their drain wires to the crimp-on lugs pre-fas-tened near the terminal board.



Fabrication of TTYCS cableFabrication of TTYCSLA cable

- Connectors J3 to J6 on the I/O Board in the processor unit can be set to IEC 61162-1 or IEC 61162-2. This console is shipped with the setting for IEC 61162-2.
- The connector J11 on the I/O Board in the processor unit can be set to the contact input or digital input. This console is shipped with the setting for the contact input.

## 3.4 How to Mount the Rack for the Processor Unit

After completing the wiring, remount the rack if it was removed at section 3.2.


**Note:** Leave sufficient space at the sides and rear of the unit to facilitate maintenance.

1. Confirm that the power switch on the EC-3000/3005 is turned off before doing this procedure.
2. Set the rack for the processor unit to the rails until the rack contacts the stoppers on the rails.


**Note 1:** When remounting the processor unit from the console, be careful not to apply tension to cables.

**Note 2:** The processor unit weighs 20 kg. Hold the rack securely so that it will not drop to the deck.


**Note 3:** Do not tilt the processor unit to insert into the console unit.




If you could not put the rack on the rails immediately, you can rest the rack on the spacers shown below.



3. Fasten the cables from the processor unit with clamps at the left and right hand sides of the rack at the position of the red-colored marks on the cables.




4. Press the stoppers with your fingers to unlock them to release the rack, then push the rack into the console.
5. Fasten two hex. bolts (M6, removed at step 2 in section 3.2.) to fix the rack to the console.
6. Fasten the cables from the processor unit with four clamps at the front of the rack.



Location of four clamps

7. Use the clamp (see step 1 in section 3.2) to refasten the power cable.

**Note:** Confirm that the dummy plate covers the power switch.



8. Fix the front cover to the console with two screws.

3. ECN-303/304 (OPTION)

This page is intentionally left blank.

## **4. SETTING UP THE EQUIPMENT**

---

Set up the ECDIS from the [Common Installation Setting] menu after the installation.  
For details of the [Common Installation Setting] menu, see the instruction manual  
(E42-01204).

#### 4. SETTING UP THE EQUIPMENT

This page is intentionally left blank.

# APPX. 1 JIS CABLE GUIDE

Cables listed in the manual are usually shown as Japanese Industrial Standard (JIS). Use the following guide to locate an equivalent cable locally.

JIS cable names may have up to 6 alphabetical characters, followed by a dash and a numerical value (example: DPYC-2.5).

For core types D and T, the numerical designation indicates the *cross-sectional Area (mm<sup>2</sup>)* of the core wire(s) in the cable.

For core types M and TT, the numerical designation indicates the *number of core wires* in the cable.

## 1. Core Type

D: Double core power line

T: Triple core power line

M: Multi core



TT: Twisted pair communications  
(1Q=quad cable)

## 2. Insulation Type

P: Ethylene Propylene Rubber

## 3. Sheath Type

Y: PVC (Vinyl)



## 4. Armor Type

C: Steel

## 5. Sheath Type

Y: Anticorrosive vinyl sheath

## 6. Shielding Type

SLA: All cores in one shield, plastic tape w/aluminum tape

-SLA: Individually shielded cores, plastic tape w/aluminum tape

EX: **TTYCYSLA - 4**

**MPYC - 4**

The following reference table lists gives the measurements of JIS cables commonly used with Furuno products:

Type	Core Area	Core Diameter	Cable Diameter	Type	Core Area	Core Diameter	Cable Diameter
DPYC-1.5	1.5mm <sup>2</sup>	1.56mm	11.7mm	TTYCSLA-1	0.75mm <sup>2</sup>	1.11mm	9.4mm
DPYC-2.5	2.5mm <sup>2</sup>	2.01mm	12.8mm	TTYCSLA-1T	0.75mm <sup>2</sup>	1.11mm	10.1mm
DPYC-4	4.0mm <sup>2</sup>	2.55mm	13.9mm	TTYCSLA-1Q	0.75mm <sup>2</sup>	1.11mm	10.8mm
DPYC-6	6.0mm <sup>2</sup>	3.12mm	15.2mm	TTYCSLA-4	0.75mm <sup>2</sup>	1.11mm	15.7mm
DPYC-10	10.0mm <sup>2</sup>	4.05mm	17.1mm	TTYCY-1	0.75mm <sup>2</sup>	1.11mm	11.0mm
DPYCY-1.5	1.5mm <sup>2</sup>	1.56mm	13.7mm	TTYCY-1T	0.75mm <sup>2</sup>	1.11mm	11.7mm
DPYCY-2.5	2.5mm <sup>2</sup>	2.01mm	14.8mm	TTYCY-1Q	0.75mm <sup>2</sup>	1.11mm	12.6mm
DPYCY-4	4.0mm <sup>2</sup>	2.55mm	15.9mm	TTYCY-4	0.75mm <sup>2</sup>	1.11mm	17.7mm
MPYC-2	1.0mm <sup>2</sup>	1.29mm	10.0mm	TTYCY-4SLA	0.75mm <sup>2</sup>	1.11mm	19.5mm
MPYC-4	1.0mm <sup>2</sup>	1.29mm	11.2mm	TTYCYSLA-1	0.75mm <sup>2</sup>	1.11mm	11.2mm
MPYC-7	1.0mm <sup>2</sup>	1.29mm	13.2mm	TTYCYSLA-4	0.75mm <sup>2</sup>	1.11mm	17.9mm
MPYC-12	1.0mm <sup>2</sup>	1.29mm	16.8mm	TTPYCSLA-1	0.75mm <sup>2</sup>	1.11mm	9.2mm
TPYC-1.5	1.5mm <sup>2</sup>	1.56mm	12.5mm	TTPYCSLA-1T	0.75mm <sup>2</sup>	1.11mm	9.8mm
TPYC-2.5	2.5mm <sup>2</sup>	2.01mm	13.5mm	TTPYCSLA-1Q	0.75mm <sup>2</sup>	1.11mm	10.5mm
TPYC-4	4.0mm <sup>2</sup>	2.55mm	14.7mm	TTPYCSLA-4	0.75mm <sup>2</sup>	1.11mm	15.3mm
TPYCY-1.5	1.5mm <sup>2</sup>	1.56mm	14.5mm				
TPYCY-2.5	2.5mm <sup>2</sup>	2.01mm	15.5mm				
TPYCY-4	4.0mm <sup>2</sup>	2.55mm	16.9mm				

# APPX. 2 ROD TERMINALS

---

MC-3000S, MC-CS Board (24P0114)

Connector #	Pin #	Signal name	Rod terminal to use	Connected cable	
J1	1	24V_VOUT	AI 0.34-6 TQ (blue)	MC1.5-W-Lxxx	
	2	24V_GND			
	3	MODBUS-A	AI 0.14-8 GY (gray)		
	4	MODBUS-B			
	5	GND			
Connector #	Pin #	Signal name	Rod terminal to use	Connected cable	
J2	1	24V_IN	AI 1.5-6 BK (black)	DPYC-1.5	
	2	24V_GND			
	3	PWR_FAIL-A	AI 0.75-6 GY (Gray)	TTYCS-4 TTYCSLA-4	
	4	PWR_FAIL-COM			
	5	PWR_FAIL-B			
	6	NC	-	-	
Connector #	Pin #	Signal name	Rod terminal to use	Connected cable	
J4	1	TD1-A	AI 0.75-6 GY (Gray)	TTYCS-4 TTYCSLA-4	
	2	TD1-B			
	3	RD1-A			
	4	RD1-B			
	5	ISOGND1			
	6	RD1-H			
	7	RD1-C			
Connector #	Pin #	Signal name	Rod terminal to use	Connected cable	
J5	1	TD2-A	AI 0.75-6 GY (gray)	TTYCS-4 TTYCSLA-4	
	2	TD2-B			
	3	RD2-A			
	4	RD2-B			
	5	ISOGND2			
	6	RD2-H			
	7	RD2-C			
Connector #	Pin #	Signal name	Rod terminal to use	Connected cable	
J6	1	TD3-A	AI 0.75-6 GY (gray)	TTYCS-4 TTYCSLA-4	
	2	TD3-B			
	3	RD3-A			
	4	RD3-B			
	5	ISOGND3			
	6	RD3-H			
	7	RD3-C			

<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>
J7	1	TD4-A	AI 0.75-6 GY (gray)	TTYCS-4 TTYCSLA-4
	2	TD4-B		
	3	RD4-A		
	4	RD4-B		
	5	ISOGND4		
	6	RD4-H		
	7	RD4-C		
<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>
J8	1	TD5-A	AI 0.75-6 GY (gray)	TTYCS-1Q TTYCSLA-1Q
	2	TD5-B		
	3	RD5-H		
	4	RD5-C		
	5	TD6-A	AI 0.75-6 GY (gray)	TTYCS-1Q TTYCSLA-1Q
	6	TD6-B		
	7	RD6-H		
	8	RD6-C		
<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>
J9	1	TD7-A	AI 0.75-6 GY (gray)	TTYCS-1Q TTYCSLA-1Q
	2	TD7-B		
	3	RD7-H		
	4	RD7-C		
	5	TD8-A	AI 0.75-6 GY (gray)	TTYCS-1Q TTYCSLA-1Q
	6	TD8-B		
	7	RD8-H		
	8	RD8-C		

MC-3010A MC-ANLG Board (24P0115)

<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>	
J1	1	24V_IN	AI 0.34-6 TQ (blue)	MC1.5-W-Lxxx	
	2	24V_GND			
	3	MODBUS-A	AI 0.14-8 GY (gray)		
	4	MODBUS-B			
	5	GND			
<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>	
J2	1	24V_OUT	AI 0.34-6 TQ (blue)	MC1.5-W-Lxxx	
	2	24V_GND			
	3	MODBUS-A	AI 0.14-8 GY (gray)		
	4	MODBUS-B			
	5	GND			
<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>	
J3*	1	AN1_IN	AI 0.75-6 GY (gray)	TTYCS-1 TTYCSLA-1	
	2	AN1_GND			
	3	CURR1_JP1			
	4	CURR1_JP2			
<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>	
J4*	1	AN2_IN	AI 0.75-6 GY (gray)	TTYCS-1 TTYCSLA-1	
	2	AN2_GND			
	3	CURR2_JP1			
	4	CURR2_JP2			
<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>	
J5*	1	AN3_IN	AI 0.75-6 GY (gray)	TTYCS-1 TTYCSLA-1	
	2	AN3_GND			
	3	CURR3_JP1			
	4	CURR3_JP2			

\*: For pin #3 and 4, no cable is connected. However the jumper connection is necessary depending on the input specification.

MC-3020D, MC-DIN Board (24P0116)

<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>	
J1	1	24V_IN	AI 0.34-6 TQ (blue)	MC1.5-W-Lxxx	
	2	24V_GND			
	3	MODBUS-A	AI 0.14-8 GY (gray)		
	4	MODBUS-B			
	5	GND			
<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>	
J2	1	24V_OUT	AI 0.34-6 TQ (blue)	MC1.5-W-Lxxx	
	2	24V_GND			
	3	MODBUS-A	AI 0.14-8 GY (gray)		
	4	MODBUS-B			
	5	GND			
<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>	
J3*	1	DV12V_OUT1	AI 1-6 RD (red)	MPYC-12	
	2	DIGI_IN1			
	3	DIGI_RTN1			
	4	GND			
	5	DC12V_OUT2			
	6	DIGI_IN2			
	7	DIGI_RTN2			
	8	GND			
<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>	
J4*	1	DV12V_OUT3	AI 1-6 RD (red)	MPYC-12	
	2	DIGI_IN3			
	3	DIGI_RTN3			
	4	GND			
	5	DC12V_OUT4			
	6	DIGI_IN4			
	7	DIGI_RTN4			
	8	GND			
<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>	
J5*	1	DV12V_OUT5	AI 1-6 RD (red)	MPYC-12	
	2	DIGI_IN5			
	3	DIGI_RTN5			
	4	GND			
	5	DC12V_OUT6			
	6	DIGI_IN6			
	7	DIGI_RTN6			
	8	GND			

\*: Pin #1 and 5: no cable connection. However the jumper connection is necessary between #1 and 2 and #5 and 6 depending on the input specification.

APPX. 2 ROD TERMINALS

Connector #	Pin #	Signal name	Rod terminal to use	Connected cable
J6*	1	DV12V_OUT7	AI 1-6 RD (red)	MPYC-12
	2	DIGI_IN7		
	3	DIGI_RTN7		
	4	GND		
	5	DC12V_OUT8		
	6	DIGI_IN8		
	7	DIGI_RTN8		
	8	GND		

\*: Pin #1 and 5: no cable connection. However the jumper connection is necessary between #1 and 2 and #5 and 6 depending on the input specification.

## MC-3030D, MC-DOUT Board (24P0117)

<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>	
J1	1	24V_IN	AI 0.34-6 TQ (blue)	MC1.5-W-Lxxx	
	2	24V_GND			
	3	MODBUS-A	AI 0.14-8 GY (gray)		
	4	MODBUS-B			
	5	GND			
<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>	
J2	1	24V_OUT	AI 0.34-6 TQ (blue)	MC1.5-W-Lxxx	
	2	24V_GND			
	3	MODBUS-A	AI 0.14-8 GY (gray)		
	4	MODBUS-B			
	5	GND			
<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>	
J3	1	A1	AI 1-6 RD (red)	MPYC-12	
	2	COM1			
	3	B1			
	4	A2			
	5	COM2			
	6	B2			
<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>	
J4	1	A3	AI 1-6 RD (red)	MPYC-12	
	2	COM3			
	3	B3			
	4	A4			
	5	COM4			
	6	B4			
<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>	
J5	1	A5	AI 1-6 RD (red)	MPYC-12	
	2	COM5			
	3	B5			
	4	A6			
	5	COM6			
	6	B6			
<b>Connector #</b>	<b>Pin #</b>	<b>Signal name</b>	<b>Rod terminal to use</b>	<b>Connected cable</b>	
J6	1	A7	AI 1-6 RD (red)	MPYC-12	
	2	COM7			
	3	B7			
	4	A8			
	5	COM8			
	6	B8			

# APPX. 3 RA/IF BOARD JUMPER VALUES

---

The values for each jumper block on the RA/IF board (24P0140) are shown below.

## CH1/CH2 signal settings

J1/J8 HD-TERM		J3/J16 VID-TERM		J5/J18 BP-TERM		J10/J22 TRG-TERM	
1-2	1.2 kΩ	1-5	75Ω	1-2	1.2 kΩ	1-5	50Ω
2-3	OFF	2-6	50Ω	2-3	OFF	2-6	75Ω
J2/J9 HD-PULL UP		J3-7 1.2 kΩ		J6/J19 BP-PULL UP		J13/J24 BP-PULSE NUM	
1-4	5V IN	4-8	100 kΩ	1-4	5V IN	1-2	2048
2-5	OC (560Ω)	J4/J12 HD-POLARITY		2-5	OC (560Ω)	2-3	1024
3-6	OC (1 kΩ)	1-2	NORMAL	3-6	OC (1 kΩ)		
		2-3	REVERSE				

## Input bypass settings (CH2 only)

J7/J11 HD-INTERFACE		J17/J20 BP-INTERFACE	
1-2	ADJUST	1-2	ADJUST
2-3	BYPASS	2-3	BYPASS
J14/J15 VID-INTERFACE		J21/J23	
1-2	ADJUST	1-2	ADJUST
2-3	BYPASS	2-3	BYPASS

## APPX. 4 ALERT LIST

The table starting from the bottom of the page lists the possible alerts for this equipment. Each alert is listed with alert IDs (ALF and ALR), alert description, and priority/category. This equipment can output alerts in ALF or ALR format. The alert number depends on the output format and may differ between formats.

This unit supports the aggregate alert function. Aggregate alerts are a grouping of similar alerts. When an aggregated alert occurs, the aggregated alert name (header alert) is displayed on the AMS connected to this unit. The following table lists the ALF alert numbers and aggregate alert names that are subject to aggregate alerts.

Aggregated Alert Name	Alert Priority	ALF No.
Critical Point*	Alarm	3037, x
Critical Point	Warning	3038, x
WOL XX (XX=WPT no.)*	Warning	3028, x
Wheel Over Line*	Alarm	3027, x
Target Capacity	Warning	3042, x
Target Capacity	Caution	3043, x

X: instance number

\*: TCS dedicated alert

If the warning alert on the left side of the table below is not acknowledged within the set time (escalation time), the alarm will sound again and you will be re-notified (the warning status will be repeated). For the warning alerts on the right side of the table below, if you do not acknowledge within 120 seconds (TCS dedicated alert: 30 seconds) after the alert occurs, the priority will change from "warning" to "alarm".

Warning repeated	Change to Alarm
Applicable warning alert	Escalation time (default setting)
IEC 62923-2 alert	Anchor watch <sup>1</sup> 270 s (fixed)
Other than IEC 62923-2 alert	60 s (changeable) (XX=WPT no.) <sup>2</sup>
	WOL Approach XX (XX=WPT no.) <sup>2</sup>
	WOL XX (XX=WPT no.) <sup>2</sup>
	TCS Stopped <sup>2</sup>
	Track End <sup>2</sup>
	CRS Difference <sup>2</sup>
	Bad Track POSN <sup>2</sup>
	Speed Too Low <sup>2</sup>
	Drift Comp Fail <sup>2</sup>
	TCS Test Mode <sup>2</sup>
	POSN Recovered <sup>2</sup>
	SPD Recovered <sup>2</sup>

<sup>1</sup>: The escalation time for the [Anchor Watch] alert is the time specified in IEC61174. You cannot change the setting.

## APPX. 4 ALERT LIST

\*2: TCS dedicated alert.

**Note 1:** You can change the priority of some alerts, from the [Chart Alerts] page. See the Operator's Manual.

**Note 2:** This equipment does not support the responsibility transfer alert function.

**Note 3:** "TCS" in the Priority/Category indicates TCS dedicated alert.

Priority: Alarm, Warning, Caution

Alert No.	Alert Name, Meaning and Remedy	Priority/Category
ALF ID	ALR ID	
3005,-	465	Warning/B
3038,1 to 3038,199	-	Warning/A
3038,199 to 100000	-	Warning/A
3037,1001 to 3037,1199	-	Alarm/A, TCS
3038,1001 to 3038,1199	-	Warning/A, TCS
3028,1001 to 3028,1199	-	Warning/A, TCS
3028,1199	-	Warning/A, TCS
3027,1001 to 3027,1199	-	Alarm/A, TCS
3064,-	657	Alarm/B, TCS
3065,-	159	Warning/B, TCS
3003,-	985	Caution/B
3003,1	541	Caution/B
3003,2	667	Caution/B

\*1: The connection in the Autopilot.

Alert No.	Alert Name, Meaning and Remedy		Priority/Category
ALF ID	ALR ID		
3011,8	654	<b>Name:</b> POSN Discrepancy <b>Meaning:</b> POSN is much different from others in POSN sensors. <b>Remedy:</b> Monitor situation carefully, or stop track control.	Alarm/A, TCS
3012,8	154	<b>Name:</b> POSN Discrepancy <b>Meaning:</b> There is a difference between position sensors during track control. <b>Remedy:</b> Monitor situation carefully, or stop track control.	Warning/A, TCS
3011,7	655	<b>Name:</b> HDG Discrepancy <b>Meaning:</b> HDG value is much different from others in HDG sensors. <b>Remedy:</b> Monitor situation carefully, or stop track control.	Alarm/A, TCS
3012,7	155	<b>Name:</b> HDG Discrepancy <b>Meaning:</b> There is a difference between heading sensors during track control. <b>Remedy:</b> Monitor situation carefully, or stop track control.	Warning/A, TCS
80746,2	698	<b>Name:</b> No POSN Monitor <b>Meaning:</b> Position monitor function cannot be used because several position sensors are not available. <b>Remedy:</b> Check the position monitor status.	Caution/B, TCS
80746,1	697	<b>Name:</b> No HDG Monitor <b>Meaning:</b> Heading monitor function cannot be used because several heading sensors are not available. <b>Remedy:</b> Check the heading monitor status.	Caution/B, TCS
3014,1	156	<b>Name:</b> Heading Failure <b>Meaning:</b> Lost speed during track control. <b>Remedy:</b> Monitor situation carefully, or stop track control.	Alarm/B, TCS
3014,2	161	<b>Name:</b> Position Failure <b>Meaning:</b> Lost speed during track control. <b>Remedy:</b> Monitor situation carefully, or stop track control.	Alarm/B, TCS
3014,3	162	<b>Name:</b> Speed Failure <b>Meaning:</b> Lost speed during track control. <b>Remedy:</b> Monitor situation carefully, or stop track control.	Alarm/B, TCS
3024,1	172	<b>Name:</b> Off Track <b>Meaning:</b> While monitoring route, ship position deviates more than XTD limit <b>Remedy:</b> Make XTD smaller.	Alarm/A
3031,1	171	<b>Name:</b> Safety Contour <b>Meaning:</b> When a check area is set, the vessel entered a shallow area than the threshold set in [Safety Contour]. <b>Remedy:</b> Reconfirm Safety Contour setting or change the course.	Alarm/A
3031,2	496	<b>Name:</b> Anchor Watch <b>Meaning:</b> While anchor watch alert function is enabled, ship's position has been outside of alarm area centering certain position for more than 3 seconds. <b>Remedy:</b> Be careful of dragging anchor.	Alarm/A
3031,-	510	<b>Name:</b> Lost MODBUS COM <b>Meaning:</b> Connection to the MODBUS is lost or interrupted. <b>Remedy:</b> Check connection.	Warning/B

Alert No.	ALF ID	ALR ID	Alert Name, Meaning and Remedy	Priority/Category
3032,2		495	<b>Name:</b> Anchor Watch <b>Meaning:</b> While anchor watch alert function is enabled, ship's position has been outside of alarm area centering certain position for more than 3 seconds. <b>Remedy:</b> Be careful of dragging anchor.	Warning/A, TCS
3032,-		331	<b>Name:</b> Lost SEL Gyro <b>Meaning:</b> When connected with Double Gyro System, instrument produced by YDK Technologies, "Double Gyro" status cannot be acquired. <b>Remedy:</b> If the error frequently occurs, contact FURUNO and inform frequency of occurrence.	Warning/B, TCS
3035,1		620	<b>Name:</b> USR CHT Danger <b>Meaning:</b> A User Chart Danger Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Warning/A
3035,2		621	<b>Name:</b> Separation Zone <b>Meaning:</b> A Traffic Separation Zone that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Warning/A
3035,3		622	<b>Name:</b> ITZ <b>Meaning:</b> An Inshore Traffic Zone that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Warning/A
3035,4		623	<b>Name:</b> Restricted Area <b>Meaning:</b> A Restricted Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Warning/A
3035,5		624	<b>Name:</b> Caution Area <b>Meaning:</b> A Caution Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Warning/A
3035,6		625	<b>Name:</b> OFS PROD Area <b>Meaning:</b> An Offshore Production Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Warning/A
3035,7		626	<b>Name:</b> MIL PFAc AREA <b>Meaning:</b> A Military Protection Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Warning/A
3035,8		627	<b>Name:</b> SPL Landing Area <b>Meaning:</b> A Seaplane Landing Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Warning/A

Alert No.	Alert Name, Meaning and Remedy		Priority/Category
ALF ID	ALR ID	ALF ID	ALR ID
3035,9	628	Name: SM Transit Lane <b>Meaning:</b> A Submarine Transit Lane that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Warning/A Caution/B
3035,10	629	<b>Name:</b> Anchorage Area <b>Meaning:</b> An Anchorage Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Warning/A Caution/B
3035,11	630	<b>Name:</b> Marine Farm <b>Meaning:</b> A Marine Farm/Aquaculture that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Warning/A Caution/B
3035,12	631	<b>Name:</b> PSSA Area <b>Meaning:</b> A PSSA Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Warning/A Caution/B
3035,13	632	<b>Name:</b> ATBA <b>Meaning:</b> An Areas to be Avoided that is set to Alarm in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Warning/A Caution/B
3035,14	645	<b>Name:</b> NAV Hazard <b>Meaning:</b> One or more navigational hazards detected by the Look-ahead function. <b>Remedy:</b> Adjust course as necessary.	Warning/A Caution/B
3036,1	594	<b>Name:</b> USR CHT Danger <b>Meaning:</b> A User Chart Danger Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Caution/B Caution/B
3036,2	595	<b>Name:</b> Separation Zone <b>Meaning:</b> A Traffic Separation Zone that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Caution/B Caution/B
3036,3	596	<b>Name:</b> ITZ <b>Meaning:</b> An Inshore Traffic Zone that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Caution/B Caution/B
3036,4	597	<b>Name:</b> Restricted Area <b>Meaning:</b> A Restricted Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Caution/B Caution/B
3036,5	598	<b>Name:</b> Caution Area <b>Meaning:</b> A Caution Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	Caution/B Warning/A

Priority/Category	Alert Name, Meaning and Remedy	Alert No.	ALF ID	ALR ID
Caution/B	<b>Name:</b> OFS PROD Area <b>Meaning:</b> An Offshore Production Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	3036,6	599	3036,7
Caution/B	<b>Name:</b> MIL_PPRAC Area <b>Meaning:</b> A Military Protection Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	600		
Caution/B	<b>Name:</b> SPL Landing Area <b>Meaning:</b> A Seaplane Landing Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	601		
Caution/B	<b>Name:</b> SM Transit Lane <b>Meaning:</b> A Submarine Transit Lane that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	602		
Caution/B	<b>Name:</b> Anchorage Area <b>Meaning:</b> An Anchorage Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	603		
Caution/B	<b>Name:</b> PSSA Area <b>Meaning:</b> A PSSA Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	604		
Caution/B	<b>Name:</b> ATBA <b>Meaning:</b> An Areas to be Avoided that is set to Alarm in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	605		
Caution/B	<b>Name:</b> NAV Hazard <b>Meaning:</b> One or more navigational hazards detected by the Look-ahead function. <b>Remedy:</b> Adjust course as necessary.	606		
Caution/B	<b>Name:</b> USR CHT Danger <b>Meaning:</b> A User Chart Danger Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	607		
Caution/B	<b>Name:</b> Separation Zone <b>Meaning:</b> A Traffic Separation Zone that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	608		
Caution/B	<b>Name:</b> ITZ <b>Meaning:</b> An Inshore Traffic Zone that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	609		
Caution/B	<b>Name:</b> Restricted Area <b>Meaning:</b> A Restricted Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	610		
Caution/B	<b>Name:</b> Caution Area <b>Meaning:</b> A Caution Area that is set to Warning/Caution in chart alert is detected inside the check area. <b>Remedy:</b> Be careful of the object mentioned here, on ship's direction.	611		

Alert No.	Alert Name, Meaning and Remedy		Priority/Category
ALF ID	ALR ID		
3043,4	532	<b>Name:</b> AIS Capacity 95% <b>Meaning:</b> 95% of maximum number of AIS targets which can be displayed is used. <b>Remedy:</b> Adjust [AIS DISP FILTER] settings.	Caution/B
3042,4	533	<b>Name:</b> AIS CPTY Full <b>Meaning:</b> Maximum number of AIS targets which can be displayed is used. <b>Remedy:</b> Adjust [AIS DISP FILTER] settings.	Warning/A
3042,5	535	<b>Name:</b> Active AIS Full <b>Meaning:</b> 100% of capacity for active AIS is used. <b>Remedy:</b> The number of active AIS target became 100% of its limit. Change the unnecessary targets to sleep mode.	Warning/A
3043,5	534	<b>Name:</b> Active AIS 95% <b>Meaning:</b> 95% of capacity for active AIS is used. <b>Remedy:</b> The number of active AIS target became 95% of its limit. Change the unnecessary targets to sleep mode.	Caution/B
3043,7	547	<b>Name:</b> AIS DATREF Full <b>Meaning:</b> 100% of memory capacity for AIS data report is filled. <b>Remedy:</b> Adjust [AIS DISP FILTER] settings.	Caution/B
3043,8	548	<b>Name:</b> AIS SART Full <b>Meaning:</b> 100% of memory capacity for AIS locating device is filled. <b>Remedy:</b> Adjust [AIS DISP FILTER] settings.	Caution/B
3043,9	549	<b>Name:</b> AIS SYN TGT Full <b>Meaning:</b> 100% of memory capacity for AIS synthetic target is filled. <b>Remedy:</b> Adjust [AIS DISP FILTER] settings.	Caution/B
3052,5	552	<b>Name:</b> AIS AtOn Lost <b>Meaning:</b> The system lost an AIS AtOn. <b>Remedy:</b> Confirm that the AIS AtOn is lost, then acknowledge the alert.	Warning/A
3052,6	553	<b>Name:</b> AIS SART Lost <b>Meaning:</b> The system lost an AIS SART. <b>Remedy:</b> Confirm that the AIS SART is lost, then acknowledge the alert.	Warning/A
30432,-	431	<b>Name:</b> HUB-3000 Error <b>Meaning:</b> A network error has occurred between the HUB-3000 and one or more connected units. <b>Remedy:</b> Check network connections between the EC-3000/3005 and networked units.	Warning/B
30452,-	330	<b>Name:</b> Conflict Gyro <b>Meaning:</b> When connected with Double Gyro System, instrument produced "Selected" status for 3 seconds. <b>Remedy:</b> If the error frequently occurs, contact FURUNO and inform frequency of occurrence.	Warning/B, TCS
30645,-	644	<b>Name:</b> Actual UKC Limit <b>Meaning:</b> Actual depth is outside the preset UKC limit. <b>Remedy:</b> Check depth, adjust heading accordingly.	Warning/A

Alert No.	ALF ID	ALR ID	Alert Name, Meaning and Remedy	Priority/Category
30703,-	700	<b>Name:</b> RT Version > 1 <b>Meaning:</b> Received route transfer sentence (RTZ) is a higher version than this system. <b>Remedy:</b> Check route details. Some route details may not be displayed correctly.	Caution/B	
30801,-	485	<b>Name:</b> Depth Limit <b>Meaning:</b> Seabed has been less than set depth for more than 3 seconds. <b>Remedy:</b> Be careful of risk of grounding.	Alarm/A	
80716,-	665	<b>Name:</b> AP Mode Conflict <b>Meaning:</b> Failure to start TCS. <b>Remedy:</b> Check the TCS mode in the Autopilot.	Caution/B, TCS	
80721,-	659	<b>Name:</b> Drift Comp Fail <b>Meaning:</b> Cannot perform drift compensation. <b>Remedy:</b> Drift is inaccurate. Monitor drift carefully.	Alarm/B, TCS	
80722,-	689	<b>Name:</b> Drift Comp Fail <b>Meaning:</b> Cannot perform drift compensation. <b>Remedy:</b> Drift is inaccurate. Monitor drift carefully.	Warning/B, TCS	
80726,-	696	<b>Name:</b> Drift Inaccurate <b>Meaning:</b> Drift estimation is not reliable. <b>Remedy:</b> Monitor the drift value and compensate for error accordingly.	Caution/B, TCS	
80731,2	661	<b>Name:</b> POSN Recovered <b>Meaning:</b> Failed position sensor becomes available before TCS stops. <b>Remedy:</b> Monitor ship's position.	Alarm/B, TCS	
80732,2	693	<b>Name:</b> POSN Recovered <b>Meaning:</b> Failed position sensor becomes available before TCS stops. <b>Remedy:</b> Monitor ship's position.	Warning/B, TCS	
80731,3	662	<b>Name:</b> SPD Recovered <b>Meaning:</b> Failed speed sensor becomes available before TCS stops. <b>Remedy:</b> Monitor ship's speed.	Alarm/B, TCS	
80732,3	694	<b>Name:</b> SPD Recovered <b>Meaning:</b> Failed speed sensor becomes available before TCS stops. <b>Remedy:</b> Monitor ship's speed.	Warning/B, TCS	
80727,-	660	<b>Name:</b> TCS Test Mode <b>Meaning:</b> TCS is in test mode. Checks disabled. <b>Remedy:</b> Wait until completion of tests to conduct checks.	Alarm/B, TCS	
80728,-	690	<b>Name:</b> TCS Test Mode <b>Meaning:</b> TCS is in test mode. Checks disabled. <b>Remedy:</b> Wait until completion of tests to conduct checks.	Warning/B, TCS	
80735,-	675	<b>Name:</b> Use MAN Steering <b>Meaning:</b> All GPS signals are lost during track control, and track control has been continued for 10 minutes in DR. Alarm generates every 2 minutes. <b>Remedy:</b> Switch autopilot mode to manual or auto.	Warning/B TCS	
3061,-	658	<b>Name:</b> Bad Track POSN <b>Meaning:</b> Self route check failed during track control. <b>Remedy:</b> Stop track control.	Alarm/A TCS	

Alert No.	Alert Name, Meaning and Remedy		Priority/Category
ALF ID	ALR ID		
3052,-	163	<b>Name:</b> Bad Track POSN <b>Meaning:</b> Self route check failed during track control. <b>Remedy:</b> Stop track control.	Warning/A TCS
3015,21	170	<b>Name:</b> Lost Position <b>Meaning:</b> All position data has been lost for more than 30 seconds. <b>Remedy:</b> Check the connection with all GPS.	Warning/B
3015,22	272	<b>Name:</b> Lost UTC Signal <b>Meaning:</b> Time data of all available GPS sensor has been not available for more than 3 seconds. <b>Remedy:</b> Check position sensor, sensor status.	Warning/B
3015,23	277	<b>Name:</b> Lost Wind Signal <b>Meaning:</b> Wind speed/direction data of all available WIND sensors has been not available for more than 3 seconds. <b>Remedy:</b> Check the connection with all wind sensors. Also, check sensor status.	Warning/B
3015,24	279	<b>Name:</b> Lost COG/SOG SIG <b>Meaning:</b> COG/SOG data input stopped for three seconds. <b>Remedy:</b> Check the connection with all GPS sensors. Also, check sensor status.	Warning/B
3015,25	284	<b>Name:</b> Lost LOG(BT) SIG <b>Meaning:</b> SOG data of all available LOG (ground speed) sensors has been not available for more than 3 seconds. Also, check sensor status.	Warning/B
3015,26	450	<b>Name:</b> Lost Heading SIG <b>Meaning:</b> Heading data of all available gyro has been not available for more than 2 seconds. <b>Remedy:</b> Check the connection with all gyro. Also, check sensor status.	Warning/B
3015,27	453	<b>Name:</b> Lost SDME Signal <b>Meaning:</b> Speed data from all available SDME has been not available for more than 3 seconds. <b>Remedy:</b> Check the connection with all SDME. Also, check sensor status.	Warning/B
3015,28	278	<b>Name:</b> Lost LOG(W/T) SIG <b>Meaning:</b> STW data of all available SDME sensors has been not available for more than 3 seconds. <b>Remedy:</b> Check the connection with all SDME. Also, check sensor status.	Warning/B
3015,30	380	<b>Name:</b> Lost AIS COM <b>Meaning:</b> Data from AIS has been discontinued for more than set time. (Set at installation) Default: 60 seconds AIS is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with AIS and network.	Warning/B
3016,24	382	<b>Name:</b> Lost COG/SOG SIG <b>Meaning:</b> COG/SOG data input stopped for three seconds. <b>Remedy:</b> Check the connection with all GPS sensors. Also, check sensor status.	Caution/B

Alert No.	ALF ID	ALR ID	Alert Name, Meaning and Remedy	Priority/Category
3016,25		383	<b>Name:</b> Lost LOG(BT) SIG <b>Meaning:</b> SOG data of all available LOG (ground speed) sensors has been not available for more than 3 seconds. <b>Remedy:</b> Check that connection with all LOG sensors. Also, check sensor status.	Caution/B
3016,28		384	<b>Name:</b> Lost LOG(W/T) SIG <b>Meaning:</b> Speed data from all available SDME has been not available for more than 3 seconds. <b>Remedy:</b> Check the connection with all SDME. Also, check sensor status.	Caution/B
3016,30		381	<b>Name:</b> Lost AIS COM <b>Meaning:</b> Data from AIS has been discontinued for more than set time. (Set at installation) Default: 60 seconds AIS is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with AIS and network.	Caution/B
30403,1		255	<b>Name:</b> Lost Gyro1 COM <b>Meaning:</b> Data from No.1 gyro has been discontinued for more than set time. (Set at installation) Default: 60 seconds <b>Remedy:</b> No.1 gyro is turned off, or there is a problem with network.	Caution/B
30403,2		256	<b>Name:</b> Lost Gyro2 COM <b>Meaning:</b> Data from No.2 gyro has been discontinued for more than set time. (Set at installation) Default: 60 seconds <b>Remedy:</b> No.2 gyro is turned off, or there is a problem with network.	Caution/B
30403,3		257	<b>Name:</b> Lost Gyro3 COM <b>Meaning:</b> Data from No.3 gyro has been discontinued for more than set time. (Set at installation) Default: 60 seconds <b>Remedy:</b> No.3 gyro is turned off, or there is a problem with network.	Caution/B
30403,4		258	<b>Name:</b> Lost Gyro4 COM <b>Meaning:</b> Data from No.4 gyro has been discontinued for more than set time. (Set at installation) Default: 60 seconds <b>Remedy:</b> No.4 gyro is turned off, or there is a problem with network.	Caution/B
30403,5		259	<b>Name:</b> Lost Gyro5 COM <b>Meaning:</b> Data from No.5 gyro has been discontinued for more than set time. (Set at installation) Default: 60 seconds <b>Remedy:</b> No.5 gyro is turned off, or there is a problem with network.	Caution/B
30512,1		900	<b>Name:</b> No POSN for FILT <b>Meaning:</b> No valid position sensor is available for filter. (Banned or connection error), <b>Remedy:</b> Check the connection with all GPS sensors.	Warning/B, TCS
30512,2		901	<b>Name:</b> No SOG for FILT <b>Meaning:</b> No valid COG/SOG is available for filter. (Banned or connection error), <b>Remedy:</b> Check the connection with all GPS sensors.	Warning/B, TCS

Alert No.	Alert Name, Meaning and Remedy		Priority/Category
ALF ID	ALR ID	ALF ID	ALR ID
30512,3	902	Name: No STW for FILT <b>Meaning:</b> No valid CTW/STW sensor is available for filter. <b>(Banned or connection error)</b> <b>Remedy:</b> Check the connection with all GPS sensors.	Warning/B, TCS
30512,4	903	Name: No HDG for FILT <b>Meaning:</b> No valid heading sensor is available for filter. <b>(Banned or connection error)</b> <b>Remedy:</b> Check the connection with all GPS sensors.	Warning/B, TCS
30603,1	273	<b>Name:</b> Lost Bow Depth <b>Meaning:</b> Depth data of all available depth sensor(Bow) has been not available for more than 3 seconds. <b>Remedy:</b> Check the connection with all echo sounders.	Caution/B
30603,2	274	<b>Name:</b> Lost MID Depth <b>Meaning:</b> Depth data of all available depth sensor(Mid) has been not available for more than 3 seconds. <b>Remedy:</b> Check the connection with all echo sounders.	Caution/B
30603,3	275	<b>Name:</b> Lost Stern Depth <b>Meaning:</b> Depth data of all available depth sensor(Stern) has been not available for more than 3 seconds. <b>Remedy:</b> Check the connection with all echo sounders.	Caution/B
30603,5	285	<b>Name:</b> Lost HDG MAG <b>Meaning:</b> Heading data of all available magnetic gyro has been not available for more than 3 seconds. <b>Remedy:</b> Check the connection with all magnetic gyro.	Caution/B
30603,6	276	<b>Name:</b> Lost Depth <b>Meaning:</b> Depth data of all available depth sensors has been not available for more than 3 seconds. <b>Remedy:</b> Check the connection with all echo sounders.	Caution/B
30682,1	680	<b>Name:</b> Watch End <b>Meaning:</b> Watch is ending. <b>Remedy:</b> Prepare to make turn(s).	Warning/B
30682,2	681	<b>Name:</b> Repeated Timer <b>Meaning:</b> The action set with repeated timer is approaching. <b>Remedy:</b> Take the actions scheduled in advance.	Warning/B
30682,3	682	<b>Name:</b> Specified Timer <b>Meaning:</b> The action set with specified timer is approaching. <b>Remedy:</b> Take the actions scheduled in advance.	Warning/B
33035,1	634	<b>Name:</b> UKC Limit <b>Meaning:</b> Measured depth from echo sounder is less than set UKC limit value. <b>Remedy:</b> Be careful that measured depth is less than UKC limit.	Warning/A
33035,2	635	<b>Name:</b> Non-official ENC <b>Meaning:</b> A non-official ENC with warning and caution settings was detected in the fore monitoring check area. <b>Remedy:</b> Install official ENC.	Warning/A
33035,3	636	<b>Name:</b> No Vector Chart <b>Meaning:</b> A vector chart without warning and caution was detected in the fore monitoring check area, <b>Remedy:</b> Install latest vector chart.	Warning/A

Priority/Category	Alert Name, Meaning and Remedy	Alert No.	ALF ID	ALR ID
Warning/A	<b>Name:</b> Not Up-to-date <b>Meaning:</b> When Not Up to Date is set to Warning/Caution in chart alert, a chart area that is not up-to-date is detected inside the check area. <b>Remedy:</b> Install latest chart.	33035,4	637	
Warning/A	<b>Name:</b> Permit Expired <b>Meaning:</b> When Permit Expired is set to Warning/Caution in chart alert, a chart area that has an expired permit is detected inside the check area. <b>Remedy:</b> Update chart permits.	33035,5	638	
Warning/A	<b>Name:</b> Sounding UKC LIM <b>Meaning:</b> Chart depth for one or more legs is outside of UKC threshold. <b>Remedy:</b> Adjust course as necessary.	33035,6	646	
Warning/A	<b>Name:</b> Too Many Dangers <b>Meaning:</b> Selected route and look-ahead area have too many dangerous objects. <b>Remedy:</b> The check area may not be completely checked for dangerous objects. Make the route or look-ahead area smaller.	33035,7	647	
Caution/B	<b>Name:</b> UKC Limit <b>Meaning:</b> Measured depth from echo sounder is less than UKC limit value. <b>Remedy:</b> Be careful that measured depth is less than UKC limit.	33036,1	608	
Caution/B	<b>Name:</b> Non-official ENC <b>Meaning:</b> When Non-official ENC is set to Warning/Caution in chart alert, the non-official chart area is detected inside the check area. <b>Remedy:</b> Install latest official ENC.	33036,2	609	
Caution/B	<b>Name:</b> No Vector Chart <b>Meaning:</b> When No Vector Chart is set to Warning/Caution in chart alert, the No Vector Chart area is detected inside the check area. <b>Remedy:</b> Install vector charts.	33036,3	611	
Caution/B	<b>Name:</b> Not Up-to-date <b>Meaning:</b> When Not Up to Date is set to Caution in chart alert, a chart area that is not up-to-date is detected inside the check area.	33036,4	612	
Caution/B	<b>Name:</b> Permit Expired <b>Meaning:</b> When Permit Expired is set to Caution in chart alert, a chart area that has an expired permit is detected inside the check area. <b>Remedy:</b> Update chart permits.	33036,5	613	
Caution/B	<b>Name:</b> Sounding UKC LIM <b>Meaning:</b> Chart depth for one or more legs is outside the UKC threshold. <b>Remedy:</b> Adjust course accordingly.	33036,6	614	

## APPX. 4 ALERT LIST

## APPX. 4 ALERT LIST

Alert No.	Alert Name, Meaning and Remedy		Priority/Category
ALF ID	ALR ID		
33036,7	615	<b>Name:</b> Too Many Dangers <b>Meaning:</b> Selected route and look-ahead area have too many dangerous objects. <b>Remedy:</b> The check area may not be completely checked for dangerous objects. Make the route or look-ahead area smaller.	Caution/B
3007,200	160	<b>Name:</b> TCS Stopped <b>Meaning:</b> Track control is discontinued because sensors such as GYRO, GPS, LOG and Autopilot stop input during Track Control. <b>Remedy:</b> Check the sensors and autopilot.	Alarm/B, TCS
3008,200	153	<b>Name:</b> TCS Stopped <b>Meaning:</b> Track control is discontinued because sensors such as GYRO, GPS, LOG and Autopilot stop input during track control. <b>Remedy:</b> Check the sensors and autopilot.	Warning/B, TCS
3022,-	165	<b>Name:</b> TCS Power Fail <b>Meaning:</b> Some units running TCS have experienced a power failure. <b>Remedy:</b> Check the TCS.	Warning/B, TCS
3024,2	653	<b>Name:</b> End of Track <b>Meaning:</b> Vessel is 30 seconds away from last waypoint. <b>Remedy:</b> Track control reaches last waypoint. Take necessary action.	Alarm/A, TCS
3025,2	652	<b>Name:</b> End of Track <b>Meaning:</b> Vessel is 30 seconds away from last waypoint. <b>Remedy:</b> Track control reaches last waypoint. Take necessary action.	Warning/A, TCS
3008,100	691	<b>Name:</b> Route Failure <b>Meaning:</b> Route monitoring is stopped due to internal error. <b>Remedy:</b> Check own ship position.	Warning/B
30303,1	030	<b>Name:</b> Lost SA1 COM <b>Meaning:</b> Communication error with No.1 sensor adapter is detected. 30 seconds timeout. No.1 sensor adapter is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.1 sensor adapter and network.	Caution/B
30303,2	031	<b>Name:</b> Lost SA2 COM <b>Meaning:</b> Communication error with No.2 sensor adapter is detected. 30 seconds timeout. No.2 sensor adapter is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.2 sensor adapter and network.	Caution/B
30303,3	032	<b>Name:</b> Lost SA3 COM <b>Meaning:</b> Communication error with No.3 sensor adapter is detected. 30 seconds timeout. No.3 sensor adapter is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.3 sensor adapter and network.	Caution/B

Priority/Category	Alert Name, Meaning and Remedy	Alert No.	ALF ID	ALR ID
Caution/B	<b>Name:</b> Lost SA4 COM <b>Meaning:</b> Communication error with No.4 sensor adapter is detected. 30 seconds timeout. No.4 sensor adapter is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.4 sensor adapter and network.	30303,5	034	
Caution/B	<b>Name:</b> Lost SA5 COM <b>Meaning:</b> Communication error with No.5 sensor adapter is detected. 30 seconds timeout. No.5 sensor adapter is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.5 sensor adapter and network.	30303,6	035	
Caution/B	<b>Name:</b> Lost SA6 COM <b>Meaning:</b> Communication error with No.6 sensor adapter is detected. 30 seconds timeout. No.6 sensor adapter is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.6 sensor adapter and network.	30303,7	036	
Caution/B	<b>Name:</b> Lost SA7 COM <b>Meaning:</b> Communication error with No.7 sensor adapter is detected. 30 seconds timeout. No.7 sensor adapter is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.7 sensor adapter and network.	30303,8	037	
Caution/B	<b>Name:</b> Lost SA8 COM <b>Meaning:</b> Communication error with No.8 sensor adapter is detected. 30 seconds timeout. No.8 sensor adapter is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.8 sensor adapter and network.	30303,9	038	
Caution/B	<b>Name:</b> Lost SA9 COM <b>Meaning:</b> Communication error with No.9 sensor adapter is detected. 30 seconds timeout. No.9 sensor adapter is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.9 sensor adapter and network.	30303,10	039	
Caution/B	<b>Name:</b> Lost SA10 COM <b>Meaning:</b> Communication error with No.10 sensor adapter is detected. 30 seconds timeout. No.10 sensor adapter is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.10 sensor adapter and network.	30303,11	094	
Caution/B	<b>Name:</b> Lost SA11 COM <b>Meaning:</b> Communication error with No.11 sensor adapter is detected. 30 seconds timeout. No.11 sensor adapter is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.11 sensor adapter and network.	30303,12	095	

Alert No.	Alert Name, Meaning and Remedy		Priority/Category
ALF ID	ALR ID		
30303,13	096	<b>Name:</b> Lost SA13 COM <b>Meaning:</b> Communication error with No.13 sensor adapter is detected. 30 seconds timeout. No.13 sensor adapter is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.13 sensor adapter and network.	Caution/B
30303,14	097	<b>Name:</b> Lost SA14 COM <b>Meaning:</b> Communication error with No.14 sensor adapter is detected. 30 seconds timeout. No.14 sensor adapter is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.14 sensor adapter and network.	Caution/B
30303,15	098	<b>Name:</b> Lost SA15 COM <b>Meaning:</b> Communication error with No.15 sensor adapter is detected. 30 seconds timeout. No.15 sensor adapter is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.15 sensor adapter and network.	Caution/B
30303,16	099	<b>Name:</b> Lost SA16 COM <b>Meaning:</b> Communication error with No.16 sensor adapter is detected. 30 seconds timeout. No.16 sensor adapter is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.16 sensor adapter and network.	Caution/B
3031,101	656	<b>Name:</b> CRS Difference <b>Meaning:</b> Actual heading of the ship deviates from the track course beyond a preset value (default 30 degrees). <b>Remedy:</b> Monitor closely or stop track control.	Alarm/A TCS
3032,101	158	<b>Name:</b> CRS Difference <b>Meaning:</b> Actual heading of the ship deviates from the track course beyond a preset value (default 30 degrees). <b>Remedy:</b> Check the connection with No.1 ROT gyro.	Warning/A TCS
30403,11	391	<b>Name:</b> Lost ROT Gyro1 <b>Meaning:</b> Data from No.1 ROT gyro has been discontinued for more than set time. (Set at installation) <b>Default:</b> 60 seconds <b>Remedy:</b> Check the connection with No.1 ROT gyro.	Caution/B
30403,12	392	<b>Name:</b> Lost ROT Gyro2 <b>Meaning:</b> Data from No.2 ROT gyro has been discontinued for more than set time. (Set at installation) <b>Default:</b> 60 seconds <b>Remedy:</b> Check the connection with No.2 ROT gyro.	Caution/B
30403,13	393	<b>Name:</b> Lost ROT Gyro3 <b>Meaning:</b> Data from No.3 ROT gyro has been discontinued for more than set time. (Set at installation) <b>Default:</b> 60 seconds <b>Remedy:</b> Check the connection with No.3 ROT gyro.	Caution/B
30403,21	290	<b>Name:</b> Lost GPS1 COM <b>Meaning:</b> Ship position data from No.1 GPS has been discontinued for more than set time. (Set at installation) <b>Default:</b> 60 seconds <b>Remedy:</b> No.1 GPS is turned off, or there is a problem with network.	Caution/B
30403,29	298	<b>Name:</b> Lost GPS2 COM <b>Meaning:</b> Ship position data from No.2 GPS has been discontinued for more than set time. (Set at installation) <b>Default:</b> 60 seconds <b>Remedy:</b> No.2 GPS is turned off, or there is a problem with network.	Caution/B
30403,30	299	<b>Name:</b> Lost GPS3 COM <b>Meaning:</b> Ship position data from No.3 GPS has been discontinued for more than set time. (Set at installation) <b>Default:</b> 60 seconds <b>Remedy:</b> No.3 GPS is turned off, or there is a problem with network.	Caution/B
30403,24	293	<b>Name:</b> Lost GPS4 COM <b>Meaning:</b> Ship position data from No.4 GPS has been discontinued for more than set time. (Set at installation) <b>Default:</b> 60 seconds <b>Remedy:</b> No.4 GPS is turned off, or there is a problem with network.	Caution/B
30403,25	294	<b>Name:</b> Lost GPS5 COM <b>Meaning:</b> Ship position data from No.5 GPS has been discontinued for more than set time. (Set at installation) <b>Default:</b> 60 seconds <b>Remedy:</b> No.5 GPS is turned off, or there is a problem with network.	Caution/B
30403,26	295	<b>Name:</b> Lost GPS6 COM <b>Meaning:</b> Ship position data from No.6 GPS has been discontinued for more than set time. (Set at installation) <b>Default:</b> 60 seconds <b>Remedy:</b> No.6 GPS is turned off, or there is a problem with network.	Caution/B
30403,27	296	<b>Name:</b> Lost GPS7 COM <b>Meaning:</b> Ship position data from No.7 GPS has been discontinued for more than set time. (Set at installation) <b>Default:</b> 60 seconds <b>Remedy:</b> No.7 GPS is turned off, or there is a problem with network.	Caution/B
30403,28	297	<b>Name:</b> Lost GPS8 COM <b>Meaning:</b> Ship position data from No.8 GPS has been discontinued for more than set time. (Set at installation) <b>Default:</b> 60 seconds <b>Remedy:</b> No.8 GPS is turned off, or there is a problem with network.	Caution/B
30403,29	298	<b>Name:</b> Lost GPS9 COM <b>Meaning:</b> Ship position data from No.9 GPS has been discontinued for more than set time. (Set at installation) <b>Default:</b> 60 seconds <b>Remedy:</b> No.9 GPS is turned off, or there is a problem with network.	Caution/B
30403,30	299	<b>Name:</b> Lost GPS10 COM <b>Meaning:</b> Ship position data from No.10 GPS has been discontinued for more than set time. (Set at installation) <b>Default:</b> 60 seconds <b>Remedy:</b> No.10 GPS is turned off, or there is a problem with network.	Caution/B

Alert No.	Alert Name, Meaning and Remedy		Priority/Category
ALF ID	ALR ID		
30403,41	280	<b>Name:</b> Lost SDME 1 COM <b>Meaning:</b> Speed data from No.1 SDME has been discontinued for more than set time. (Set at installation) Default: 60 seconds No.1 SDME is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.1 SDME and network.	Caution/B
30403,42	281	<b>Name:</b> Lost SDME 2 COM <b>Meaning:</b> Speed data from No.2 SDME has been discontinued for more than set time. (Set at installation) Default: 60 seconds No.2 SDME is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.2 SDME and network.	Caution/B
30403,43	282	<b>Name:</b> Lost SDME 3 COM <b>Meaning:</b> Speed data from No.3 SDME has been discontinued for more than set time. (Set at installation) Default: 60 seconds No.3 SDME is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.3 SDME and network.	Caution/B
30403,51	235	<b>Name:</b> Lost Depth1 COM <b>Meaning:</b> Input of depth data from No.1 echo sounder has been discontinued for more than set time. (Set at installation) Default: 60 seconds <b>Remedy:</b> No.1 echo sounder is turned off, or there is a problem with network.	Caution/B
30403,52	236	<b>Name:</b> Lost Depth2 COM <b>Meaning:</b> Input of depth data from No.2 echo sounder has been discontinued for more than set time. (Set at installation) Default: 60 seconds <b>Remedy:</b> No.2 echo sounder is turned off, or there is a problem with network.	Caution/B
30403,53	237	<b>Name:</b> Lost Depth3 COM <b>Meaning:</b> Input of depth data from No.3 echo sounder has been discontinued for more than set time. (Set at installation) Default: 60 seconds <b>Remedy:</b> No.3 echo sounder is turned off, or there is a problem with network.	Caution/B
30403,61	300	<b>Name:</b> Lost Rudder1 COM <b>Meaning:</b> Rudder data from No.1 rudder sensor has been discontinued for more than set time. (Set at installation) Default: 60 seconds <b>Remedy:</b> Check the connection with No.1 rudder sensor and network.	Caution/B
30403,62	301	<b>Name:</b> Lost Rudder2 COM <b>Meaning:</b> Rudder data from No.2 rudder sensor has been discontinued for more than set time. (Set at installation) Default: 60 seconds <b>Remedy:</b> Check the connection with No.2 rudder sensor and network.	Caution/B
30403,63	302	<b>Name:</b> Lost Rudder3 COM <b>Meaning:</b> Rudder data from No.3 rudder sensor has been discontinued for more than set time. (Set at installation) Default: 60 seconds <b>Remedy:</b> Check the connection with No.3 rudder sensor and network.	Caution/B
30403,71	303	<b>Name:</b> Lost HCS1 COM <b>Meaning:</b> Data from No.1 HCS has been discontinued for more than set time. (Set at installation) Default: 60 seconds <b>Remedy:</b> Check the connection with No.1 HCS and network.	Caution/B
30403,72	304	<b>Name:</b> Lost HCS2 COM <b>Meaning:</b> Data from No.2 HCS has been discontinued for more than set time. (Set at installation) Default: 60 seconds <b>Remedy:</b> Check the connection with No.2 HCS and network.	Caution/B
30403,81	305	<b>Name:</b> Lost VDR COM <b>Meaning:</b> Sentence from VDR has been discontinued for more than set time. (Set at installation) Default: 180 seconds <b>Remedy:</b> Check the connection with VDR and network.	Caution/B
30403,91	306	<b>Name:</b> Lost BNWAS1 COM <b>Meaning:</b> Caution Sentence from BNWAS1 has been discontinued for more than set time. (Set at installation) Default: 180 seconds <b>Remedy:</b> Check the connection with BNWAS1 and network.	Caution/B
30403,92	307	<b>Name:</b> Lost BNWAS2 COM <b>Meaning:</b> Caution Sentence from BNWAS2 has been discontinued for more than set time. (Set at installation) Default: 180 seconds <b>Remedy:</b> Check the connection with BNWAS2 and network.	Caution/B

Alert No.	Alert Name, Meaning and Remedy		Priority/Category
ALF ID	ALR ID		
30403,93	308	<b>Name:</b> Lost BNWAS3 COM <b>Meaning:</b> Caution Sentence from BNWAS3 has been discontinued for more than set time. (Set at installation) <b>Default:</b> 180 seconds <b>BNWAS3 is turned off, or there is a problem with network.</b> <b>Remedy:</b> Check the connection with BNWAS3 and network.	Caution/B, TCS
30503,1	851	<b>Name:</b> GPS1 Banned <b>Meaning:</b> Own ship position data from No.1 GPS is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
30503,2	852	<b>Name:</b> GPS2 Banned <b>Meaning:</b> Own ship position data from No.2 GPS is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
30503,3	853	<b>Name:</b> GPS3 Banned <b>Meaning:</b> Own ship position data from No.3 GPS is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
30503,4	854	<b>Name:</b> GPS4 Banned <b>Meaning:</b> Own ship position data from No.4 GPS is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
30503,5	855	<b>Name:</b> GPS5 Banned <b>Meaning:</b> Own ship position data from No.5 GPS is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS

Alert No.	ALF ID	ALR ID	Alert Name, Meaning and Remedy	Priority/Category
			<b>Name:</b> GPS6 Banned <b>Meaning:</b> Own ship position data from No.6 GPS is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
		30503,6	<b>Name:</b> GPS7 Banned <b>Meaning:</b> Own ship position data from No.7 GPS is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
		30503,7	<b>Name:</b> GPS8 Banned <b>Meaning:</b> Own ship position data from No.8 GPS is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
		30503,8	<b>Name:</b> GPS9 Banned <b>Meaning:</b> Own ship position data from No.9 GPS is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
		30503,9	<b>Name:</b> GPS10 Banned <b>Meaning:</b> Own ship position data from No.10 GPS is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
		30503,11	<b>Name:</b> Gyro1 Banned <b>Meaning:</b> Heading data from No.1 Gyro is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
		871		

Alert No.	Alert Name, Meaning and Remedy		Priority/Category
ALF ID	ALR ID		
30503,12	872	<b>Name:</b> Gyro2 Banned <b>Meaning:</b> Heading data from No.2 Gyro is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
30503,13	873	<b>Name:</b> Gyro3 Banned <b>Meaning:</b> Heading data from No.3 Gyro is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
30503,14	874	<b>Name:</b> Gyro4 Banned <b>Meaning:</b> Heading data from No.4 Gyro is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
30503,15	875	<b>Name:</b> Gyro5 Banned <b>Meaning:</b> Heading data from No.5 Gyro is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
30503,21	861	<b>Name:</b> SDME1 Banned <b>Meaning:</b> Own ship speed data from No.1 SDME is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
30503,22	862	<b>Name:</b> SDME2 Banned <b>Meaning:</b> Own ship speed data from No.2 SDME is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS

Alert No.	ALF ID	ALR ID	Alert Name, Meaning and Remedy	Priority/Category
30503,23		863	<b>Name:</b> SDME3 Banned <b>Meaning:</b> Own ship speed data from No.3 SDME is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
30503,31		881	<b>Name:</b> ROT Gyro1 Banned <b>Meaning:</b> Heading data from No.1 ROT Gyro is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
30503,32		882	<b>Name:</b> ROT Gyro2 Banned <b>Meaning:</b> Heading data from No.2 ROT Gyro is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
30503,33		883	<b>Name:</b> ROT Gyro 3 Banned <b>Meaning:</b> Heading data from No.3 ROT Gyro is determined abnormal by integrity check. <b>Remedy:</b> Reset the filter to confirm that it isn't a temporal error value. If the data is normal, it is reusable. However, if it's continually removed, there is a possibility that correct data is not received from sensor. In this case, contact FU-RUNO.	Caution/B, TCS
30403,101		360	<b>Name:</b> Lost WIND1 COM <b>Meaning:</b> Data from No.1 wind sensor has been discontinued for more than set time. (Set at installation) Default: 60 seconds No.1 wind sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.1 wind sensor.	Caution/B
30403,102		361	<b>Name:</b> Lost WIND2 COM <b>Meaning:</b> Data from No.2 wind sensor has been discontinued for more than set time. (Set at installation) Default: 60 seconds No.2 wind sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.2 wind sensor.	Caution/B
30403,103		362	<b>Name:</b> Lost WIND3 COM <b>Meaning:</b> Data from No.3 wind sensor has been discontinued for more than set time. (Set at installation) Default: 60 seconds No.3 wind sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.3 wind sensor.	Caution/B

Alert No.	Alert Name, Meaning and Remedy		Priority/Category
ALF ID	ALR ID	ALF ID	ALR ID
30403, 111	370	<b>Name:</b> Lost CURRENT COM <b>Meaning:</b> Data from water current has been discontinued for more than set time. (Set at installation) Default: 60 seconds Water current sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with water current and network.	Caution/B  <b>Name:</b> Lost OTHER4 COM <b>Meaning:</b> Data from No.4 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.4 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.4 other sensor and network.
30403, 121	371	<b>Name:</b> Lost TEMP COM <b>Meaning:</b> Data from water temp. has been discontinued for more than set time. (Set at installation) Default: 60 seconds Water temp sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with water temp and network.	Caution/B  <b>Name:</b> Lost OTHER5 COM <b>Meaning:</b> Data from No.5 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.5 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.5 other sensor and network.
30403, 141	390	<b>Name:</b> Lost NAVTEX COM <b>Meaning:</b> Data from NAVTEX has been discontinued for more than set time. (Set at installation) Default: 180 seconds NAVTEX is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with NAVTEX and network.	Caution/B  <b>Name:</b> Lost OTHER6 COM <b>Meaning:</b> Data from No.6 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.6 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.6 other sensor and network.
30403, 151	310	<b>Name:</b> Lost OTHER1 COM <b>Meaning:</b> Data from No.1 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.1 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.1 other sensor and network.	Caution/B  <b>Name:</b> Lost OTHER7 COM <b>Meaning:</b> Data from No.7 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.7 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.7 other sensor and network.
30403, 152	311	<b>Name:</b> Lost OTHER2 COM <b>Meaning:</b> Data from No.2 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.2 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.2 other sensor and network.	Caution/B  <b>Name:</b> Lost OTHER8 COM <b>Meaning:</b> Data from No.8 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.8 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.8 other sensor and network.
30403, 153	312	<b>Name:</b> Lost OTHER3 COM <b>Meaning:</b> Data from No.3 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.3 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.3 other sensor and network.	Caution/B  <b>Name:</b> Lost OTHER9 COM <b>Meaning:</b> Data from No.9 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.9 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.9 other sensor and network.

Alert No.	Alert Name, Meaning and Remedy		Priority/Category
ALF ID	ALR ID		
30403, 160	319	<b>Name:</b> Lost OTHER10 COM <b>Meaning:</b> Data from No.10 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.10 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.10 other sensor and network.	Caution/B
30403, 161	411	<b>Name:</b> Lost OTHER11 COM <b>Meaning:</b> Data from No.11 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.11 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.11 other sensor and network.	Caution/B
30403, 162	412	<b>Name:</b> Lost OTHER12 COM <b>Meaning:</b> Data from No.12 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.12 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.12 other sensor and network.	Caution/B
30403, 163	413	<b>Name:</b> Lost OTHER13 COM <b>Meaning:</b> Data from No.13 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.13 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.13 other sensor and network.	Caution/B
30403, 164	414	<b>Name:</b> Lost OTHER14 COM <b>Meaning:</b> Data from No.14 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.14 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.14 other sensor and network.	Caution/B
30403, 165	415	<b>Name:</b> Lost OTHER15 COM <b>Meaning:</b> Data from No.15 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.15 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.15 other sensor and network.	Caution/B

Alert No.	ALF ID	ALR ID	Alert Name, Meaning and Remedy	Priority/Category
				Caution/B
	30403, 166	416	<b>Name:</b> Lost OTHER16 COM <b>Meaning:</b> Data from No.16 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.16 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.16 other sensor and network.	Caution/B
	30403, 167	417	<b>Name:</b> Lost OTHER17 COM <b>Meaning:</b> Data from No.17 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.17 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.17 other sensor and network.	Caution/B
	30403, 168	418	<b>Name:</b> Lost OTHER18 COM <b>Meaning:</b> Data from No.18 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.18 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.18 other sensor and network.	Caution/B
	30403, 169	419	<b>Name:</b> Lost OTHER19 COM <b>Meaning:</b> Data from No.19 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.19 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.19 other sensor and network.	Caution/B
	30403, 170	420	<b>Name:</b> Lost OTHER20 COM <b>Meaning:</b> Data from No.20 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.20 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.20 other sensor and network.	Caution/B
	30403, 171	421	<b>Name:</b> Lost OTHER21 COM <b>Meaning:</b> Data from No.21 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.21 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.21 other sensor and network.	Caution/B

Alert No.	Alert Name, Meaning and Remedy		Priority/Category
ALF ID	ALR ID	ALF ID	ALR ID
30403, 172	422	<b>Name:</b> Lost OTHER22 COM <b>Meaning:</b> Data from No.22 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.22 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.22 other sensor and network.	Caution/B
30403, 173	423	<b>Name:</b> Lost OTHER23 COM <b>Meaning:</b> Data from No.23 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.23 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.23 other sensor and network.	Caution/B
30403, 174	424	<b>Name:</b> Lost OTHER24 COM <b>Meaning:</b> Data from No.24 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.24 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.24 other sensor and network.	Caution/B
30403, 175	425	<b>Name:</b> Lost OTHER25 COM <b>Meaning:</b> Data from No.25 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.25 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.25 other sensor and network.	Caution/B
30403, 176	426	<b>Name:</b> Lost OTHER26 COM <b>Meaning:</b> Data from No.26 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.26 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.26 other sensor and network.	Caution/B
30403, 177	427	<b>Name:</b> Lost OTHER27 COM <b>Meaning:</b> Data from No.27 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.27 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.27 other sensor and network.	Caution/B

Alert No.	Alert Name, Meaning and Remedy		Priority/Category
ALF ID	ALR ID	ALF ID	ALR ID
30403, 178	428	<b>Name:</b> Lost OTHER28 COM <b>Meaning:</b> Data from No.28 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.28 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.28 other sensor and network.	Caution/B
30403, 179	429	<b>Name:</b> Lost OTHER29 COM <b>Meaning:</b> Data from No.29 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.29 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.29 other sensor and network.	Caution/B
30403, 180	430	<b>Name:</b> Lost OTHER30 COM <b>Meaning:</b> Data from No.30 other sensor has been discontinued for more than set time. (Set at installation) Default: 180 seconds No.30 other sensor is turned off, or there is a problem with network. <b>Remedy:</b> Check the connection with No.30 other sensor and network.	Caution/B

Priority: Indication

All indication alerts are in category "B". Note that the ALF sentence is not output.

**Note:** Indication alerts appears in both the Alert box and the Alert list, just like any other alert.

Alert No.	Alert Name, Meaning and Remedy		
ALF ID	ALR ID	ALF ID	ALR ID
30001,1	001	<b>Name:</b> Main Monitor Fan1 Rotation Speed Lowering <b>Meaning:</b> The rotation speed of the No. 1 fan in the main monitor (FURUNO make) connected to COM1 is lowering. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.	
30001,2	002	<b>Name:</b> Main Monitor Fan2 Rotation Speed Lowering <b>Meaning:</b> The rotation speed of the No. 2 fan in the main monitor (FURUNO make) connected to COM1 is lowering. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.	
30001,3	003	<b>Name:</b> Main Monitor Fan3 Rotation Speed Lowering <b>Meaning:</b> The rotation speed of the No. 3 fan in the main monitor (FURUNO make) connected to COM1 is lowering. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.	
30001,4	004	<b>Name:</b> Main Monitor Fan4 Rotation Speed Lowering <b>Meaning:</b> The rotation speed of the No. 4 fan in the main monitor (FURUNO make) connected to COM1 is lowering. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.	

Alert No.	Alert Name, Meaning and Remedy	
ALF ID	ALR ID	
30001,5	014	<b>Name:</b> Sub Monitor Fan1 Rotation Speed Lowering <b>Meaning:</b> The rotation speed of the No. 1 fan in the sub monitor (FURU-NO make) connected to COM2 is lowering. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.
30001,6	015	<b>Name:</b> Sub Monitor Fan2 Rotation Speed Lowering <b>Meaning:</b> The rotation speed of the No. 2 fan in the sub monitor (FURU-NO make) connected to COM2 is lowering. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.
30001,7	016	<b>Name:</b> Sub Monitor Fan3 Rotation Speed Lowering <b>Meaning:</b> The rotation speed of the No. 3 fan in the sub monitor (FURU-NO make) connected to COM2 is lowering. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.
30001,8	017	<b>Name:</b> Sub Monitor Fan4 Rotation Speed Lowering <b>Meaning:</b> The rotation speed of the No. 4 fan in the sub monitor (FURU-NO make) connected to COM2 is lowering. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.
30001,9	011	<b>Name:</b> Main Monitor RS485 Communication Timeout <b>Meaning:</b> RS485 communication error between the display (main monitor) connected to COM1 and EC-3000/3005 has occurred for 180 seconds or more (sentence error or checksum error). <b>Remedy:</b> Check the brilliance control cable. If the cable is damaged, replace it.
30001,10	024	<b>Name:</b> Sub Monitor RS485 Communication Timeout <b>Meaning:</b> RS485 communication error between the display (sub monitor) connected to COM2 and EC-3000/3005 has occurred for 180 seconds or more (sentence error or checksum error). <b>Remedy:</b> Check the brilliance control cable. If the cable is damaged, replace it.
30001,11	012	<b>Name:</b> Main Monitor No Signal <b>Meaning:</b> No video signal has been input for 60 seconds or more from the display (main monitor) connected to COM1. <b>Remedy:</b> Check the video signal cable. If the cable is damaged, replace it.
30001,12	025	<b>Name:</b> Sub Monitor No Signal <b>Meaning:</b> No video signal has been input for 60 seconds or more from the display (sub monitor) connected to COM2. <b>Remedy:</b> Check the video signal cable. If the cable is damaged, replace it.
30001,13	013	<b>Name:</b> Main Monitor Sentence Syntax Error <b>Meaning:</b> There is a syntax error in the sentence input from the display (main monitor) connected to COM1. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.
30001,14	026	<b>Name:</b> Sub Monitor Sentence Syntax Error <b>Meaning:</b> There is a syntax error in the sentence input from the display (sub monitor) connected to COM2. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.

Alert No.	ALF ID	ALR ID	Alert Name, Meaning and Remedy
30001,15		027	<b>Name:</b> Main Monitor COM Timeout <b>Meaning:</b> The connection with the display (main monitor) connected to COM1 has been lost for 60 seconds or more. <b>Remedy:</b> Check the connection with the display unit.
30001,16		028	<b>Name:</b> Sub Monitor COM Timeout <b>Meaning:</b> The connection with the display (sub monitor) connected to COM2 has been lost for 60 seconds or more. <b>Remedy:</b> Check the connection with the display unit.
30001,17		073	<b>Name:</b> Processor Unit CPU Temp High <b>Meaning:</b> The temperature of the CPU in the processor unit is rising. <b>Remedy:</b> Turn off the processor unit. Wait several minutes, then turn on the power. If the message appears, contact a FURUNO agent or dealer to request service.
30001,18		074	<b>Name:</b> Processor Unit GPU Temp High <b>Meaning:</b> The temperature of the GPU in the processor unit is rising. <b>Remedy:</b> Turn off the processor unit. Wait several minutes, then turn on the power. If the message appears, contact a FURUNO agent or dealer to request service.
30001,19		075	<b>Name:</b> Processor Unit CPU Board Temp High <b>Meaning:</b> The temperature of the CPU board in the processor unit is rising. <b>Remedy:</b> Turn off the processor unit. Wait several minutes, then turn on the power. If the message appears, contact a FURUNO agent or dealer to request service.
30001,20		076	<b>Name:</b> Processor Unit Remote1 Temp High <b>Meaning:</b> The temperature of the CPU in the processor unit is rising. <b>Remedy:</b> Turn off the processor unit. Wait several minutes, then turn on the power. If the message appears, contact a FURUNO agent or dealer to request service.
30001,21		077	<b>Name:</b> Processor Unit Remote2 Temp High <b>Meaning:</b> The temperature of the CPU in the processor unit is rising. <b>Remedy:</b> Turn off the processor unit. Wait several minutes, then turn on the power. If the message appears, contact a FURUNO agent or dealer to request service.
30001,22		078	<b>Name:</b> Processor Unit CPU Fan Rotation Speed Lowering <b>Meaning:</b> The rotation speed of the CPU fan in the processor unit is lowering. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.
30001,23		079	<b>Name:</b> Processor Unit Fan1 Rotation Speed Lowering <b>Meaning:</b> The rotation speed of the No. 1 fan in the processor unit is lowering. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.
30001,24		080	<b>Name:</b> Processor Unit Fan2 Rotation Speed Lowering <b>Meaning:</b> The rotation speed of the No. 2 fan in the processor unit is lowering. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.
30001,25		081	<b>Name:</b> Processor Unit Fan3 Rotation Speed Lowering <b>Meaning:</b> The rotation speed of the No. 3 fan in the processor unit is lowering. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.

Alert No.	ALF ID	ALR ID	Alert Name, Meaning and Remedy
30001,26	089	Name: Processor Unit CPU board Battery Power Error <b>Meaning:</b> CPU board battery voltage in processor unit is out of threshold. <b>Remedy:</b> Turn off the processor unit. Wait several minutes, then turn on the power. If the message appears, contact a FURUNO agent or dealer to request service.	
30001,27	090	<b>Name:</b> Processor Unit CPU board Core Power Error <b>Meaning:</b> CPU board core voltage error has occurred. <b>Remedy:</b> Turn off the processor unit. Wait several minutes, then turn on the power. If the message appears, contact a FURUNO agent or dealer to request service.	
30001,28	070	<b>Name:</b> RCU 1 COM Timeout <b>Meaning:</b> Communication error with No. 1 control unit has occurred for 40 seconds or more. <b>Remedy:</b> Check the connection with the control unit.	
30001,29	071	<b>Name:</b> RCU 2 COM Timeout <b>Meaning:</b> Communication error with No. 2 control unit has occurred for 40 seconds or more. <b>Remedy:</b> Check the connection with the control unit.	
30001,30	072	<b>Name:</b> RCU 3 COM Timeout <b>Meaning:</b> Communication error with No. 3 control unit has occurred for 40 seconds or more.	
30001,31	400	<b>Name:</b> Network Printer Not Available <b>Meaning:</b> The network printer cannot be detected. There may be a connection error or an error (out of paper, jam, out of ink, etc.) on the printer side. <b>Remedy:</b> Make sure the printer is connected to the network. Make sure that no errors (out of paper, jam, out of ink, etc.) have occurred on the printer side.	
30001,32	401	<b>Name:</b> Local Printer Not Available <b>Meaning:</b> The local printer cannot be detected. There may be a connection error or an error (out of paper, jam, out of ink, etc.) on the printer side. <b>Remedy:</b> Make sure the printer is connected to the network. Make sure that no errors (out of paper, jam, out of ink, etc.) have occurred on the printer side.	
30002,3	006	<b>Name:</b> Main Monitor High Temperature Inside Monitor <b>Meaning:</b> The internal temperature of the display (main monitor) connected to COM1 is rising. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer and report the frequency of occurrence.	
30002,4	019	<b>Name:</b> Sub Monitor High Temperature Inside Monitor <b>Meaning:</b> The internal temperature of the display (sub monitor) connected to COM2 is rising. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer and report the frequency of occurrence.	
30002,5	007	<b>Name:</b> Main Monitor Fan1 No Rotation <b>Meaning:</b> The No. 1 fan of the main monitor (FURUNO make) connected to COM1 has stopped rotating. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.	

Alert No.	ALF ID	ALR ID	Alert Name, Meaning and Remedy
30002,6	008	<b>Name:</b> Main Monitor Fan2 No Rotation <b>Meaning:</b> The No. 2 fan of the main monitor (FURUNO make) connected to COM1 has stopped rotating. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.	
30002,7	009	<b>Name:</b> Main Monitor Fan3 No Rotation <b>Meaning:</b> The No. 3 fan of the main monitor (FURUNO make) connected to COM1 has stopped rotating. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.	
30002,8	010	<b>Name:</b> Main Monitor Fan4 No Rotation <b>Meaning:</b> The No. 4 fan of the main monitor (FURUNO make) connected to COM1 has stopped rotating. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.	
30002,9	020	<b>Name:</b> Sub Monitor Fan1 No Rotation <b>Meaning:</b> The No. 1 fan of the sub monitor (FURUNO make) connected to COM2 has stopped rotating. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.	
30002,10	021	<b>Name:</b> Sub Monitor Fan2 No Rotation <b>Meaning:</b> The No. 2 fan of the sub monitor (FURUNO make) connected to COM2 has stopped rotating. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.	
30002,11	022	<b>Name:</b> Sub Monitor Fan3 No Rotation <b>Meaning:</b> The No. 3 fan of the sub monitor (FURUNO make) connected to COM2 has stopped rotating. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.	
30002,12	023	<b>Name:</b> Sub Monitor Fan4 No Rotation <b>Meaning:</b> The No. 4 fan of the sub monitor (FURUNO make) connected to COM2 has stopped rotating. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.	
30002,13	082	<b>Name:</b> Processor Unit CPU Fan No Rotation <b>Meaning:</b> The CPU fan in the processor unit has stopped rotating. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.	
30002,14	083	<b>Name:</b> Processor Unit Fan1 No Rotation <b>Meaning:</b> The No. 1 fan in the processor unit has stopped rotating. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.	
30002,15	084	<b>Name:</b> Processor Unit Fan2 No Rotation <b>Meaning:</b> The No. 2 fan in the processor unit has stopped rotating. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.	
30002,16	085	<b>Name:</b> Processor Unit Fan3 No Rotation <b>Meaning:</b> The No. 3 fan in the processor unit has stopped rotating. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer about replacement of the fan.	

Alert No.	ALF ID	ALR ID	Alert Name, Meaning and Remedy		
30002,17	086		<b>Name:</b> Processor Unit CPU board 5V Power Error <b>Meaning:</b> Voltage error (5V) on the CPU board. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer and report the frequency of occurrence.	<b>Name:</b> NAVTEX Message Received	<b>Meaning:</b> Navtex message has been received. <b>Remedy:</b> Check the content of the message.
30002,18	087		<b>Name:</b> Processor Unit CPU board 3.3V Power Error <b>Meaning:</b> Voltage error (3.3V) on the CPU board. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer and report the frequency of occurrence.	<b>Name:</b> ALR ID	<b>Meaning:</b> Alert ID
30002,19	088		<b>Name:</b> Processor Unit CPU board 12V Power Error <b>Meaning:</b> Voltage error (12V) on the CPU board. <b>Remedy:</b> If this occurs frequently, contact a FURUNO agent or dealer and report the frequency of occurrence.	30807,-	820
30050,1	320		<b>Name:</b> Lost CH1 COM <b>Meaning:</b> Communication with the EC-3000/3005 serial port CH1 has been interrupted for more than the time set at installation (default setting: no timeout). <b>Remedy:</b> Check the serial port.	<b>Name:</b> NAVTEX Message Received	<b>Meaning:</b> Check the content of the message.
30050,2	321		<b>Name:</b> Lost CH2 COM <b>Meaning:</b> Communication with the EC-3000/3005 serial port CH2 has been interrupted for more than the time set at installation (default setting: no timeout). <b>Remedy:</b> Check the serial port.	<b>Name:</b> ALR ID	<b>Meaning:</b> Alert ID
30050,3	322		<b>Name:</b> Lost CH3 COM <b>Meaning:</b> Communication with the EC-3000/3005 serial port CH3 has been interrupted for more than the time set at installation (default setting: no timeout). <b>Remedy:</b> Check the serial port.	30807,-	820
30050,4	323		<b>Name:</b> Lost CH4 COM <b>Meaning:</b> Communication with the EC-3000/3005 serial port CH4 has been interrupted for more than the time set at installation (default setting: no timeout). <b>Remedy:</b> Check the serial port.	<b>Name:</b> NAVTEX Message Received	<b>Meaning:</b> Check the content of the message.
30050,5	324		<b>Name:</b> Lost CH5 COM <b>Meaning:</b> Communication with the EC-3000/3005 serial port CH5 has been interrupted for more than the time set at installation (default setting: no timeout). <b>Remedy:</b> Check the serial port.	<b>Name:</b> ALR ID	<b>Meaning:</b> Alert ID
30050,6	325		<b>Name:</b> Lost CH6 COM <b>Meaning:</b> Communication with the EC-3000/3005 serial port CH6 has been interrupted for more than the time set at installation (default setting: no timeout). <b>Remedy:</b> Check the serial port.	30807,-	820
30050,7	326		<b>Name:</b> Lost CH7 COM <b>Meaning:</b> Communication with the EC-3000/3005 serial port CH7 has been interrupted for more than the time set at installation (default setting: no timeout). <b>Remedy:</b> Check the serial port.	<b>Name:</b> NAVTEX Message Received	<b>Meaning:</b> Check the content of the message.
30050,8	327		<b>Name:</b> Lost CH8 COM <b>Meaning:</b> Communication with the EC-3000/3005 serial port CH8 has been interrupted for more than the time set at installation (default setting: no timeout). <b>Remedy:</b> Check the serial port.	<b>Name:</b> ALR ID	<b>Meaning:</b> Alert ID

## PACKING LIST

EC-3005-6MEA\*, -6MEB\*, -6MEC\*, -6MET\*, -6MRA\*, -6MRB\*, -6MRC\*, -6MRT\*

24AU-X-9851-2

1/1

NAME	OUTLINE	DESCRIPTION/CODE No.	Q' TY
<b>ユニット UNIT</b>			
制御部 PROCESSOR		EC-3005-* 000-039-268-00 **	1
<b>予備品 SPARE PARTS</b>			
予備品 SPARE PARTS		SP24-00601 001-170-660-00	1
<b>付属品 ACCESSORIES</b>			
付属品 ACCESSORIES		FP24-01401 001-628-840-00	1

## 工事材料 INSTALLATION MATERIALS

NAME	OUTLINE	DESCRIPTION/CODE No.	Q' TY
<b>工事材料 INSTALLATION MATERIALS</b>			
工事材料 INSTALLATION MATERIALS		CP24-02101 001-170-630-00	1
<b>電源ケーブル AC CABLE</b>			
AC CABLE		IEC60320-C13-L5M 000-176-423-11	1
<b>ケーブル(クミヒン) CABLE ASSEMBLY</b>			
CABLE ASSEMBLY		DSUB9P-X2-L5M 000-176-663-11	1
<b>ケーブル(クミヒン) CABLE ASSEMBLY</b>			
CABLE ASSEMBLY		DSUB9P-X2-L5M 000-176-663-11	2

コード番号末尾の[\*\*]は、選択品の代表コードを表します。

CODE NUMBER ENDING WITH “\*\*” INDICATES THE CODE NUMBER OF REPRESENTATIVE MATERIAL.

(※)は、ダミーコードに付き、注文できません。

(※) THIS CODE CANNOT BE ORDERED.

(略図の寸法は、参考値です。DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

NAME	OUTLINE	DESCRIPTION/CODE No.	Q' TY
<b>図書 DOCUMENT</b>			
ドングルインフォメーションシート DONGLE INFORMATION SHEET		210 297 999-999-085-0*	1 (*)
<b>取扱説明CD OPERATOR'S MANUAL CD</b>			
OPERATOR'S MANUAL CD		φ 120 FMD3X00 O/M *CDROM* 000-194-779-1*	1
<b>操作要領書 OPERATOR'S GUIDE</b>			
OPERATOR'S GUIDE		210 297 OS*-44730-* 000-176-127-1*	1
<b>装備設定要領 INSTRUCTION MANUAL</b>			
INSTRUCTION MANUAL		210 297 *42-01204-* 000-194-858-1*	1
<b>装備要領書 INSTALLAION MANUAL</b>			
INSTALLAION MANUAL		210 297 IM*-44730-* 000-195-306-1*	1

(※)印は、仕様により選択。

(※1): CHOOSE ONE DEPENDING ON THE SPECIFICATION.

A-1

C4522-Z01-C

## PACKING LIST

EC-3005-6ME\*-V, -6MR\*-V, -6ME\*-HKV, -6MR\*-HKV,

24AU-X-9852-2

1/1

NAME	OUTLINE	DESCRIPTION/CODE No.	Q' TY
<b>ユニット UNIT</b>			
制御部 PROCESSOR		EC-3005-* 000-039-268-00 **	1
<b>付属品 ACCESSORIES</b>			
付属品 ACCESSORIES		FP24-01401 001-628-840-00	1
<b>工事材料 INSTALLATION MATERIALS</b>			
工事材料 INSTALLATION MATERIALS		CP24-02101 001-170-630-00	1
<b>電源ケーブル AC CABLE</b>			
AC CABLE		IEC60320-C13-L5M 000-176-423-11	1
<b>ケーブル(クミヒン) CABLE ASSEMBLY</b>			
CABLE ASSEMBLY		DSUB9P-X2-L5M 000-176-663-11	1
<b>ケーブル(クミヒン) CABLE ASSEMBLY</b>			
CABLE ASSEMBLY		DSUB9P-X2-L5M 000-176-663-11	2
<b>図書 DOCUMENT</b>			
ドングルインフォメーションシート DONGLE INFORMATION SHEET		210 297 999-999-085-0*	1 (*)

コード番号末尾の[\*\*]は、選択品の代表コードを表します。

CODE NUMBER ENDING WITH “\*\*” INDICATES THE CODE NUMBER OF REPRESENTATIVE MATERIAL.

(※)は、ダミーコードに付き、注文できません。

(※) THIS CODE CANNOT BE ORDERED.

(略図の寸法は、参考値です。DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

NAME	OUTLINE	DESCRIPTION/CODE No.	Q' TY
<b>取扱説明CD OPERATOR'S MANUAL CD</b>			
OPERATOR'S MANUAL CD		φ 120 FMD3X00 O/M *CDROM* 000-194-779-1*	1
<b>操作要領書 OPERATOR'S GUIDE</b>			
OPERATOR'S GUIDE		210 297 OS*-44730-* 000-176-127-1*	1
<b>装備設定要領 INSTRUCTION MANUAL</b>			
INSTRUCTION MANUAL		210 297 *42-01204-* 000-194-858-1*	1
<b>装備要領書 INSTALLAION MANUAL</b>			
INSTALLAION MANUAL		210 297 IM*-44730-* 000-195-306-1*	1

(※)印は、仕様により選択。

(※1): CHOOSE ONE DEPENDING ON THE SPECIFICATION.

A-2

C4522-Z02-C

## PACKING LIST

EC-3005-7MEA\*, -7MEB\*, -7MEC\*, -7MET\*, -7MRA\*, -7MRB\*, -7MRC\*, -7MRT\*

24AU-X-9853-2

1/1

NAME	OUTLINE	DESCRIPTION/CODE No.	Q' TY
<b>ユニット UNIT</b>			
制御部 PROCESSOR		EC-3005-* 000-039-268-00 **	1
<b>予備品 SPARE PARTS</b>			
予備品 SPARE PARTS		SP24-00602 001-170-670-00	1
<b>付属品 ACCESSORIES</b>			
付属品 ACCESSORIES		FP24-01401 001-628-840-00	1

## 工事材料 INSTALLATION MATERIALS

NAME	OUTLINE	DESCRIPTION/CODE No.	Q' TY
<b>工事材料 INSTALLATION MATERIALS</b>			
工事材料 INSTALLATION MATERIALS		CP24-02101 001-170-630-00	1
<b>電源ケーブル AC CABLE</b>			
AC CABLE		IEC60320-C13-L5M L=5M 000-176-423-11	1
<b>ケーブル(クミヒン) CABLE ASSEMBLY</b>			
CABLE ASSEMBLY		DSUB9P-X2-L5M L=5M 000-176-663-11	1 (*1)
<b>ケーブル(クミヒン) CABLE ASSEMBLY</b>			
CABLE ASSEMBLY		DSUB9P-X2-L5M L=5M 000-176-663-11	2 (*1)

コード番号末尾の[\*\*]は、選択品の代表コードを表します。

CODE NUMBER ENDING WITH “\*\*” INDICATES THE CODE NUMBER OF REPRESENTATIVE MATERIAL.

(※)は、ダミーコードに付き、注文できません。

(※) THIS CODE CANNOT BE ORDERED.

(略図の寸法は、参考値です。DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

NAME	OUTLINE	DESCRIPTION/CODE No.	Q' TY
<b>図書 DOCUMENT</b>			
ドングルインフォメーションシート DONGLE INFORMATION SHEET		210 (width) 297 (height)	1 (*)
<b>取扱説明CD OPERATOR'S MANUAL CD</b>			
OPERATOR'S MANUAL CD		φ 120 (diameter)	1
<b>操作要領書 OPERATOR'S GUIDE</b>			
OPERATOR'S GUIDE		210 (width) 297 (height)	1
<b>装備設定要領 INSTRUCTION MANUAL</b>			
INSTRUCTION MANUAL		210 (width) 297 (height)	1
<b>装備要領書 INSTALLAION MANUAL</b>			
INSTALLAION MANUAL		210 (width) 297 (height)	1

コード番号末尾の[\*\*]は、選択品の代表コードを表します。

(※1)印は、仕様により選択。

(※1): CHOOSE ONE DEPENDING ON THE SPECIFICATION.

A-3

C4522-Z03-C

## PACKING LIST

EC-3005-7ME\*-V, -7MR\*-V, -7ME\*-HKV, -7MR\*-HKV

24AU-X-9854-2 1/1

NAME	OUTLINE	DESCRIPTION/CODE No.	Q' TY
<b>ユニット UNIT</b>			
制御部 PROCESSOR		EC-3005-* 000-039-268-00 **	1
<b>付属品 ACCESSORIES</b>			
付属品 ACCESSORIES		FP24-01401 001-628-840-00	1

## 工事材料 INSTALLATION MATERIALS

NAME	OUTLINE	DESCRIPTION/CODE No.	Q' TY
<b>工事材料 INSTALLATION MATERIALS</b>			
工事材料 INSTALLATION MATERIALS		CP24-02101 001-170-630-00	1
<b>電源ケーブル AC CABLE</b>			
AC CABLE		IEC60320-C13-L5M L=5M 000-176-423-11	1
<b>ケーブル(クミヒン) CABLE ASSEMBLY</b>			
CABLE ASSEMBLY		DSUB9P-X2-L5M L=5M 000-176-663-11	1 (*1)
<b>ケーブル(クミヒン) CABLE ASSEMBLY</b>			
CABLE ASSEMBLY		DSUB9P-X2-L5M L=5M 000-176-663-11	2 (*1)

## 図書 DOCUMENT

NAME	OUTLINE	DESCRIPTION/CODE No.	Q' TY
<b>ドングルインフォメーションシート DONGLE INFORMATION SHEET</b>			
ドングルインフォメーションシート DONGLE INFORMATION SHEET		210 (width) 297 (height)	1 (*)

コード番号末尾の[\*\*]は、選択品の代表コードを表します。

CODE NUMBER ENDING WITH “\*\*” INDICATES THE CODE NUMBER OF REPRESENTATIVE MATERIAL.

(※)は、ダミーコードに付き、注文できません。

(※) THIS CODE CANNOT BE ORDERED.

(略図の寸法は、参考値です。DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

C4522-Z04-C

A-4

**PACKING LIST** EC-3000-2xx9\*, EC-3000-27\*/32\*/33\*, EC-3000-T-27\*/32\*/33\*, EC-3000-R27\*/32\*/33\*

24AL-X-9851-15 1/2

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
<b>ユニット UNIT</b>			
制御部 PROCESSOR UNIT		EC-3000-* 000-020-737-00	1 **

予備品 SPARE PARTS	OUTLINE	DESCRIPTION/CODE No.	Q'TY
SPARE PARTS		SP24-00601 001-170-660-00	1 (*1)
SPARE PARTS		SP24-00602 001-170-670-00	1 (*1)

付属品 ACCESSORIES	OUTLINE	DESCRIPTION/CODE No.	Q'TY
ACCESSORIES		FP24-00601 001-170-630-00	1 (*2)
ACCESSORIES		FP24-00602 001-259-570-00	1 (*7)
ACCESSORIES		FP24-00603 001-285-760-00	1 (*7)
ACCESSORIES		FP24-00605 001-501-070-00	1 (*2)
ACCESSORIES		FP24-00607 001-623-580-00	1 (*8)
ACCESSORIES		FP24-00608 001-624-400-00	1 (*8)

工事材料 INSTALLATION MATERIALS	OUTLINE	DESCRIPTION/CODE No.	Q'TY
CABLE ASSEMBLY		DSUB9P-X2-L5M L=5M	1 000-170-663-11

1.コード番号末尾の[\*\*]は、選択品の代表コードを表します。

- 1.CODE NUMBER ENDING WITH “\*\*” INDICATES THE CODE NUMBER OF REPRESENTATIVE MATERIAL.  
2.(\*)\*(2)\*(3)\*(4)\*(5)\*(6)\*(7)\*(8)は、それぞれ仕様選択品を表します。  
2.(\*)\*(2)\*(3)\*(4)\*(5)\*(6)\*(7)\*(8) INDICATE SPECIFICATION SELECTIVE ITEM.

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
工事材料 INSTALLATION MATERIALS		CP24-02101 001-170-630-00	1
電源ケーブル AC CABLE		IEC60320-C13-15M L=5M	1 000-170-423-11

図書 DOCUMENT	OUTLINE	DESCRIPTION/CODE No.	Q'TY
ドングルインフォメーションシート DONGLE INFORMATION SHEET		999-999-085-0*	1 (*)
取扱説明CD OPERATOR'S MANUAL CD		CD3X00 O/M *CD-ROM* 000-194-491-1*	1 (*3)
取扱説明CD OPERATOR'S MANUAL CD		FAR3XX0 O/M *CD-ROM* 000-197-278-1*	1 (*3)
取扱説明CD OPERATOR'S MANUAL CD		FOR2XX9 O/M *CD-ROM* 000-176-722-1*	1 (*3)
取扱説明CD OPERATOR'S MANUAL CD		FMD310X O/M *CD-ROM* 000-199-426-1*	1 (*3)
取扱説明CD OPERATOR'S MANUAL CD		FMD3X00 O/M *CD-ROM* 000-194-779-1*	1 (*3)
取扱説明CD OPERATOR'S MANUAL CD		FMD3X00 O/M *CD-ROM* 000-199-426-1*	1 (*3)
取扱説明CD OPERATOR'S MANUAL CD		FMD3X00 O/M *CD-ROM* 000-194-856-1*	1 (*3)
操作要領書 OPERATOR'S GUIDE		OS*-36160-* 000-178-029-1*	1 (**4)
操作要領書 OPERATOR'S GUIDE		OS*-36162-* 000-199-361-1*	1 (**4)

3.(\*)は、ダミーコードに付き、注文できません。

3. (\*) THIS CODE CANNOT BE ORDERED.

4.(\*)\*(8) :仕様により選択。HKまたは和文(-J)は(\*)、それ以外は(\*)になります。

4.(\*)\*(8) : SELECT ONE ACCORDING TO SPECIFICATIONS : (\*) FOR -HK OR -J, (\*) FOR OTHERS.

A-5

C4473-Z01-R(1)

**PACKING LIST** EC-3000-2xx9\*, EC-3000-27\*/32\*/33\*, EC-3000-T-27\*/32\*/33\*, EC-3000-R27\*/32\*/33\*

24AL-X-9851-15 2/2

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
操作要領書 OPERATOR'S GUIDE		OS*-44730-* 000-176-127-1*	1 (**4)
操作要領書 OPERATOR'S GUIDE		OS*-44732-* 000-199-417-1*	1 (**4)
操作要領書 OPERATOR'S GUIDE		OSE-36040-* 000-176-133-1*	1 (**4)
操作要領書(和) OPERATOR'S GUIDE (JP)		OSJ-45010-* 000-194-447-1*	1 (**4)
装備設定要領 INSTRUCTION MANUAL		*42-01204-* 000-194-859-1*	1 (*6)
装備設定要領 INSTRUCTION MANUAL		*42-02113-* 000-199-377-1*	1 (*6)
装備設定要領 INSTRUCTION MANUAL		J42-01711-* 000-194-452-1*	1 (*6)
装備設定要領書 INSTRUCTION MANUAL		*32-01305-* 000-198-109-1*	1 (*6)
装備設定要領書 INSTRUCTION MANUAL		J42-02115-* 000-199-380-1*	1 (*6)
装備要領書 INSTALLATION MANUAL		IM*-36160-* 000-196-985-1*	1 (*5)
装備要領書 INSTALLATION MANUAL		IM*-36162-* 000-199-359-1*	1 (*5)
装備要領書 INSTALLATION MANUAL		IM*-44730-* 000-195-306-1*	1 (*5)

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
装備要領書 INSTALLATION MANUAL		IM*-44732-* 000-199-419-1*	1 (*5)
装備要領書 INSTALLATION MANUAL		IME-36040-* 000-176-135-1*	1 (*5)
装備要領書 INSTALLATION MANUAL		IME-36060-* 000-176-137-1*	1 (*5)
装備要領書 INSTALLATION MANUAL		IME-36100-* 000-176-139-1*	1 (*5)
装備要領書(和) INSTALLATION MANUAL (JP)		IMJ-45010-* 000-194-450-1*	1 (*5)

1.コード番号末尾の[\*\*]は、選択品の代表コードを表します。

- 1.CODE NUMBER ENDING WITH “\*\*” INDICATES THE CODE NUMBER OF REPRESENTATIVE MATERIAL.  
2.(\*)\*(2)\*(3)\*(4)\*(5)\*(6)\*(7)\*(8)は、それぞれ仕様選択品を表します。  
2.(\*)\*(2)\*(3)\*(4)\*(5)\*(6)\*(7)\*(8) INDICATE SPECIFICATION SELECTIVE ITEM.

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

A-6

C4473-Z01-R(2)

# PACKING LIST EC-3000\*V EC-3000-27\*V/32\*V/33\*V , EC-3000-T-27\*V/32\*V/33\*V EC-3000-R27/32/33-\*V

24AL-X-9866-16 1/2

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
<b>ユニット UNIT</b>			
制御部 PROCESSOR UNIT		EC-3000-* 000-020-737-00	1 **
<b>付属品 ACCESSORIES</b>			
付属品 ACCESSORIES		FP24-00601 001-170-660-00	1 (*1)
付属品 ACCESSORIES		FP24-00602 001-258-570-00	1 (*6)
付属品 ACCESSORIES		FP24-00603 001-285-760-00	1 (*6)
付属品 ACCESSORIES		FP24-00605 001-501-070-00	1 (*1)
付属品 ACCESSORIES		FP24-01501 *BELUGA* 001-647-160-00	1 (*7)
付属品 ACCESSORIES		FP24-01502 *BELUGA* 001-647-210-00	1 (*7)
<b>工事材料 INSTALLATION MATERIALS</b>			
ケーブル(クミン) CABLE ASSEMBLY		DSub9P-X2-L5M 000-176-663-11	1
工事材料 INSTALLATION MATERIALS		GP24-02101 001-170-630-00	1
電源ケーブル AC CABLE		IEC60320-C13-L5M 000-176-423-11	1
<b>図書 DOCUMENT</b>			
ドングルインフォメーションシート DONGLE INFORMATION SHEET		----- 999-999-085-0*	1 (*)

1.コード番号末尾の[\*\*]は、選択品の代表コードを表します。

1.CODE NUMBER ENDING WITH “\*\*” INDICATES THE CODE NUMBER OF REPRESENTATIVE MATERIAL.  
2.(\*):(\*):(\*):(\*):(\*):(\*):(\*)は、それぞれ仕様選択品を表します。  
2.(\*):(\*):(\*):(\*):(\*):(\*):(\*) INDICATE SPECIFICATION SELECTIVE ITEM.

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
取扱説明CD OPERATOR'S MANUAL CD		CD3X00 O/M *CDROM* 000-194-491-1*	1 (*2)
取扱説明CD OPERATOR'S MANUAL CD		FAR3XX0 O/M *CD-ROM* 000-197-278-1*	1 (*2)
取扱説明CD OPERATOR'S MANUAL CD		FGR2XX9 O/M *CDROM* 000-176-722-1*	1 (*2)
取扱説明CD OPERATOR'S MANUAL CD		FMD3X00 O/M *CD-ROM* 000-199-428-1*	1 (*2)
取扱説明CD OPERATOR'S MANUAL CD		FMD3X00 O/M *CDROM* 000-194-426-1*	1 (*2)
操作要領書 OPERATOR'S GUIDE		----- 05*-36160-* 000-178-029-1*	1 (**3)
操作要領書 OPERATOR'S GUIDE		----- 05*-36162-* 000-199-361-1*	1 (**3)
操作要領書 OPERATOR'S GUIDE		----- 05*-44730-* 000-176-127-1*	1 (**3)
操作要領書 OPERATOR'S GUIDE		----- 05*-44732-* 000-199-417-1*	1 (**3)
操作要領書 OPERATOR'S GUIDE		----- 05F-36040-* 000-176-133-1*	1 (**3)

A-7

3.(\*)は、ダミーコードに付き、注文できません。

3.(\*) THIS CODE CANNOT BE ORDERED.

4.(\*):(\*):(\*):(\*):(\*):(\*):(\*)は、仕様により選択。-HKまたは和文(-J)は(\*)、それ以外は(\*)になります。

4.(\*):(\*):(\*):(\*):(\*):(\*):(\*) : SELECT ONE ACCORDING TO SPECIFICATIONS : (\*) FOR -HK OR -J, (\*) FOR OTHERS.

C4473-Z13-S(1)

# PACKING LIST EC-3000\*V EC-3000-27\*V/32\*V/33\*V , EC-3000-T-27\*V/32\*V/33\*V EC-3000-R27/32/33-\*V

24AL-X-9866-16 2/2

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
操作要領書(和) OPERATOR'S GUIDE (JP)		OSJ-45010-* 000-194-447-1*	1 (*3)
装備設定要領 INSTRUCTION MANUAL		*42-01204-* 000-194-859-1*	1 (**5)
装備設定要領 INSTRUCTION MANUAL		*42-02113-* 000-199-377-1*	1 (**5)
装備設定要領 INSTRUCTION MANUAL		J42-01711-* 000-194-452-1*	1 (**5)
装備設定要領書 INSTRUCTION MANUAL		*32-01305-* 000-198-109-1*	1 (**5)
装備設定要領書 INSTRUCTION MANUAL		J42-02115-* 000-199-380-1*	1 (**5)
装備要領書 INSTALLATION MANUAL		IM*-36160-* 000-196-085-1*	1 (**4)
装備要領書 INSTALLATION MANUAL		IM*-36162-* 000-199-359-1*	1 (**4)
装備要領書 INSTALLATION MANUAL		IM*-44730-* 000-195-306-1*	1 (**4)
装備要領書 INSTALLATION MANUAL		IM*-44732-* 000-199-419-1*	1 (**4)
装備要領書 INSTALLATION MANUAL		IM*-36040-* 000-176-135-1*	1 (**4)
装備要領書 INSTALLATION MANUAL		IM*-36060-* 000-176-137-1*	1 (**4)

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
装備要領書 INSTALLATION MANUAL		IME-36100-* 000-176-139-1*	1 (*4)
装備要領書(和) INSTALLATION MANUAL (JP)		IMJ-45010-* 000-194-450-1*	1 (*4)

A-8

1.コード番号末尾の[\*\*]は、選択品の代表コードを表します。

1.CODE NUMBER ENDING WITH “\*\*” INDICATES THE CODE NUMBER OF REPRESENTATIVE MATERIAL.  
2.(\*):(\*):(\*):(\*):(\*):(\*):(\*)は、それぞれ仕様選択品を表します。  
2.(\*):(\*):(\*):(\*):(\*):(\*):(\*) INDICATE SPECIFICATION SELECTIVE ITEM.

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

3.(\*)は、ダミーコードに付き、注文できません。

3.(\*) THIS CODE CANNOT BE ORDERED.

4.(\*):(\*):(\*):(\*):(\*):(\*):(\*)は、仕様により選択。-HKまたは和文(-J)は(\*)、それ以外は(\*)になります。

4.(\*):(\*):(\*):(\*):(\*):(\*):(\*) : SELECT ONE ACCORDING TO SPECIFICATIONS : (\*) FOR -HK OR -J, (\*) FOR OTHERS.

C4473-Z13-S(2)

## PACKING LIST

RCU-024B , RCU-024B-HK

24AL-X-9879 -2 1/1

A-9

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
ユニット UNIT			
ECDIS操作部		RCU-024B*	1
ECDIS CONTROL UNIT		000-037-640-00 **	
付属品 ACCESSORIES		FP24-00701	1
ACCESSORIES		001-418-340-00	
工事材料 INSTALLATION MATERIALS			
ケーブル(ケミカル)USB CABLE ASSEMBLY		TS-20-071-1 L=5000 000-176-700-11	1
工事材料 INSTALLATION MATERIALS		CP24-02201 001-418-330-00	1

コード番号末尾の[\*\*]は、選択品の代表コードを表します。  
CODE NUMBER ENDING WITH “\*\*” INDICATES THE CODE NUMBER OF REPRESENTATIVE MATERIAL.

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

CN  
C4473-231-C

## PACKING LIST

RCU-026/-HK

24AL-X-9881 -0 1/1

A-10

NAME	OUTLINE	DESCRIPTION/CODE No.	Q'TY
ユニット UNIT			
トラックボール操作部 TRACKBALL CONTROL UNIT		RCU-026/-HK 000-027-666-00 **	1
付属品 ACCESSORIES		FP24-00801	1
ACCESSORIES		001-418-410-00	
工事材料 INSTALLATION MATERIALS			
ケーブル(ケミカル)USB CABLE ASSEMBLY		TS-20-071-1 L=5000 000-176-700-11	1
工事材料 INSTALLATION MATERIALS		CP24-02301 001-418-400-00	1

コード番号末尾の[\*\*]は、選択品の代表コードを表します。  
CODE NUMBER ENDING WITH “\*\*” INDICATES THE CODE NUMBER OF REPRESENTATIVE MATERIAL.

型式/コード番号が2段の場合、下段より上段に代わる過渡期品であり、どちらかが入っています。なお、品質は変わりません。  
TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT.  
QUALITY IS THE SAME.

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

CN  
C4473-233-A

A-11

## FURUNO

CODE NO. 001-170-630-00  
TYPE CP24-02101 24AL-X-9401 -3  
1/1

工事材料表 INSTALLATION MATERIALS					
番号 NO.	名称 NAME	略図 OUTLINE	型名／規格 DESCRIPTIONS	数量 Q'TY	用途／備考 REMARKS
1	配線板1 WIRING PLATE 1		24-014-0104-2 CODE NO. 100-366-812-10	1	
2	筐体足1 CHASSIS BASE 1		24-014-0121-1 CODE NO. 100-367-721-10	1	
3	筐体足2 CHASSIS BASE 2		24-014-0122-1 CODE NO. 100-372-721-10	1	
4	配線板2組立品 WIRING PLATE 2 ASSY		CP24-02102 CODE NO. 100-186-200-00	1	
5	コバックス CABLE TIE		CV-100N CODE NO. 000-162-167-10	10	
6	コバックス CABLE TIE		CV-150N CODE NO. 000-162-186-10	30	
7	圧着端子 CRIMP-ON LUG		FVI-25-4 (LF) RED K CODE NO. 100-186-866-11	9	
8	+n インドコボジ BINDING HEAD SCREW		M03X SUS304 CODE NO. 100-182-664-10	5	
9	+n インドコボジ BINDING HEAD SCREW		M4X8 SUS304 CODE NO. 000-162-669-10	10	

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

FURUNO ELECTRIC CO., LTD.

C4473-M01-D

## FURUNO

CODE NO. 001-418-330-00  
TYPE CP24-02201 24AL-X-9408 -0  
1/1

工事材料表 INSTALLATION MATERIALS					
番号 NO.	名称 NAME	略図 OUTLINE	型名／規格 DESCRIPTIONS	数量 Q'TY	用途／備考 REMARKS
1	+ラスカビツクボジ SELF-TAPPING SCREW		SK20 SUS304 CODE NO. 000-162-608-10	2	
2	コバックス CABLE TIE		CV-125N CODE NO. 000-172-164-10	2	

型式/コード番号が2段の場合、下段より上段に代わる過渡期品であり、どちらかが入っています。なお、品質は変わりません。  
TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT.  
QUALITY IS THE SAME.

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

FURUNO ELECTRIC CO., LTD.

C4473-M08-A

**FURUNO**

CODE NO.	001-418-400-00	24AL-X-9409 -0
TYPE	FP24-02301	1/1

工事材料表 INSTALLATION MATERIALS					
番号 NO.	名 称 NAME	略 図 OUTLINE	型名／規格 DESCRIPTIONS	数量 Q'TY	用途／備考 REMARKS
1	ナットタッピングスクリュー SELF-TAPPING SCREW		M5X20 SUS304 CODE NO. 000-162-648-10	2	
2	コベーツ CABLE TIE		CF-125N CODE NO. 000-172-164-10	2	
3	ナットヘッドスクリュー WASHER HEAD SCREW #8*		M3X12 SUS304 CODE NO. 000-162-648-10	4	

盤式/コード番号が2段の場合、下段より上段に代わる通常商品であり、どちらかが入っています。なお、品質は変わりません。  
TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT.  
QUALITY IS THE SAME.

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

FURUNO ELECTRIC CO., LTD. CN  
C4473-M09-A

**FURUNO**

CODE NO.	001-628-840-00	24AU-X-9501 -0
TYPE	FP24-01401	1/1

付属品表 ACCESSORIES					
番号 NO.	名 称 NAME	略 図 OUTLINE	型名／規格 DESCRIPTIONS	数量 Q'TY	用途／備考 REMARKS
1	防塵スポンジ DUST-PROOF SPONGE		24-014-0105-1 CODE NO. 100-366-821-10	1	
2	DVD-R書き込み品 PROGRAM INSTALL SOFTWARE		2450163- CODE NO. 001-628-860-00	1	

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

FURUNO ELECTRIC CO., LTD.

C4522-F01-A

**FURUNO**

CODE NO.	001-623-580-00	24AL-X-9514 -1
TYPE	FP24-00607	1/1

付属品表 ACCESSORIES					
番号 NO.	名 称 NAME	略 図 OUTLINE	型名／規格 DESCRIPTIONS	数量 Q'TY	用途／備考 REMARKS
1	防塵スポンジ DUST-PROOF SPONGE		24-014-0105-1 CODE NO. 100-366-821-10	1	
2	DVD-R書き込み品 PROGRAM INSTALL SOFTWARE		2450110- CODE NO. 001-623-590-00	1	

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

FURUNO ELECTRIC CO., LTD. C4473-F13-B

**FURUNO**


CODE NO.	001-258-570-00	24AL-X-9509 -1
TYPE	FP24-00602	1/1

付属品表 ACCESSORIES					
番号 NO.	名 称 NAME	略 図 OUTLINE	型名／規格 DESCRIPTIONS	数量 Q'TY	用途／備考 REMARKS
1	防塵スポンジ DUST-PROOF SPONGE		24-014-0105-1 CODE NO. 100-366-821-10	1	
2	DVD-R書き込み品 PROGRAM INSTALL SOFTWARE		2450110- CODE NO. 001-258-580-00	1	

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

FURUNO ELECTRIC CO., LTD. C4473-F08-B





- NOTE
1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
  2. #: MINIMUM SERVICE CLEARANCE.
  3. USE M6 BOLTS OR COACH SCREWS Ø6 FOR FIXING THE UNIT.
  4. FACE THE DVD DRIVE TO RIGHT OR LEFT SIDE EITHER MOUNT THE FIXING PLATES (SUPPLIED) TO THE CHASSIS AS THE FIXING NOTCH FACES TO BOTTOM.

DRAWN	14/Mar/2022	T.YAMASAKI	NAME	EC-3000/3005
CHECKED	14/Mar/2022	H.MAKI	NAME	制御部 (壁掛装置)
APPROVED	10/Jan/2023	H.MAKI	NAME	外寸図
SCALE	1/8	WEIGHT 14 kg	NAME	PROCESSOR UNIT (BULKHEAD MOUNT)
DWG. NO.	C4473-501-E	REF. NO.	24-014-01G-3	OUTLINE DRAWING



通風口(排出)  
AIR OUTLET

表 1 TABLE 1

寸法区分 DIMENSION	公差 (mm) TOLERANCE
L ≤ 50	±1.5
50 < L ≤ 100	±2.5
100 < L ≤ 500	±3



CFAST ENTRY  
CFAST 取出口  
REAR VIEW (SCALE: 1/12)

## 注記

- 1) 指定外の寸法公差は表 1 による。
- 2) #印寸法は最小サービス空間寸法とする。
- 3) 取付用ネジはM6ボルトまたはコーキボルト呼び径6を使用のこと。

## NOTE

1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
2. # MINIMUM SERVICE CLEARANCE.
3. USE M6 BOLTS OR COACH SCREWS Ø6 FOR FIXING THE UNIT.

アース端子  
(GND TERMINAL)  
POWER SWITCH  
電源スイッチ  
SOURCE FUSE, MAIN SW  
電源スイッチ  
POWER SWITCH信号コネクタ  
SIGNAL CONNECTOR

DRAWN	14/Mar/2022	T.YAMASAKI	NAME	EC-3000/3005
CHECKED	14/Mar/2022	H.MAKI	名稱	制御部(卓上装備)
APPROVED	10/Jan/2023	H.MAKI	外寸図	
SCALE	1/8	WEIGHT 14 kg	NAME	PROCESSOR UNIT (TABLETOP MOUNT)
DWG.#	C4473-514-C	REF.#	24-014-0106-4	OUTLINE DRAWING







表1 TABLE 1

寸法区分 DIMENSION	(mm)	公差 (mm) TOLERANCE
$L \leq 50$		±1.5
$50 < L \leq 100$		±2.5
$100 < L \leq 500$		±3



注記

1) 指定外の寸法公差は表1による。

2) #印寸法は最小サービス空間寸法とする。

3) 取付ネジはセムスネジ B M4×12を使用のこと。  
壁の厚さ (A) は最小2mm、最大4mmとする。  
それ以外の場合は、M4×(A(壁の厚さ)+8±2mm)とする。

NOTE 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.

2. #. MINIMUM SERVICE CLEARANCE.

3. USE SEMS B SCREWS (M4x12) FOR BULKHEAD THICKNESS(A):2≤A≤4  
OR SCREW LENGTH: A+8±2.

DRAWN 6 Nov/2012 T.YAMASAKI  
CHECKED 6 Nov/2012 H.MAKI  
APPROVED / Nov/2012 Y.NISHIYAMA  
SAFETY 1/4 MASS 3.0 kg  
DWG No. C4473-602-B

DRAWN 6 Nov/2012 T.YAMASAKI  
CHECKED 6 Nov/2012 H.MAKI  
APPROVED / Nov/2012 Y.NISHIYAMA  
SAFETY 1/4 MASS 3.0 kg  
DWG No. C4473-602-B

NAMEPLATE  
NAME  
RCU-024  
ECDIS操作部 (卓上装備)  
外寸図  
NAME ECDIS CONTROL UNIT (TABLETOP MOUNT)  
REF. NO. 24-014-100G-2  
OUTLINE DRAWING

1






2

D-3  
FURUNO ELECTRIC CO., LTD.

電源・信号ケーブル (5 m)  
POWER/SIGNAL CABLE  
USBケーブル  
USB CABLE  
339

寸法区分 DIMENSION	(mm)	公差 (mm) TOLERANCE
$L \leq 50$		$\pm 1.5$
$50 < L \leq 100$		$\pm 2.5$
$100 < L \leq 500$		$\pm 3$

表1 TABLE 1




MAX. 72

38

55

180

4-% 水抜穴  
DRAIN HOLES



C

本体位置  
UNIT LOCATION  
取付穴寸法 (尺度 : 1 / 8)  
CUTOUT DIMENSIONS (SCALE: 1/8)

注記  
1) 指定外の寸法公差は表1による。

2) #印寸法は最小サービス空間寸法とする。

3) 壁の厚さ (A) は最小10mm、最大20mmとする。

NOTE 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.

2. MINIMUM SERVICE CLEARANCE.

3. BULKHEAD THICKNESS(A):  $10 \leq A \leq 20$

DRAWN	5/Nov/2012 T.YAMASAKI	TIME	RCU-024
CHECKED	5/Nov/2012 H.MAKI	名稱	ECDIS操作部(埋込装備)
APPROVED	/Nov/2012 Y.NISHIYAMA	外寸図	
SCALE	1/4	NAME	ECDIS CONTROL UNIT (FLUSH MOUNT)
DWG No.	C4473-603-B	REF No.	24-014-110C-2

CUTOUT DIMENSIONS (SCALE: 1/8)








表1 TABLE 1




寸法区分 DIMENSION	(mm)	公差 (mm) TOLERANCE
$L \leq 50$		±1.5
$50 < L \leq 100$		±2.5
$100 < L \leq 500$		±3



- 注記 1) 指定外の寸法公差は表1による。  
 2) #印寸法は最小サービス空間寸法とする。  
 3) 取付ネジはトラスタッピング呼び径 $5 \times 20$ を使用のこと。
- NOTE 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.  
 2. #. MINIMUM SERVICE CLEARANCE.  
 3. USE TAPPING SCREWS  $\varnothing 5 \times 20$  FOR FIXING THE UNIT.

DRAWN 5/Nov/2012 I.YAMASAKI	TIME RCU-024	名稱 ECDIS操作部(取付金具)
CHECKED 5/Nov/2012 H.MAKI		外寸図
APPROVED 7/Nov/2012 Y.NISHIYAMA	ECD-3200	NAME ECDIS CONTROL UNIT (Fixture Mount)
SCALE 1/4	MASS 3.3 kg	備考 ■は5STRケーブルを含む。 MASS INCLUDES 5 STR. CABLE.
DWG No. C4473-604-B	REF No. 24-014-120G-2	OUTLINE DRAWING

信号コネクタ  
SIGNAL CONNECTOR





1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.  
 2. # MINIMUM SERVICE CLEARANCE.  
 3. USE SEMI B SCREWS (M4x12) FOR BULKHEAD THICKNESS(A)2≤A≤4  
 OR SCREW LENGTH: A+8±2.

DRAWN	10/Jun/2018	YAMASAKI	TITLE	RDJ-024
CHECKED	10/Jun/2018	H.MAKI	名稱	ECDIS操作部(卓上装備)
APPROVED	11/Jan/2018	H.MAKI	FDI-3200/3300	外寸図
SCALE	1/4	MASS 2.1 kg	重量は5kgでアブルを含む。 WASS INCLUDES 5kg	NAME
DRAWING	C4473-G19-A	REF. NO.	24-014-5106-1	OUTLINE DRAWING

表1 TABLE 1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
L ≤ 50	±1.5
50 < L ≤ 100	±2.5
100 < L ≤ 500	±3



## 注記

1) 指定外の寸法公差は表 1 による。


2) #印寸法は最小サービス空間寸法とする。

3) 取付ネジはセムスネジ B M4×12を使用のこと。  
 壁の厚さ (A) は最小2mm、最大4mmとする。  
 または、ネジ長さを A + 8±2 とする。



NOTE 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.  
 2. # MINIMUM SERVICE CLEARANCE.  
 3. USE SEMI B SCREWS (M4x12) FOR BULKHEAD THICKNESS(A)2≤A≤4  
 OR SCREW LENGTH: A+8±2.

信号ケーブル  
SIGNAL CABLE  
339


信号電源ケーブル (5m)  
POWER/SIGNAL CABLE



A

矢視B  
VIEW B

C



- NOTE  
1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.  
2. #: MINIMUM SERVICE CLEARANCE.  
3. BULKHEAD THICKNESS(A):  $10 \leq A \leq 20$ .

注記  
1) 指定外の寸法公差は表 1 による。  
2) #印寸法は最小サービス空間寸法とする。  
3) 壁の厚さ (A) は最小10mm、最大20mmとする。





表1 TABLE 1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
$L \leq 50$	$\pm 1.5$
$50 < L \leq 100$	$\pm 2.5$
$100 < L \leq 500$	$\pm 3$

DRAWN 10/Jun/2018 T.YAMASAKI	APPROVED 11/Jun/2018 H.MAKI	SCALE 1/4	NAME C4473-G13-A	TITLE RCU-024
CHECKED 10/Jun/2018 H.MAKI	CD-3200/3300 FD-3200/3300	NAME		名稱 ECDIS 操作部 (埋込装置)
		REF. NO.	24-014-5006-1	外寸図
				OUTLINE DRAWING

表1 TABLE 1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
$L \leq 50$	$\pm 1.5$
$50 < L \leq 100$	$\pm 2.5$
$100 < L \leq 500$	$\pm 3$



- NOTE  
 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.  
 2. #: MINIMUM SERVICE CLEARANCE.  
 3. BULKHEAD THICKNESS(A):  $10 \leq A \leq 20$ .

- 注記  
 1) 指定外の寸法公差は表 1 による。  
 2) #印寸法は最小サービス空間寸法とする。  
 3) 壁の厚さ (A) は最小10mm、最大20mmとする。

DRAWN	10/Jun/2018 T.YAMASAKI	APPROVED	11/Jun/2018 H.MAKI	SCALE	1/4	NAME	ECDIS CONTROL UNIT (FIXTURE MOUNT)
DRAWN	10/Jun/2018 T.YAMASAKI	APPROVED	11/Jun/2018 H.MAKI	SCALE	1/4	NAME	ECDIS CONTROL UNIT (FIXTURE MOUNT)
CHECKED	10/Jun/2018 H.MAKI	FD-3200/3300	FD-3200/3300	REF. NO.	24-04-5205-1	OUTLINE DRAWING	OUTLINE DRAWING

FURUNO






表1 TABLE 1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
$L \leq 50$	$\pm 1.5$
$50 < L \leq 100$	$\pm 2.5$
$100 < L \leq 500$	$\pm 3$

- 注記 1) 指定外の寸法公差は表1による。  
 2) #印寸法は最小サービス空間寸法とする。  
 3) 取付ネジはセムスネジ M3×1.2を使用のこと。壁の厚さ(A)は最小2、最大4とする。それ以外はねじ長さをA+8±2とする。

NOTE 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.  
 2. #. MINIMUM SERVICE CLEARANCE.


3. USE SEMS B SCREWS M3X12 FOR BULKHEAD THICKNESS (A):  $2 \leq A \leq 4$ .  
 OR SCREW LENGTH: A+8±2.

RCU-026

名稱 トラックボール操作部(卓上装備)

外寸図

NAME TRACKBALL CONTROL UNIT (TABLETOP MOUNT)  
 REF.No. 24-014-150G-2  
 DRAWING NO. C4473-05-C  
 OUTLINE DRAWING



FURUNO




底面図  
BOTTOM VIEW

表1 TABLE 1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
$L \leq 50$	$\pm 1.5$
$50 < L \leq 100$	$\pm 2.5$
$100 < L \leq 500$	$\pm 3$

NOTE

1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
2. #. MINIMUM SERVICE CLEARANCE.
3. USE TAPPING SCREWS  $\phi 5 \times 20$  FOR FIXING THE UNIT.

DRAWN

RCU-026

CHECKED

H.MAKI

APPROVED

H.MAKI

FD-3200

SCALE

1/2

MASS

1.5

kg

NAME

TRACKBALL CONTROL UNIT (Fixture Mount)

DWG.No.

C4473-007-C

REF.No.

24-014-170G-2

OUTLINE DRAWING

名称 トラックボール操作部(取付金具)  
外寸図




表1 TABLE 1

- 注 記 1) 指定外の寸法公差は表1による。  
 2) #印寸法は最小サービス空間寸法とする。  
 3) 取付用ネジはトラスタッピンネジ呼び径 $4 \times 20$ を使用のこと。

- NOTE 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.  
 2. #: MINIMUM SERVICE CLEARANCE.  
 3. USE TAPPING SCREWS  $\phi 4 \times 20$  FOR FIXING THE UNIT.

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
$L \leq 50$	±1.5
$50 < L \leq 100$	±2.5
$100 < L \leq 500$	±3

DRAWN 11/Jan/2012 T.YAMASAKI		TITLE MC-3000S
CHECKED 11/Jan/2012 H.MAKI		名称 センサー アダプター (シリアル)
APPROVED 13/Jan/2012 Y.NISHIYAMA	FMD-3200	外寸図
SCALE 1/2	MASS 1.5 kg	質量はケーブルを含まず。 MASS DOES NOT INCLUDE CABLE.
DWG. No. C4473-G08-A	REF. No. 24-014-200G-1	NAME SENSOR ADAPTER (SERIAL) OUTLINE DRAWING




表1 TABLE 1

- 注 記 1) 指定外の寸法公差は表 1 による。  
2) #印寸法は最小サービス空間寸法とする。  
3) 取付用ネジはトラスタッピンネジ呼び径  $4 \times 20$  を使用のこと。

- NOTE 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.  
2. #: MINIMUM SERVICE CLEARANCE.  
3. USE TAPPING SCREWS  $\phi 4 \times 20$  FOR FIXING THE UNIT.

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
$L \leq 50$	±1.5
$50 < L \leq 100$	±2.5
$100 < L \leq 500$	±3

DRAWN 11/Jan/2012 T.YAMASAKI		TITLE MC-3010A
CHECKED 11/Jan/2012 H.MAKI		名称 センサー アダプター (アナログ)
APPROVED 13/Jan/2012 Y.NISHIYAMA	FMD-3200	外寸図
SCALE 1/2	MASS 0.8 kg	質量はケーブルを含まず。 MASS DOES NOT INCLUDE CABLE.
DWG. No. C4473-G09-A	REF. No. 24-014-210G-1	NAME SENSOR ADAPTER (ANALOG) OUTLINE DRAWING




表1 TABLE 1

- 注 記 1) 指定外の寸法公差は表 1 による。  
 2) #印寸法は最小サービス空間寸法とする。  
 3) 取付用ネジはトラスタッピンネジ呼び径  $4 \times 20$  を使用のこと。

- NOTE 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.  
 2. #: MINIMUM SERVICE CLEARANCE.  
 3. USE TAPPING SCREWS  $\phi 4 \times 20$  FOR FIXING THE UNIT.

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
$L \leq 50$	±1.5
$50 < L \leq 100$	±2.5
$100 < L \leq 500$	±3

DRAWN 11/Jun/2012 T.YAMASAKI		TITLE MC-3020D
CHECKED 11/Jun/2012 H.MAKI		名称 センサー アダプター (デジタルイン)
APPROVED 13/Jun/2012 Y.NISHIYAMA	FMD-3200	外寸図
SCALE 1/2	MASS 0.8 kg	質量はケーブルを含まず。 MASS DOES NOT INCLUDE CABLE.
DWG. No. C4473-G10-A	REF. No. 24-014-220G-1	NAME SENSOR ADAPTER (DIGITAL IN) OUTLINE DRAWING




表1 TABLE 1

- 注 記 1) 指定外の寸法公差は表 1 による。  
 2) #印寸法は最小サービス空間寸法とする。  
 3) 取付用ネジはトラスタッピンネジ呼び径  $4 \times 20$  を使用のこと。

- NOTE 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.  
 2. #: MINIMUM SERVICE CLEARANCE.  
 3. USE TAPPING SCREWS  $\phi 4 \times 20$  FOR FIXING THE UNIT.


寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
$L \leq 50$	±1.5
$50 < L \leq 100$	±2.5
$100 < L \leq 500$	±3

DRAWN 11/Jan/2012 T.YAMASAKI			TITLE MC-3030D
CHECKED 11/Jan/2012 H.MAKI			名称 センサー アダプター (デジタルアウト)
APPROVED 13/Jan/2012 Y.NISHIYAMA	FMD-3200		外寸図
SCALE 1/2	MASS 0.8 kg	±10% 質量はケーブルを含まず。 MASS DOES NOT INCLUDE CABLE.	NAME SENSOR ADAPTER (DIGITAL OUT)
DWG. No. C4473-G11-A	REF. No. 24-014-230G-1		OUTLINE DRAWING

FURUNO

表1 TABLE 1

寸法区分 (mm)		公差 (mm) TOLERANCE
L ≤ 50		±1.5
50 < L ≤ 100		±2.5
100 < L ≤ 500		±3



- 注記  
1) 指定外の寸法公差は表1による。  
2) #印寸法は最小サービス空間寸法とする。


- 3) 取付用ネジはトラスツッピンネジ呼び径4×20を使用のこと。  
NOTE 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.  
2. #. MINIMUM SERVICE CLEARANCE.

3. USE TAPPING SCREWS Ø4x20 FOR FIXING THE UNIT.

NOTE	1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED. 2. #. MINIMUM SERVICE CLEARANCE.	DRAWN 8/Jun/2018 I.YAMASAKI	NAME HUB-3000
		CHECKED 8/Jun/2018 H.MAKI	名稱 インテリジェントハブ
		APPROVED 8/Jun/2018 H.MAKI	外寸図
		SCALE 1/3 MASS 1.5 kg 質量はケーブルを含まず。 DWG. No. C4473-G12-C REF. No. 24-014-350G-2	NAME INTELLIGENT HUB OUTLINE DRAWING

表1 TABLE 1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
$L \leq 50$	$\pm 1.5$
$50 < L \leq 100$	$\pm 2.5$
$100 < L \leq 500$	$\pm 3$



- 注 記 1) 指定外の寸法公差は表 1 による。  
 2) #印寸法は最小サービス空間寸法とする。  
 3) 取付用ネジはトラスタッピンネジ呼び径  $5 \times 20$  を使用のこと。  
 4) 壁掛装備は、必ずコネクタが下方となるよう取付けること。

- NOTE 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.  
 2. #: MINIMUM SERVICE CLEARANCE.  
 3. USE TAPPING SCREWS  $\phi 5 \times 20$  FOR FIXING THE UNIT.  
 4. FOR BULKHEAD MOUNT, FACE THE CONNECTORS DOWNWARD.

DRAWN 22/Aug/2019	T.YAMASAKI		TITLE RCB-002/002A
CHECKED 22/Aug/2019	H.MAKI		名称 レーダー接続箱(壁掛・卓上装備)
APPROVED 22/Aug/2019	H.MAKI	KQ-900 FMD-3100	外寸図
SCALE 1/4	MASS 3.0 $\pm 10\%$ kg		NAME RADAR CONNECTION BOX (BULKHEAD / TABLETOP MOUNT)
DWG. No. C4484-G03-C	REF. No. 24-016-130G-1		OUTLINE DRAWING









表1 TABLE 1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
$L \leq 50$	$\pm 1.5$
$50 < L \leq 100$	$\pm 2.5$
$100 < L \leq 500$	$\pm 3$
$500 < L \leq 1000$	$\pm 4$
$1000 < L \leq 2000$	$\pm 5$


矢視B  
VIEW B

## 注記

- 1) 指定外の寸法公差は表1による。
- 2) 取付用ネジはM12ボルトを使用のこと。
- 3) 質量は標準構成に、オプションのHUB-100、HUB-3000、PR-241、MC-3000S、MC-3010Aを含む。

- NOTE
1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
  2. USE M12 BOLTS FOR FIXING THE UNIT.
  3. MASS INCLUDES STANDARD CONFIGURATION AND OPTIONS (HUB-100, HUB-3000, PR-241, MC-3000S, MC-3010A).

DRAWN 29/Sep/2022 I.YAMASAKI	CHECKED 29/Sep/2022 H.MAKI	APPROVED 17/Jan/2023 H.MAKI	SCALE 1/16
NAME ECN-304	NAME STANDARD CONSOLE	NAME STANDAR-D CONSOL-ER	NAME 外寸図
ITEM FMD-3200/3005	ITEM	ITEM	ITEM
REF. NO. C4473-G13-C	REF. NO. 24-014-311G-3	REF. NO.	REF. NO. OUTLINE DRAWING

**FURUNO**

注記  
1) 指定外の寸法公差は表1による。  
2) #印寸法は最小サービス空間寸法とする。  
3) 取付ネジはM10ボルトまたはコ一チボルト呼び径9を使用のこと。

D


NOTE  
1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.  
2. # MINIMUM SERVICE CLEARANCE.  
3. USE M10 BOLTS OR COUPLING SCREWS φ9 FOR FIXING THE UNIT.

DRAWN	1/Nov/2022	S. HAN	TITLE MU-270W 名稱 表示部(連結台タイプ) 外寸図
CHECKED	1/Nov/2022	T. YAMASAKI	
APPROVED	9/Nov/2022	H. MAKI	
SCALE	1/10	MASS 32 kg 注意はケーブル・オプションを含まず。 MASS DOES NOT INCLUDE CABLE OPTION.	


NAME	MONITOR UNIT (CONNECTION STAND TYPE)
REF. NO.	C4493-004-1
DATE	26-09-1306-3
NOTE	OUTLINE DRAWING

**FURUNO ELECTRIC CO., LTD.**


A




B



C



D



## 注記


- \* 1) 造船所手配。
  - \* 2) オプション。
  - \* 3) 10mケーブルは、MU-190のみ使用可。
- NOTE  
 \*1: SHIPYARD SUPPLY.  
 \*2: OPTION.  
 \*3: 10 m CABLE IS AVAILABLE ONLY FOR MU-190.

DRAWN	19/Jun/2023 T. YAMASAKI
CHECKED	19/Jun/2023 H. MAKI
APPROVED	21/Jun/2023 H.MAKI
SCALE	MASS kg
DWG. No.	C4522-C01- B


TITLE	FMD-3005
名称	電子海図情報表示装置
相互結線図	
NAME	ECDIS
REF. No.	24-014-6001-4

INTERCONNECTION DIAGRAM


A



B



C



D





ネットワーク機器  
NETWORK EQUIPMENT

インテリジェントハブ  
INTELLIGENT HUB \*2 \*4  
HUB-3000

センサー アダプター  
SENSOR ADAPTER  
MC-3000S (SERIAL 8ch)  
MC-3010A (ANALOG 3ch)  
MC-3020D (DIGITAL IN)  
MC-3030D (DIGITAL OUT)

(詳細はC4473-C02を参照)  
(REFER TO C4473-C02 FOR DETAIL)



注記

\* 1) 造船所手配。

\* 2) オプション。

\* 3) 10mケーブルは、MU-190のみ使用可。

\* 4) IEC61162-450 Ed. 1でネットワークを構成するときは、HUB-100も使用可。

NOTE


\*1: SHIPYARD SUPPLY.

\*2: OPTION.


\*3: 10 m CABLE IS AVAILABLE ONLY FOR MU-190.

\*4: HUB-100 ALSO AVAILABLE WHEN THE NETWORK FOR IEC61162-450 Ed. 1 IS USED.

DRAWN	19/Jun/2023 T. YAMASAKI	TITLE	FMD-3200 (-BB) /3300
CHECKED	19/Jun/2023 H. MAKI	名称	電子海図情報表示装置
APPROVED	21/Jun/2023 H.MAKI	相互結線図	
SCALE	MASS	NAME	ECDIS
DWG. No.	C4473-C01- Q	REF. No.	24-014-6001-4



A



## 注記

\* 1) 造船所手配。

\* 2) オプション。

\* 3) センサー アダプターは MC-3000S を含む  
3 台までコンソール内に収納可。

## NOTE

\*1: SHIPYARD SUPPLY.

\*2: OPTION.

\*3: A CONSOLE CAN INCLUDE THREE UNITS (MC-3000S INCLUDED)  
AMONG SENSOR ADAPTERS.

DRAWN		29/Sep/2022 T. YAMASAKI
CHECKED		29/Sep/2022 H. MAKI
APPROVED	17/Jan/2023 H. MAKI	FMD-3005 FMD-3200/3300
SCALE	MASS	kg
DWG. No.	C4473-C03- G	REF. No. 24-014-6301-3

TITLE		ECN-303/304-A/B/C
名称		スタンダードコンソール
相互結線図		
NAME	STANDARD CONSOLE	INTERCONNECTION DIAGRAM