

**For NN3D only!**

## **Read This First!!- BBWX! Installation Guidelines**

**This guide is intended as a supplement to the operators and installation manual contained on the DVD. Please refer to both documents as required.**

**In order to properly connect and configure the BBWX1 with NN3D, the following items MUST be completed.**


- 1. Update (or confirm) all NN3D MFD processors and displays to BBWX1 compatible software. This software must be version 1.11 or higher. The software and instructions are located on the DVD.**
- 2. Record the DATA ESN (not audio ESN) from the back of the BBWX1, then call Sirius (1-800-869-5480) to activate the WX (weather) subscription. The subscriber's contact and payment information must be available to activate the account.**
- 3. Connect the BBWX1 to the NN3D network. (See diagram)**

## To activate the BBWX1 Sirius Weather receiver

1. Write down the DATA ESN number  
*(located on the white sticker on the bottom of the receiver module)*
2. Connect the Sirius antenna and power cable to power on the receiver.
3. Call Sirius at (800) 869-5480, to initiate the account activation.



## Connecting the BBWX1 to the NN3D Network



The Ethernet cable supplied with the BBWX1 can be connected directly to an Ethernet hub. For single display / processor connections, see the INST Guide.