

\*The command list for USB keyboard

		F		F11		1	Tilt lever +1 (down)	NumLock+"0"	Screen shot
		T	Target Lock	7		2	Tilt lever -1 (UP)		
W	Retract	P	Fish Mark1	8		4	Range +1	Proceed key	Range +1
H		,	Fish Mark2	9		3	Range -1	Back key	Range -1
I	Full-Protrude	M	Menu	0		L	USER PROG +1		
B		Z	Off Center			J	USER PROG -1		
Q		C	Erase Marks			G	GAIN +1		
5		F1	F1			D	GAIN -1		
6		F2	F2			Y	Play Still Images	The key commands in green color are not related to keys on control unit.	
V		F3	F3			X	Record Still Images		
S		F4	F4			U	Reload SignalInfo file		
A		F5							
N		F6							
E	Event Mark1	F7							
O	Event Mark2	F8							
R		F9							

In the case of CSH-10, key commands in red color will be able to operate without any special procedure.



Note) In regard with "Brilliance+1/-1", they are only for "Panel test" and they are not available with our MU-190HD etc in normal use actually.

Proceed key

Back key

