

MAXSEA

MARINE SOFTWARE

Press F1 for Help

Press the F1 keyboard shortcut or go to the Help menu and choose the User Guide.

Click Search, type the word or phrase to search, then click List Topics.

Select the topic you want to print, and then click Print.

Printing the User Guide

To print the complete User Guide, go to Windows Start menu, Programs, MaxSea utilities and choose "Operator's Manual.pdf" or "Installation's Manual.pdf".

Organizing the Chart Desktop

Right-clicking on each palette title opens a context menu where you can choose display options such as transparency and the size of the buttons and text.

To move each palette, click on its title bar, hold the mouse button down, drag it to the new position and release the mouse button.

Double-click in the title bar of each palette to dock it around the edge of the chart window (top, bottom, right, left).




Click on the arrow in the title bar of each palette to add or remove buttons as you wish.



Click on the cross in the title bar of each palette to close it (reopen in Display Menu).



Click on the bar at the left side of any "docked" palette and drag it to make it a "floating" palette.



Keyboard Shortcuts

Shortcuts	Action
Ctrl + M	Activate AIS MKD
Ctrl + T	Activate AIS TX message
Ctrl + N	Create a new file
Ctrl + O	Open a file
Ctrl + W	Close a file
Ctrl + S	Save the current file
Ctrl + P	Print
Ctrl + F	Activate On/Off Full Screen mode
Ctrl + X	Delete selected object
Ctrl + C	Copy selected object
Ctrl + V	Paste selected object
Ctrl + A	Select all objects
Ctrl + D	Unselect all objects
F1	Access the User Guide
F2	Zoom In
F3	Zoom Out
F4	Center On/Off
F5	Track On/Off
F6	Create a logbook entry
F7	Select the next leg
F8	Select the previous leg
F10	Tides and Currents display On/Off
F11	Weather display On/Off
F12	Activate Man Overboard function
Shift + F1	Switch tools: zoom, pan, etc...
Shift + F2	Switch lighting level (day, night, dusk)
Shift + F4	Switch between north/course/head up
Shift + F5	PBG On/Off
Shift + F6	Save an event
Shift + F7	Show/Hide Vector Chart
Shift + F8	Show/Hide Raster Chart
Shift + F9	Show/Hide Depth Profile Window
Shift + F10	Show/Hide 2D display
Shift + F11	Show/Hide 3D display
Shift + F12	Radar Overlay On/Off

MaxSea International
www.maxsea.com

Copyright © MaxSea International - 2006


Quick Reference Card

MAXSEA

MARINE SOFTWARE

The Chart Toolbar

A few clicks is all it takes to display the chart in Auto-centering mode, North Up/Course Up modes and to call up Tide, Current and Weather.



Right-click for more

Quickly access commands or information related to a selected object by positioning the pointer on the object or group of objects and right-clicking.

Zooming Options

1 - Use the Zoom In and Zoom Out Activation Buttons



2 - Use the F2 and F3 keyboard shortcuts or the +/- keys

3 - Use the Magnifying Tool



To zoom in: Click and hold while dragging the pointer across the selected chart area, then release to zoom in.

To zoom out: Click and release immediately

4 - Using any Tool, right-click on the chart to select a chart scale



5 - Using a mouse or track ball with a wheel, roll up and down to zoom in and out



The Toolbar

Click on tool buttons to define what task the pointer will perform.

Title Bar

Activation Buttons

To save Event and activate Man Over Board



To activate and stop tracking



(* optional feature)

To activate and stop PBG Personal Bathing Generator (*)



To change Radar range in (*)



To change Radar range out (*)



Zoom In

Zoom Out

Navigation Tools

To change chart scale



To pan charts and access chart data



To calculate headings, distances & EBL/VRM



To take bearings

To pick a quick route or activate a route



To build a route

Selection & Modification Tools

To insert a waypoint or a point in a line



To Cut a line or track in two parts



To select and move an object, point or waypoint



To remove information

To Plot waypoints, marks, lines, areas or text



To select and display information about a specific object

Plotting Object Definition

To choose plotting object type



To choose plotting symbol

To choose plotting font size



To choose plotting color

To choose plotting line width



To choose plotting pattern

Additional Display Options

To select Chart Desktop mode



To select day, dusk or night color mode