CLINICIPAL FM-7000 OPERATOR'S GUIDE CLINICIPAL

ITEM			KEYSTROKE		
CH16 DISTRESS CALL			сн16		
AUTO REVERT WATCH ON CURRENT CH. WITH THE HANDSET ON THE REST.		RENT	Hang the handset in the handset rest. (Ch16 is automatically selected.) INTL SHIFT 1 etc.		
CHANNEL SELECTION			(Channel Number) ENT (or rotate channel selector)		
CH MODE (INTL/USA/WX) SELECTION		TL/USA/WX)	SHIFT 1 etc.		
MEMORY OPERATION STORE DELETE		RECALL	RCL (Memory Number) ENT		
		STORE	STO SHIFT RCL (Memory Number) ENT (Channel Mode: INTL/USA) ENT (Channel Number) ENT		
		DELETE	STO SHIFT RCL (Memory Number) ENT 0 ENT		
DUAL WATCH		sired CH I CH16	(Desired Channel Number) ENT SHIFT CH16		
	gua	ired CH and rd CH (in U.S. ers)	SHIFT + CH 16 (U.S. coast guard channel should be stored in MEMO 0)		
SCANNING START		START	SHIFT 5		
(Multiple Watch)		STOP	Press the PTT switch or any key.		
		SETTING SCAN PARAM- ETERS	SHIFT + SCAN → HI/LOW → (1~9) ENT Dual watch guantity Select HOLD or LOCK mode		

OPTIO	These functions require optional devices. Check here if the function is available	P			
HAILER		HAILER SHIFT 8			
DSC(class-C) INDIVIDUAL CALL INTERCOM		SHIFT ID (Receiving station's ID) ENT SHIFT 9 SHIFT 7 (2~5) ENT			
					BEEP

